


SIM508EVB USER GUIDE



SIMCOM Ltd.
21st Feb 2006



Document Name:	SIM508 EVB User Guide
Version:	1.01
Date:	2006-02-21
Doc ID:	SIM508-EVB_UGD_V1.01
Status:	Released

General Notes

Simcom offers this information as a service to the customers, to support application and engineering efforts that use the products designed by Simcom. The information provided is based upon requirements specifically provided to Simcom by the customers. Simcom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by Simcom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of SIMCOM Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © SIMCOM Limited. 2005

Contents

Contents	2
Version History	4
1. SIM508 EVB overview.....	5
2. EVB accessory	7
3. Accessory interface	8
3.1 Power interface	8
3.2 Audio interface	9
3.3 SIM card interface.....	10
3.4 Antenna interface	11
3.4.1 GSM antenna interface.....	11
3.4.2 GPS antenna interface.....	12
3.5 RS232 interface.....	13
3.5.1 GSM part:.....	13
3.5.2 GPS part	14
3.6 Operating status LED.....	15
3.6.1 GSM part:.....	15
3.6.2 GPS part	16
4. Test interface	16
4.1 GSM serial ports	17
4.2 Keypad	18
4.3 LCD & ADC	19
4.4 GPS control & I/O.....	20
4.5 GPS serial ports and power	21
5. EVB and accessory equipment.....	22
6. Illustration:	22
6.1 GSM part.....	22
6.1.1 Running:.....	22
6.1.2 Connecting Net and calling.....	23
6.1.3 Downloading	23
6.1.4 Turn off.....	23
6.1.5 Charging	23
6.2 GPS part	23
6.1.1 Running:.....	23
6.1.2 Tracking the satellite signals	24
6.1.3 Downloading	24
6.1.4 Turn off and Reset	24

Figure Index

FIGURE 1: TOP VIEW	5
FIGURE 2: BOTTOM VIEW	5
FIGURE 3: EVB ACCESSORY	7
FIGURE 4: POWER INTERFACE	8
FIGURE 5: AUDIO INTERFACE	9
FIGURE 6: SIM CARD INTERFACE	10
FIGURE 7: GSM ANTENNA INTERFACE	11
FIGURE 8: GPS ANTENNA INTERFACE	12
FIGURE 9: GSM PART SERIAL PORTS	13
FIGURE 10: GPS PART SERIAL PORTS	14
FIGURE 11: GSM PART LED	15
FIGURE 12: GPS PART LED	16
FIGURE 13: TEST INTERFACE OVERVIEW	16
FIGURE 14: GSM SERIAL PORTS	17
FIGURE 15: KEYPAD INTERFACE	18
FIGURE 16: LCD & ADC INTERFACE	19
FIGURE 17: GPS CONTROL & I/O INTERFACE	20
FIGURE 18: GPS SERIAL PORTS	21
FIGURE 19: EVB AND ACCESSORY EQUIPMENT	22

Version History

Data	Version	Description of change	Author
2006-2-21	1.01	Origin	Simon

SCOPE

This document give the usage of SIM508 EVB, user can get useful info about the SIM508 EVB quickly through this document.

This document is subject to change without notice at any time.

1. SIM508 EVB overview




Figure 1: TOP view




Figure 2: BOTTOM view

A: 80pin connector, SIM508 module interface

B1-B5: LED indicator

B1: VBAT ON/OFF

B2: GSM net status

B3: The GSM part of the module ON/OFF status

B4: 1PPS output for GPS part

B5: GPS TX/RX status

C1-C9: Key control for various functions

C1: GSM part power-up / power down control (button Z1)

C2: VBAT ON/OFF control (shifter S2)

C3: VCHG ON/OFF control (shifter S5)

C4: GSM part program download control (shifter S1)

C5: GPS part power ON/OFF control (shifter S7)

C6: GPS part reset control (button Z2)

C7: GPS part RX/TX LED status selective shifter (shifter S6)

C8: GPS part wake up control (shifter S3)

C9: GPS part program download control (shifter S4)

D: Power source adapter interface

E1-E3: Audio interface

E1: Handset interface

E2: Headphone interface

E3: Buzzer

F1-F4: Serial ports

F1: Main serial port for downloading, AT command transmitting, data exchanging

F2: Debug serial port

F3: GPS part serial port A

F4: GPS part serial port B

G1-G2: Hole for antenna fixed

G1: Hole for GSM antenna fixed

G2: Hole for GPS antenna fixed

H: Expand port, such as keypad port, serial ports, display port

I1-I4: Hole for EVB board fixed

J: SMA connector for 1PPS output

K: SIM card connector

L: 3.3V Back-up battery for GPS part

2. EVB accessory




Figure 3: EVB accessory

- A: antenna
- A: 5V DC source adapter
- B: GSM antenna
- C: GPS antenna
- D: RF cable
- E: Earphone
- F: serial port line

3. Accessory interface

3.1 Power interface




Figure 4: Power interface

Pin	Signal	I/O	Description
1	Adapter input	I	5V/2.5A DC source input

3.2 Audio interface




Figure 5: Audio interface

Headset interface:

Pin	Signal	I/O	Description
1	MIC1P	I	Positive microphone input
2	SPK1P	O	Positive microphone input
3	SPK1N	O	Negative microphone input
4	MIC1N	I	Negative microphone input

Headphone interface:

Pin	Signal	Input/Output	Description
5	MIC2P&SPK2P	I/O	Auxiliary positive input and output

3.3 SIM card interface




Figure 6: SIM card interface

Note: Please refer to SIM508 User Guide, detailed in Chapter 3.11 SIM interface.

3.4 Antenna interface

3.4.1 GSM antenna interface




Figure 7: GSM antenna interface

3.4.2 GPS antenna interface





Figure 8: GPS antenna interface

3.5 RS232 interface

3.5.1 GSM part:




Figure 9: GSM part serial ports

Serial Port 1

Pin	Signal	I/O	Description
1	DCD	O	Data carrier detection
2	TXD	O	Transmit data
3	RXD	I	Receive data
4	DTR	I	Data Terminal Ready
5	GND		GND
7	RTS	I	Request to Send
8	CTS	O	Clear to Send
9	RI	O	Ring Indicator

Serial Port 2

Pin	Signal	I/O	Description
2	DEBUG_TX	O	Transmit data
3	DEBUG_RX	I	Receive data
5	GND		GND

3.5.2 GPS part




Figure 10: GPS part serial ports

Serial port 1:

Pin	Signal	I/O	Description
2	GPS_TXA	O	Transmit data
3	GPS_RXA	I	Receive data
5	GND		GND

Serial port 2:

Pin	Signal	I/O	Description
2	GPS_TXB	O	Transmit data
3	GPS_RXB	I	Receive data
5	GND		GND

3.6 Operating status LED

3.6.1 GSM part:




Figure 11: GSM part LED

Name	Description	STATUS
VBAT_LED	VBAT ON/OFF indicator	Bright: VBAT ON; Extinct: VBAT OFF
GSM_NET_LED	GSM_NET status indicator	Blinking at a certain frequency according to various GSM net status
MO_STATUS_LED	GSM part status indicator	Not used, will be configured in our latter software.

3.6.2 GPS part



Figure 12: GPS part LED

Name	Description	STATUS
1PPS_LED	1PPS signal indicator	Not used currently
RX/TX_LED	Run or download indicator	Run normally: Blinking at 1Hz Download: Blinking rapidly

4. Test interface




Figure 13: Test interface overview

4.1 GSM serial ports




Figure 14: GSM serial ports

Pin	Signal	I/O	Description
1	TXD	O	Transmit data
2	RXD	I	Receive data
3	DCD	O	Data carrier detection
4	RI	O	Ring Indicator
5	CTS	O	Clear to Send
6	GND		GND
7	DTR	I	Data Terminal Ready
8	DEBUG_RX	I	Receive data
9	RTS	I	Request to Send
10	DEBUG_TX	O	Transmit data

4.2 Keypad




Figure 15: Keypad interface

Pin	Signal	I/O	Description
1	KCOL0	O	Keypad array interface
2	KROW0	I	
3	KCOL1	O	
4	KROW1	I	
5	KCOL2	O	
6	KROW2	I	
7	KCOL3	O	
8	KROW3	I	
9	KCOL4	O	
10	KROW4	I	
11	GPIO32	I/O	GPIO32 reserved for user.
12	PWRKEY	I	power on key
13	GND		GND
14	VBAT	I	VBAT

4.3 LCD & ADC




Figure 16: LCD & ADC interface

Pin	Signal	I/O	Description
1	DISP_EN	O	Display enable output
2	GPIO_5	I/O	GPIO5 reserved for user
3	DISP_CLK	O	Display clock output
4	BUZZER	O	Buzzer output.
5	DISP_D0	I/O	Display data line
6	AUXADC1	I	Adc input
7	DISP_A0	O	Display data or address select
8	SIM_PRESENCE	I	SIM Card Detection
9	NCLDRESET	O	Display reset outplay
10	TEMP_BAT	I	For measure the batter temperature

4.4 GPS control & I/O




Figure 17: GPS control & I/O interface

Pin	Signal	I/O	Description
1	GPS_ON_OFF	I	GPS ON/OFF key
2	GPS_GPIO0	I/O	Reserved.
3	GPS_BOOTSEL	I	For re-programming the Flash, it must be set to High
4	GPS_GPIO4	I/O	Reserved.
5	GPS_MRST	I	Reset pin of the GPS part, active low.
6	GPS_GPIO8	I/O	Reserved.
7	GPS_TIMEMARK	O	1 PPS timemark output for synchronizing to within 1 microsecond of GPS time.
8	GPS_GPIO13	I/O	Reserved.
9	GPS_FREQ_XFER	I	External CMOS clock source. This pin applies to the SiRFLoc Client firmware, if unused, keep floating
10	GPS_GPIO14	I/O	Reserved.
11	GND		GND
12	GPS_TIMERSYNC	I	External CMOS clock source. This pin applies to the SiRFLoc Client firmware, if unused, keep floating
13	GND		GND
14	GPS_VCC	I	GPS part power supply

4.5 GPS serial ports and power




Figure 18: GPS serial ports

Pin	Signal	I/O	Description
1	GPS_TXB	O	GPS serial interface.
2	GPS_TXA	O	
3	GPS_RXB	I	
4	GPS_RXA	I	
5	GPS_VCC_RF	I	Power supply for 3V active antenna.
6	GPS_VANT	I	External DC power supply for an active antenna.
7	GPS_VCC_RF	I	Power supply for 3V active antenna.
8	GPS_VRTC	I	Apply 3V dc for backup RTC & SRAM.
9	GND		GND
10	GND		GND

5. EVB and accessory equipment

At normal circumstance, the EVB and its accessory are equipped as the following figure:




Figure 19: EVB and accessory equipment

6. Illustration:

6.1 GSM part

6.1.1 Running:

- (1) Connect the SIM508 module to the 80pins connector on the SIM508 EVB, insert the 5V direct current source adapter, switch shifter S1 on the RUN state, shifter S2 on the ON state;
- (2) Press the GSM_ON/OFF button Z1 for about 2 seconds , then the GSM part of SIM508 begins to run.

You will see the light GSM_NET on the EVB glittering at a certain frequency corresponding to various states, then you can judge whether the EVB and SIM508 is running or not. No function and test can be executed when we have not connected necessary accessories.

6.1.2 Connecting Net and calling

- (1) Connect the serial port line to the GSM_MAIN serial port, open the HyperTerminal (AT command windows) on your personal computer, the location of the HyperTerminal in windows2000 is START →accessory→ communication →HyperTerminal. Set the correct baud rate and COM number. The default baud rate of SIM508 is 115200 bps, and the COM number based on which port your serial port line insert in, you should select such as COM1, COM3 or COMx etc.
- (2) Connect the GSM antenna to the SIM508 module using an antenna transmit line, insert SIM card into the SIM card interface, insert headphone or handset into its interface.
- (3) Act on the step of running which mentioned above, power on the system, typing the AT command in the HyperTerminal, and then the SIM508 module will execute its corresponding function.

6.1.3 Downloading

Connect the serial port line to the GSM_MAIN serial port, connect the direct current source adapter, run the download program and press the START key, then switch shifter S2 on the ON state, shifter S1 on the D/L state, then the download procedure is executing

6.1.4 Turn off

Press the GSM_ON/OFF button Z1 for about 1 second, the GSM part of SIM508 will be turned off.

6.1.5 Charging

Connect the SIM508 module to the 80pin connector interface and the external battery to charging interface, which have been provided on the EVB. Insert the direct current source adapter; switch shifter S2 on the OFF state, shifter S5 on the ON state, then the SIM508 will go to the charging state.

6.2 GPS part

6.1.1 Running:

- (1) Connect the SIM508 module to the 80pins connector on the SIM508 EVB, insert the 5V direct current source adapter.
- (2) Switch shifter S3 & shifter S4 on the RUN state, shifter S6 on the GPS_TXA state.
- (3) Switch shifter S2 & shifter S7 on the ON state, then the GPS part of SIM 508 begins to run.

You will see the GPS indicator (RX/TX_LED) on the EVB glittering at a 1Hz frequency, then you can judge whether the EVB and the GPS part of SIM508 is running or not. No function and test can be executed when we have not connected necessary accessories.

Note: Be sure of both shifter S3 and shifter S4 is on RUN state when the GPS part of SIM508 is running normally, otherwise the GPS part of SIM508 will be on a undetermined state.

6.1.2 Tracking the satellite signals

- (1) Connect the serial port line to the GPS_COMA serial port
- (2) Connect the GPS antenna to the SIM508 module using an antenna transmit line
- (3) Run the GPS part of SIM508 as 6.1.1 described
- (4) Then you will see the information transmitted by the GPS_COMA serial port in our demo tool or through Hyper Terminal (AT Command widow)

6.1.3 Downloading

- (1) Connect the serial port line to the GPS_COMA serial port,.
- (2) Connect the direct current source adapter
- (3) Switch shifter S3 on RUN state and shifter S4 on the D/L state
- (4) Switch shifter S2 on the ON state and shifter S6 on the GPS_RXA state. (See note)
- (5) Switch shifter S7 on the ON state
- (6) Run the download program and press the execute key, and then the download procedure is executing immediately.

Note: Step (4) is only for the judgement while program downloading form the PC side by the glittering of the LED on EVB board, if you don't need this visual indication or you can judge by the response of the download program on the PC side directly, you can jump to step (5) directly.

6.1.4 Turn off and Reset

- (1) Turn off: Switch shifter S7 on the OFF state, that will cut the power supply for the GPS part directly, and then the GPS part of SIM508 will be turned off immediately.
- (2) Reset: Press the button Z2 and release it lightly, the GPS part of SIM508 will reset immediately, it's necessary when system is running on a emergent state or encountering a unpredictable malfunction and so on .