




Gould 500 Digital Storage Oscilloscope Operator Manual

**Copyright © 1994, 1995
Gould Instrument Systems, Inc
(Gould Instrument Systems Limited)**

Contents	
Introduction	
Getting Started	1
DSO Features	2
The Menus	3
Performance Checking	4
Waveform Processing	5
Alphabetical Summary	6
Error messages	A1
Specification	A2
Remote DC Operation	A3
RS423 to PC interfacing	A4
Connector Pinouts	A5
Front and Back Pictures	A6
Service Facilities	

Introduction	1	2. DSO Features	16
1. Getting Started	2	2.1 Capture Facilities	16
1.1 Safety and Power Requirements	2	2.1.1 Trace Hold	16
1.1.1 Symbols and Terms	2	2.1.2 S/Shot and Run	16
1.1.2 International Safety Warnings	2	2.1.3 Acquisition Status (AFTS)	17
1.1.3 Safety Statement	5	2.2 Display Modes	17
1.1.4 Grounding	5	2.2.1 Refresh	17
1.1.5 Live Parts	5	2.2.2 Roll	17
1.1.6 Environment	5	2.2.3 X-Y	17
1.1.7 Power & Frequency Requirements	6	2.2.4 Persistence	17
1.1.8 EMC	6	2.3 Cursor Measurements	17
1.1.9 Fuse Requirements	6	2.3.1 Cursor and Datum Selection	17
1.2 Using the Buttons	8	2.3.2 The Cursor & Datum Lines	17
1.3 Start-Up Display	8	2.3.3 Making Measurements	18
1.4 Obtaining a Trace	8	2.3.4 Post Storage Manipulation	18
1.4.1 AUTO SETUP	8	2.4 Plot	18
1.4.2 Manually Obtaining a Trace	9	2.4.1 Internal Color Plotter	18
1.5 Display	10	2.4.2 Pens	18
1.5.1 Internal Color Display	10	2.4.3 Pen Changing	18
1.5.2 External Monitor Output	10	2.4.4 Paper Selection	19
1.6 Channel Controls	11	2.4.5 Paper Loading	19
1.6.1 Selection (Off/On/Inv)	11	2.4.6 Internal Plotting	19
1.6.2 Coupling	11	2.4.7 External Plots	19
1.7 Horizontal Adjustments	11	2.4.8 Plot positioning and scaling	19
1.7.1 TIME/DIVISION	11	2.5 Real Time Clock	20
1.7.2 Aliases	12	3. The Menus	21
1.7.3 Position	12	3.1 Additional Buttons	21
1.7.4 Magnification	12	3.1.1 The Numeric Buttons	21
1.8 Vertical Adjustments	12	3.1.2 Menu/Traces	21
1.8.1 VOLTS/DIVISION	12	3.1.3 Menus	21
1.8.2 Position	13	3.2 Control Master Menu	22
1.8.3 Variable/Uncalibrated	13	3.3 Status Menu	23
1.8.4 Add	13	3.4 Display and Acquisition Menu	24
1.9 Trigger Control	13	3.5 Reference Trace	25
1.9.1 Selecting Source & Coupling	13	3.6 I/O Interface Menu	25
1.9.2 Trigger Level	13	3.6.1 RS423 Plot Connections	26
1.9.3 Trigger Point (T)	13	3.6.2 RS423 Data Connections	26
1.9.4 Trigger Slope (+/-)	14	3.6.3 GPIB connections	26
1.9.5 Trigger Mode (Norm/Auto)	14	3.7 Special Functions Menu	27
1.10 Trigger Delay	14	3.8 Post Storage Master Menu	28
1.10.1 Pre-Trigger	15	3.9 Save Trace Menu	28
1.10.2 Delay by Time	15	3.10 Recall Memory Menu	29
1.11 Operating Hints	15	3.11 Plot Menu	29
1.11.1 System Reset	15	4. Performance Checking	30
1.11.2 Internal Display Blank	15	4.1 Risetime	30
1.11.3 Trace off top or bottom of screen	15	4.2 Bandwidth	30
1.11.4 Trace not being acquired	15	4.3 Trigger Sensitivity	30
1.11.5 Trace is unstable	15	4.4 Trigger Bandwidth	31
1.11.6 Trace has very flat top or bottom	16	4.5 Timebase Calibration	31
1.11.7 Auto setup fails	16	4.6 Vertical Calibration	31
1.11.8 Cursor Measurements Wrong	16	4.7 Max-Min (Alias Detector)	31
1.11.9 Single shot takes too long	16		

5. Waveform Processing Functions	32	Figure List	
5.1 Cursor Measurements	32	1.2a	Single Function Buttons
5.1.1 Top and Base Measurement	32	1.2b	The Toggles
5.1.2 Voltage and Time	33	1.2c	The Paddles
5.1.3 Peak to Peak	33	1.3	Start-Up Display
5.1.4 MaxMin	33	1.4	Obtaining a Trace
5.1.5 Risetime (falltime)	34	1.4.1	An AUTO SETUP Display
5.1.6 Overshoot (preshoot)	34	1.5	Rear Panel Display Switches
5.1.7 Pulsewidth	34	1.6	Channel Controls
5.1.8 Frequency Period Duty Cycle	35	1.7	Horizontal Controls
5.1.9 RMS	35	1.7.2	Alias Generation
5.1.10 Area	35	1.8	Vertical Controls
5.2 Trace Manipulation	36	1.9	Trigger Controls
5.2.1 Filter Frequency	36	1.10a	Trigger Delay Controls
5.2.2 Filter Current Trace	37	1.10b	Trace capture With Delay
5.2.3 Invert Current Trace	37	2.1	The Capture Controls
5.2.4 Integrate Scaling	37	2.3	The Cursor and Datum Line Controls
5.2.5 Integrate Current Trace	37	2.3.2	The Cursor and Datum Lines
5.3 Trace Arithmetic	37	2.4.5	Color Plotter Paper Loading
5.4 Persistence Limits Testing	37	2.4.8a	Relative Plot positions
5.4.1 Limits	37	2.4.8b	Plot Dimensions
5.4.2 Persistence	38	3	The Menu Structure
6. Alphabetical Summary of Controls	39	3.1	The Numeric and Menu Buttons
Appendix 1: Screen Messages	41	3.2	The Control Master Menu
Appendix 2: Specification	41	3.3	A Status Menu
Appendix 3: Remote DC Operation of DSO	48	3.4	Display and Acquisition Menu
Appendix 4: RS423 to PC interfacing	49	3.5	Reference Trace Menu
Appendix 5: Connector Pinouts	50	3.6	I/O Interface Menu
Appendix 6: Front and Back Pictures	51	3.6.1	DSO to Gould 6120 or HP7475 Connections
Service Facilities	53	3.6.2a	DSO to IBM-PC/XT Connections
		3.6.2b	DSO to IBM-PC/AT Connections
		3.7	Special Functions Menu
		3.8	Post Storage Master Menu
		3.9	Save Trace Menu
		3.10	Recall Memory Menu
		3.11	Plot Menu
		5.1a	Cursor Measurements Menu
		5.1b	Example of Calculations on Trace
		5.1.1	Waveform Measurement Points
		5.1.2	Voltage & Time Measurement
		5.1.3	Peak to Peak Measurement
		5.1.4	Max & Min Measurement
		5.1.5	Risetime Measurement
		5.1.6	Overshoot Measurement
		5.1.7	Pulse Width Measurement
		5.1.8	Frequency, Period and Duty Cycle
		5.1.10	Area Measurement
		5.2	Trace Manipulation Menu
		5.2.1	Filter Frequencies
		5.3	Trace Arithmetic Menu
		5.4	Persistence/Limits Testing Menu
		A3.1	Internal Power Connections
		A4	PC Interfacing Connections
		A5a	RS423 Connector Pinout
		A5b	GPIO Connector Pinout
		A5c	Monitor Connector Pinout
		A5d	DC Connector Pinout
		A6a	Numbered Front Panel Controls
		A6b	Rear Panel Controls
Tables			
1.1.9	Fuse Ratings		
1.5.1	Color Palettes		
1.9.1	Useful Frequency Ranges		
3.6.1	RS423 Port Pin Connections		
5.2.1	Filter Frequencies		
A3.1	Copper Wire Sizes		





1995

GOULD
Instrument Systems

Manufacturer's Declaration of Conformity

We declare that the product(s) listed below meet the safety requirements of the European Commission Directive 73/23/EEC.

Product	500
---------	-----

Products manufactured after 7th February 1995 meet or exceed the protection requirements of:

EN61010-1:1993 Safety requirements for electrical equipment for measurement, control and laboratory use,

for class 1 (earthed) equipment when installed and used in accordance with the instructions in the operator's manual.

This equipment is not suitable for use in explosive atmospheres or as a component in a life support system.

Quality Engineering Manager

for and on behalf of

Gould Instrument Systems Limited
Roebuck Road, Hainault, Ilford, Essex IG6 3UE, UK.



CERTIFICATE No FM 20892
BS EN ISO 9001 1994

Introduction

WARNING Read section 1.1 Safety and Power requirements before installing or operating this instrument.



About the Instrument

The Gould 500 is a Digital Storage Oscilloscope (DSO). It includes all the features expected of advanced modern oscilloscopes designed for the professional engineer, while retaining the user-friendliness essential for those using such an instrument for the first time.

The instrument is fitted with a color display which allows easy identification of each individual trace. Eight built in color palettes provide various color assignments to suit varying tasks.

Obtaining a trace is especially simple – just connect the signal and press the AUTO SETUP button and the DSO does the rest. Having obtained a trace, readily accessible datum lines and a cursor make it easy to take automatic timing and voltage measurements directly from the display. The waveform processing function increases the power of the cursor measurements in terms of both capture and post storage analysis measurement functions.

More advanced features of the 500 include a comprehensive range of menu-controlled functions and a wide range of trigger features such as the trigger delay and pre-trigger functions. The pre-trigger display function allows the signal *prior* to the trigger point to be captured and displayed.

Traces can be stored for future use and recalled to the display via the Save Trace and Recall Memory menus respectively. With the built in battery back-up facility, these will be retained even when the instrument is switched off.

In addition to the above features, the 500 instrument has a battery backed Real Time Clock and can be fitted with an internal 4 color plotter. This provides a simple and convenient method of obtaining permanent hard copy plots of the

screen display. The plots will contain the date and time of acquisition together with the date and time of plotting.

An external multi-sync monitor can be connected to the 500 so that the display can be viewed from a greater distance or by a number of people at once, making the instrument ideal for presentations.

The instrument can be powered from an external DC supply enabling it to be used at remote locations away from an AC power source.

The 500 has signal bandwidth of 200 MHz, sampling at 200 Megasamples per second.

The 500 is fitted with full GPIB and RS423 remote control interfaces complying with IEEE 488.2 and SCPI 1990.0.

About this Manual

This manual is for use with the Gould 500 Digital Storage Oscilloscope (DSO). It contains information on the operational features of the 500 DSO. For servicing information, refer to the Service Manual.

Section 1.1 must be read and note taken of its contents before using the oscilloscope.

The manual is split into various sections that allow both novice and advanced users to find basic and more advanced operating information.

Section 1 contains information on standard operating features using the front panel controls and section 2 details more advanced features available from the front panel. Section 3 explains the further features that are accessed using the menu system.

Section 4 provides information for basic performance checking and section 5 has details of the waveform processing menu features. Section 6 is a summary of all the front panel controls.

Bracketed numbers in the text refer to the controls shown on the front panel drawing in Appendix 6.



1.1 Safety and Power Requirements

1.1.1 Symbols and Terms



This symbol is used to denote the measurement ground connection. This point is not a safety ground.



This symbol is used to denote a safety ground connection.



Where caution is required, this symbol refers the user to the operator manual for further information. See section 1.1 to section 1.1.8.



This symbol warns the user that high voltages are present close to this symbol.



These symbols show that the supply switch is in its out position and that the instrument is switched off.



These symbols show that the supply switch is in its depressed position and that the instrument is switched on.



This symbol shows that the terminals adjacent to it are for DC supplies.

WARNING statements identify conditions or practices that could be dangerous or fatal to personnel.

CAUTION statements identify conditions that could cause damage to the instrument or other property.

1.1.2 International Safety Warnings

Danish

SIKKERHEDSADVARSEL

Dette instrument skal anvendes med en beskyttelsesjordforbindelse via netkablets jordledning til jordforbindelsen i instrumentets apparatkontakt eller – hvis instrumentet er forsynet dermed – via sikkerhedsjordklemmen. Enhver afbrydelse af sikkerhedsjordforbindelsen vil formentlig gøre instrumentet berøringsfarligt. Bevidst afbrydelse er forbudt. Hvis et indgangssignal overstiger 40 V spidsværdi, skal en ekstra signal jord forbindes.

Dækslerne må ikke fjernes.

Hvis netsikringen springer som følge af en fejl, er det muligt at instrumentets AC netafbryder er blevet beskadiget, hvorfor den bør efterses af en kvalificeret tekniker.

Afbryd instrumentet fra lysnettet ved at fjerne IEC-stikket fra bagpanelet. Dette instruments AC netafbryder er kun beregnet til funktionelle formål. Den er hverken beregnet til eller egnet til afbrydelse af lysnettet.

Nederlands

VEILIGHEIDSWAARSCHUWING

Dit instrument mag uitsluitend worden gebruikt als een beschermende massa (aarde) is aangesloten via de beschermende massageleider van de voedingskabel, of – indien het instrument daarvan is voorzien – via de veiligheids-massa-aansluiting. Als de beschermende massa, binnen of buiten het instrument, wordt onderbroken, dan kan dat hierdoor uitermate gevaarlijk worden. Het opzettelijk onderbreken van de massa, is verboden. Indien er een signaal wordt aangeboden van meer dan 40 V (top-top) dan dient eveneens de signaal aarde aangesloten te zijn.

De deksels nooit verwijderen.

Als dezekering doorbrandt als gevolg van een storing of een defect, dan is het mogelijk dat de wisselstroomvoedingsschakelaar van het instrument beschadigd is. Die schakelaar moet worden gecontroleerd door een deskundig technicus.

Als de IEC-aansluiting op het achterpaneel uit het stopcontact wordt verwijderd, zal het instrument niet langer zijn aangesloten op de wisselstroomvoeding. De wisselstroomvoedingsschakelaar op dit instrument is uitsluitend bestemd voor functionele doeleinden. Die schakelaar mag nooit worden gebruikt om het instrument aan of af te zetten.

Suomi

TURVAOHJEITA

Tätä laitetta käytettäessä sen tulee olla suojamaadoitettu joko verkkojohdon suojajohtimen tai erillisen suojamaadoitusliitännän kautta, mikäli laitteeseen on sellainen asennettu. Suojamaadoituksen katkaiseminen laitteen sisä- tai ulkopuolelta tekevät siitä vaarallisen. Tahallinen katkaisu on kiellettyä. Lisäksi, jos jokin tulosignaaleista ylittää 40 V peak, on signaalimaa kytkettävä.

Älä poista suojakansia.

Mikäli laitteen verkkosulake palaa vian seurauksena, on mahdollista, että laitteen verkkokytkin on vaurioitunut ja se tulee tällöin tarkastuttaa ammattihenkilöllä.

Erotaaksesi tämän laitteen käyttöjännitteestä irrota takapaneelissa oleva IEC-liitin. Tämän laitteen verkkokytkimellä on ainoastaan toiminnallinen tarkoitus. Sitä ei ole tarkoitettu, eikä se sovellu laitteen erottamiseen käyttöjännitteestä.

Français**ATTENTION - DANGER!**

Cet appareil doit impérativement être mis à la masse par le conducteur de terre du câble d'alimentation ou, si l'instrument en comporte une, par la borne de terre. Il peut être dangereux en cas de coupure du circuit de terre, que ce soit à l'intérieur ou à l'extérieur de l'instrument. Il est formellement interdit de couper intentionnellement le circuit de terre. De plus, une masse signal doit être connectée si l'un quelconque des signaux d'entrée dépasse 40 V crête.

Ne pas déposer les panneaux de protection.

Le fait que le fusible d'alimentation saute par suite d'une anomalie risque de détériorer l'alimentation secteur de l'instrument; dans ce cas, le faire contrôler par un technicien qualifié.

Pour couper l'alimentation secteur de cet instrument, débrancher le cordon secteur monté à l'arrière. L'interrupteur d'alimentation est purement secteur fonctionnel. Il ne s'agit pas d'un dispositif de coupure du courant, et n'est pas conçu pour cette fonction.

Deutsch**WARNHINWEIS!**

Dieses Gerät muß mit einer Schutz Erde betrieben werden, die über den Schutzleiter des Speisekabels oder über die Erdungsklemme des Gerätes (falls vorhanden) anzuschließen ist. Bei einer Unterbrechung der Schutz Erde außerhalb oder innerhalb des Gerätes kann eine Gefahr am Gerät entstehen! Eine beabsichtigte Unterbrechung ist nicht zulässig. Achtung! Bei Signalspannungen über 40 V muß die Signalmasse angeschlossen sein.

Die Schutzabdeckung nicht entfernen.

Wenn die Sicherung der Versorgung infolge eines Defektes durchbrennt, besteht die Möglichkeit einer Beschädigung des Wechselstromversorgungs-Schalters des Gerätes. Der Schalter muß dann von einem qualifizierten Elektriker geprüft werden.

Zum Trennen des Gerätes von der Wechselstromversorgung den IEC-Stecker von der Rückwand abziehen. Der Wechselstromversorgungs-Schalter dient bei diesem Gerät nur für Funktionszwecke. Er ist nicht als Trennvorrichtung bestimmt bzw. geeignet!

Italiano**AVVISO DI SICUREZZA**

Questo strumento deve esser utilizzato con un collegamento protettivo di messa a terra tramite il filo di messa a terra del cavo di alimentazione o tramite il terminale di messa a terra in sicurezza, nel caso in cui lo strumento ne sia dotato. Qualsiasi interruzione della massa a terra protettiva, sia all'interno che all'esterno dello strumento, lo renderà pericoloso. E' vietata qualsiasi interruzione causata intenzionalmente. Inoltre, la connessione di terra deve essere collegata se ad uno qualsiasi degli ingressi viene applicato un segnale superiore a 40 V di picco.

Non aprire lo strumento.

Nel caso in cui il fusibile dell'alimentazione dovesse scattare a causa di un guasto, è possibile che l'interruttore dell'alimentazione a corrente alternata dello strumento possa essere danneggiato e dovrà pertanto essere controllato da un tecnico specializzato e qualificato.

Per disinnestare questo strumento dall'alimentazione a corrente alternata, levare il connettore IEC che si trova sul pannello posteriore. L'interruttore dell'alimentazione a corrente alternata di questo strumento viene fornito esclusivamente per scopi operativi e non viene inteso, né è adatto, per essere utilizzato come dispositivo di disinnesto.

Αγγλικά**ΠΡΟΕΙΔΟΠΟΙΗΣΗ ΑΣΦΑΛΕΙΑΣ**

Το όργανο αυτό πρέπει να λειτουργεί με το προστατευτικό γείωσης (γείωση) να έχει συνδεθεί μέσω του προστατευτικού αγωγού γείωσης του καλωδίου που χορηγείται ή με τον ακροδέκτη ασφαλείας που είναι για τη γείωση, εάν υπάρχει τοποθετημένος στο όργανο τέτοιος ακροδέκτης. Διακοπή της προστατευτικής γείωσης, εσωτερικά ή εξωτερικά του οργάνου ενδεχομένως να κάνει το όργανο επικίνδυνο. Διακοπή εκ προθέσεως απαγορεύεται.

Μην αφαιρείτε τα καπάκια.

Εάν καεί η ασφάλεια του οργάνου σαν αποτέλεσμα βλάβης, είναι πιθανό να έχει παθει ζημιά και ο διακόπτης εναλλασσόμενου ρεύματος του οργάνου και πρέπει να στηριχθεί από ειδικευμένο μηχανικό.

Για ν' απσυνδέσετε το όργανο από την ηλεκτρική παροχή, τραβήξτε να βγει ο συνδετήρας IEC από το πίσω ταμπλά. Η ηλεκτρικός διακόπτης που υπάρχει σ' αυτό το όργανο είναι μόνο για λειτουργικές ανάγκες. Δεν προτίθεται, ή δεν είναι κατάλληλος, σαν μέσο αποσύνδεσης.

Norsk**ADVARSEL!**

Dette instrumentet må bare anvendes så lenge det er jordnet via den beskyttende jordlederen i strømkabelen, eller via jordingsklemmen, hvis instrumentet har en. Eventuelle forstyrrelser i den beskyttende jordingen, inne i eller utenfor instrumentet, vil sannsynligvis gjøre instrumentet farlig. Forsettlig forstyrrelse er forbudt. I tillegg, signal jord må tilkobles dersom inngangs signalet overstiger 40 V spissverdi.

Ikke fjern dekslene

Hvis sikringen springer på grunn av feil som oppstår, er det mulig at instrumentets vekselstrømbryter kan bli skadet – den må derfor kontrolleres av en kvalifisert ingeniør.

Skal instrumentet koples fra vekselstrømtilførselen, kopler man ut IEC-koplingen bak på panelet. Vekselstrømbryteren på dette instrumente tjener kun en funksjonell hensikt. Den er ikke egnet, og må ikke brukes, som skillebryter.

Português**Aviso de segurança**

Este aparelho deve ser operado com uma ligação terra ligado por um conductor trifásico do cabo principal ou, se o instrumento já tiver um, via um terminal de segurança. Qualquer interrupção do trifásico, dentro ou fora do aparelho, pode tornar o aparelho perigoso. É proibida a interrupção intencional. Nota: O terminal de terra deve ser ligado se o sinal de entrada a medir for superior a 40 V de pico.

Não retire o invólucro/capas.

Se o fusível suplementar queimar por causa de erro, é possível que o interruptor da fonte AC do aparelho esteja com defeito e deveria ser checado por pessoa autorizada.

Para desconectar este aparelho da fonte AC, retire o conector IEC do painel trazeiro. Neste aparelho, o interruptor da fonte AC existe sómente por razões funcionais. Não deve ser usado e nem é apropriado como dispositivo de desconexão.

Español**ADVERTENCIA SOBRE SEGURIDAD**

Este instrumento debe utilizarse conectado a tierra a través del conductor de puesta a tierra del cable de alimentación o de la borna de seguridad, si dicho instrumento estuviera equipado con ella. Cualquier interrupción de esta puesta a tierra, dentro o fuera del instrumento, hará que el manejo del mismo resulte peligroso. Queda terminantemente prohibido dejar en circuito abierto dicha puesta a tierra. Además, debe conectarse una señal de tierra si cualquier señal de entrada sobrepasa los 40 V de pico.

No quite las tapas.

Si se fundiera el fusible de alimentación como consecuencia de una avería, cabe la posibilidad de que el interruptor de encendido del equipo esté dañado y sea necesario comprobarlo por personal técnico especializado y autorizado al efecto.

Para desconectar este instrumento de la red, desenchufe el conector IEC del panel trasero. El interruptor de entrada de CA (encendido) se incluye solo para fines funcionales. No está pensado para utilizarse como medio de desconexión, ni tampoco es adecuado para ello.

Svenska**SÄKERHETSVARNING**

Detta instrument måste drivas med en skyddande jordledning ansluten via den skyddande jordledaren på matarkabeln eller, om instrumentet har sådan monterad, via det jordade uttaget. Om jordanslutningen störs, inuti eller utanför instrumentet, är det troligt att instrumentet kommer att utgöra en fara. Avsiktlig störning är förbjuden. Dessutom måste en signaljord anslutas om någon av ingångssignalerna överstiger 40 V topp.

Tag ej bort skydden.

Om matarsäkringens smälter på grund av ett fel är det möjligt att strömställaren för växelströmsmatning på instrumentet skadas och den bör då inspekteras av en ingenjör med lämpliga kvalifikationer.

För att koppla bort instrumentet från växelströmstillförseln, tag ut IEC-anslutningen på bakpanelen. Strömställaren för växelströmstillförsel på detta instrument är enbart till för funktionerliga ändamål. Den är inte avsedd som, eller lämplig som, en bortkopplingsanordning.

GÜVENLİK UYARISI

Bu cihaz, koruma topraklaması besleme kablosunun topraklama iletkeni yoluyla ya da eğer varsa cihazın koruma topraklama terminali yoluyla bağlanmış olarak çalıştırılmalıdır. Koruma topraklamasının cihaz içinde veya dışında kesintiye uğraması cihazın tehlikeli hale gelmesine yol açar. Bağlantıyı bilerek kesintiye uğratmak yasaktır. Buna ilaveten, herhangi bir giriş sinyali 40 V tepe değeri geçerse giriş sinyali toprağı bağlanmalıdır.

Kapakları çıkarmayınız.

Eğer bir hata sonucu kaynaktaki sigorta atarsa cihazın AC (alternatif akım) güç şalteri zarar görebilir ve uygun niteliklere sahip kalifiye teknik eleman tarafından kontrol edilmelidir.

Bu cihazı AC kaynağından ayırmak için arka paneldeki IEC konektörünü yuvasından çıkarınız. Bu cihaz üzerindeki AC güç şalteri sadece işlevsel nedenlerle sağlanmıştır. Cihazı elektrik kaynağından ayırma amacını taşımaz ve bu amaçla kullanılmaya uygun değildir.

English**SAFETY WARNING**

This instrument must be operated with a protective ground (earth) connected via the protective ground conductor of the supply cable or, if the instrument is fitted with one, via the safety ground terminal. Any interruption of the protective ground, inside or outside the instrument, is likely to make the instrument dangerous. Intentional interruption is prohibited. In addition, a signal ground must be connected if any input signal exceeds 40 V peak.

Do not remove the covers.

If the supply fuse blows as the result of a fault, it is possible that the instrument's AC supply switch will be damaged and should be checked by a suitably qualified engineer.

To disconnect this instrument from the AC supply, unplug the IEC connector on the rear panel. The AC supply switch on this instrument is provided for functional purposes only. It is not intended as, or suitable as, a disconnecting device.

1.1.3 Safety Statement

The design of this instrument has been checked to EN 61010 for class 1 (grounded) use.

This manual contains information and warnings that must be observed to keep the instrument in a safe condition. The instrument should not be switched on if it is damaged and it should not be used under wet conditions.

For the correct and safe use of this instrument it is essential that both operating and service personnel follow generally accepted safety procedures in addition to the safety precautions specified in this manual.

Whenever it is likely that safety protection has been impaired, the instrument must be made inoperative and be secured against any unintended operation. Qualified maintenance or repair personnel should be informed. Safety protection is likely to be impaired if, for example, the instrument shows visible damage or fails to operate normally.

1.1.4 Grounding**AC**

The instrument must be operated with a protective ground connected via the yellow/green conductor of the supply cable.

This is connected to the instrument before the line and neutral connections when the supply plug is inserted into the socket on the back of the instrument. If the final connection to the supply is made elsewhere, ensure that the ground connection is made before line and neutral.

DC

If the unit is disconnected from the AC supply and powered from an isolated DC source, the unit will not be grounded. Independant provision **MUST** be made to maintain the case

at a safe potential by grounding the safety ground terminal on the DSO's rear panel. The safety ground terminal is electrically connected to the instrument's case, to the ground of the input signals (outer of the BNC connectors), and also internally to the negative side of the DC supply.

General

WARNING: Any interruption of the protective ground conductor inside or outside the instrument is likely to make the instrument dangerous. Intentional interruption is prohibited.

Signal connections to the instrument should be connected after the ground connection is made and disconnected before the ground connection is removed, i.e. the supply lead must be connected whenever signal leads are connected.

WARNING: It is recommended that signal grounds are always connected to a local ground. For safety, it is essential that a signal earth is connected whenever voltages greater than 40 V peak are connected. This is to prevent the instrument's case becoming live in the event of a safety ground interruption which could occur if the supply connector is accidentally disconnected from the rear of the instrument.

It is the responsibility of the user to ensure the safety of any accessories, such as probes, used with the instrument.

CAUTION: Even low voltage inputs may contain high voltage fast transients (spikes) which could damage the input. For this reason it is not safe, for instance, to make direct connections to an AC line supply.

Note: In order to verify the continued safety of this equipment, it is necessary to routinely check the earth bonding and insulation resistance. This should be done by a suitably qualified person.

1.1.5 Live Parts

The covers protect the user from live parts and they should be removed only by suitably qualified personnel for maintenance and repair purposes.

The instrument must not be operated with covers removed.

1.1.6 Environment

The instrument should preferably be operated in a clean, dry environment with an ambient temperature of between 0 °C and +50 °C.

The instrument is specified for use in a Pollution Category II environment, which is normally non-conductive with temporary light condensation, but it must not be operated while condensation is present. It should not be used in more hostile, dusty or wet conditions.

The instrument will operate with full accuracy between +15 °C and +35 °C.

Note: *Direct sunlight, radiators and other heat sources should be taken into account when assessing the ambient temperature.*

The instrument relies on forced air cooling via a fan and ventilation slots. Adequate ventilation can usually be achieved by leaving a 75 mm (3" gap) around the instrument. Care should be taken to avoid restricting the airflow to the fan at the rear of the instrument.

To clean the DSO, disconnect all signals and power sources and then wipe the surfaces lightly with a clean, soft cloth dampened with water. If the CRT filter requires cleaning it can be easily removed by unclipping it from the front of the instrument.

WARNING: Because some configurations of the instrument may be unstable according to EN 61010-1, it is not safe to operate or store the instrument standing on its rear feet without ensuring that it cannot topple over.

1.1.7 Power and Frequency Requirements

The instrument uses less than 85 V·A and operates from line voltages of 90–132 V and 180–264 V, at 45–440 Hz to Installation Category II, local level supplies distributed within a building. Under the extreme conditions of 90 V and 45 Hz, the instrument will still operate correctly even if there is a half cycle dropout in the line supply.

The instrument can also be powered from a direct current supply in the range 12 V to 33 V. Both AC and DC power can be applied simultaneously, thus providing uninterrupted operation in the event of one of the supplies failing.

The AC power connection is via a standard IEC, CEE 22 connector and the DC power connection is via the supplied 0.25" spade connector assembly. See appendix 5 for polarity details.

To disconnect this instrument from the supply both the AC and DC connector should be unplugged. To remove the AC supply, unplug the IEC connector on the rear panel. To remove the DC supply, unplug the spade connector assembly from the rear panel. The supply switch on this instrument is provided for functional purposes only. It is not intended as, or suitable as, a disconnecting device.

Access to the AC supply fuse can only be made if the AC supply connector is removed, and is by hinging open the panel connector from its top edge. The AC supply fuse must be as shown in table 1.1.9.

1.1.8 EMC

This instrument generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the operator manual, may cause harmful interference to other equipment. However, there is no guarantee that interference will not occur in a particular installation.

In demanding applications if this instrument does cause minor harmful interference to other equipment, which can be determined by turning this instrument off and on, the user is encouraged to try to reduce the interference by one or more of the following measures:

- Re-orient or relocate the affected equipment.
- Increase the separation between the instrument and the affected equipment.
- Re-orient or relocate RS423 and/or IEEE-488 interface cables.
- Connect the instrument to an outlet on a different supply circuit to the affected equipment.

Supply cables, interface cables and probes should be kept as short as practical, preferably a maximum of 1 meter. Interface cables should be screened and interface cables longer than 3 m are not acceptable in terms of interface port immunity.

This instrument must not be used in life support roles.

1.1.9 Fuse Requirements

The fuse arrangement shown in table 1.1.9 must be followed, and additionally in the UK, a 3 A fuse should be fitted in the line supply plug. The fuse should be a slow blow, high breaking capacity (TH) type. For 100/120 V use, CSA approved fuses should be fitted.

If the supply fuse blows as the result of a fault, it is possible that the instrument's AC supply switch will be damaged and should be checked by a suitably qualified engineer.

Supply Voltage	Slow-Blow (T) Fuse Rating IEC (UL/CSA)	Gould Part No	Suggested types Manufacturer/ Type No.
230 V	0.5 A (0.6 A)	457452	Bussman GMD, Littlefuse/239.600, Schurter/FSD0034.3983, Wickman/19198
115 V	1 A (1.25 A)	457454	Bussman/GMD, Littlefuse/2391.25, Schurter/FSD0034.3989 Wickman 19198
12 V DC	6.3 A (7.5 A)	460232	HBC type Bussman/SS505, Schurter/SPT 0001.2512, Wickman /19181, Littlefuse/21506.3.

Table 1.1.9 Fuse ratings

Note: For different DC voltages, the DC fuse rating multiplied by the voltage used should equal 75 W, e.g. at 30 V a 2.5 A fuse is required. For additional safety under extreme fault conditions, the DC fuse is a high breaking current (HBC) type. This fuse should have a 1500 A breaking capacity.




Figure 1.2a Single Function Buttons




Figure 1.2b The Toggles




Figure 1.2c The Paddles

1.2. Using the Buttons

The front panel buttons are classified as single action, toggles or paddles.

Single action buttons have only one function: when pressed, that one function will be activated e.g. AUTO SETUP (17). See figure 1.2a.

Toggle buttons either switch something on or off e.g. Add (22), or select the next item in a sequence e.g. Off/On/Inv (21). See figure 1.2b.

Five position paddles cause a parameter change which depends upon how far the paddle is pressed. For example, a gentle press of a Position (46) paddle will move the trace slowly. If the paddle is moved further, the trace will move more quickly. See figure 1.2c.

1.3. Start-Up Display

When switched on with the POWER button (63), the instrument will display information similar to that shown in Figure 1.3.




Figure 1.3 Start-Up Display

The trace is visible across the center of the screen. At the top will be the sensitivity of the two input channels and the timebase speed. If any input is inactive, information for that channel will not be displayed.

Users with no previous experience of a DSO will find that the instrument responds like a conventional Real Time Oscilloscope while it is repetitively triggered, but in the absence of further valid triggers, and with Auto Trigger switched off, it retains the last trace for continuous display.

1.4. Obtaining a Trace

Whenever the DSO is switched on, the previous control settings saved from the last power down will be used. These may not suit the current input signals. The instrument can be set to suit new signals either manually or, automatically using the Auto Setup feature.




Figure 1.4 Obtaining a Trace

1.4.1. AUTO SETUP

To display an input signal, connect it via either the CH1 socket (60) or the CH2 socket (59) and press AUTO SETUP (17).




Figure 1.4.1 An AUTO SETUP Display

Assuming a repetitive signal has been applied, e.g. a 2 kHz sine-wave with an amplitude of perhaps 5 V peak to peak, it will almost immediately be represented on the display. An example is shown in Figure 1.4.1.

If there is no display see section 1.11.2.

AUTO SETUP will attempt to arrange the display so that two to five complete cycles appear, with the amplitude set so that the height of the trace is between two and five screen divisions. Also, it selects auto trigger to ensure that the screen is frequently updated and a trace will be visible.

If signals are connected to both channels, the timebase is set to suit the higher amplitude signal.

1.4.2 Manually Obtaining a Trace

This subsection describes how to obtain a trace without using **AUTO SETUP**.

You may need to consult later sections of the manual as not all of the operating features have been discussed so far.

1. Switch on the instrument.
2. Ensure that the internal display is selected.
3. Decide to which channel you are going to apply the signal (CH1 or CH2).
4. Make sure the chosen channel is active by setting the **Off/On/Inv** (21) or (25) for that channel to On.
5. Set the **AC/DC/Gnd** button (20) or (24) for the chosen channel to Gnd.
6. If necessary, turn that channel's **Uncal** light out by pressing **Var** once (19) or (23).
7. Make sure that horizontal mag is not selected. (18)
8. Adjust the **TIME/DIV** setting (32) & (33) to give a timebase of 5ms.
9. Set the display mode to **Refr** (11).
10. Set the **TRIGGER Norm/Auto** button (26) to Auto.
11. Use the **CH1/CH2/Ext/Line** button (29) to choose the source for trigger signals.
12. Set the trigger coupling with the **hf rej/AC/DC** button. (28).
13. If necessary adjust the position of the trace using the **Horizontal Position** and **Vertical Position** paddles (34, 35) & (36, 37) or (38, 39).
14. Ensure that **Trace Hold** (14), (15) or (16) is not selected.
15. Select **Run** (13).
16. Apply the signal through a BNC connector to the chosen CH input socket. (59) or (60).
17. Set the **AC/DC/Gnd** button (20) or (24) for the channel to either DC or AC, as appropriate.
18. Adjust the gain of the chosen channel using the **V/DIV** paddles (36, 37) or (38, 39). For intermediate settings, set **Uncal** on by pressing the **Var** button once. (19) or (23).
19. Adjust the timebase setting using the **TIME/DIV** paddles. (32) & (33)
20. If the display is unstable, adjust the trigger **Level**. (52) & (53).

1.5 Display

The instrument is fitted with an internal color display and it has a monitor output connector for external displays. Only one display can be used at any one time.




Figure 1.5 Rear Panel Display Switches

1.5.1. Internal Color Display

The colors of the various items on the display are defined in color palettes. 8 color palettes are available. They are selected by pressing the rear panel push button labelled COLOR PALETTES. Each press of the button moves the palette onto the next selection. The eighth press will return the display to the original selection.

Palette 3 produces the same colors on the display as those produced on plots by the internal color plotter. For the match to be correct, the color pens should be loaded into the correct locations. See section 2.4.

When the internal color display is in use, the external monitor output is disabled.

1.5.2. External Monitor Output

The DSO provides an output suitable for driving multi sync monitors. The output consists of separate analog Red, Green, Blue and sync signals.

This output is activated by pressing the rear panel INT/EXT MONITOR switch. When this output is active, the internal display is de-activated. An indicator below the internal display shows that the rear panel output is in use. To return to the internal display, press the rear panel monitor switch.

The colors of the different items on the display are defined by the color palettes. See section 1.5.1

	Palette Number							
	1	2	3	4	5	6	7	8
Background	Black	Black	White	Black	Black	Black	Black	Black
Trace 1	Red	Red	Black	White	Pastel Red	Cyan	Cyan	Yellow
Trace 2	Green	Green	Blue	White	Pastel Yellow	Green	Magenta	Red
Ref Trace	Cyan	Yellow	Green	White	Pastel Green	Yellow	Green	Light Blue
Trace coll	White	White	Black	White	White	White	White	White
Graticule	Gold	Blue	Red	White	Pastel Blue	Orange	Cream	Cyan
Grat coll	Gold	Light Blue	Red	White	Pastel Blue	Orange	Cream	Cyan
Text	Cream	White	Black	White	White	White	Grey	White
Cursors	Cream	White	Black	White	White	White	White	White
Persist	Silver	Cyan	Green	White	Pastel Grey	Grey	Grey	Green
XY	Red	Red	Black	White	Pastel Red	Cyan	Cyan	Yellow

Table 1.5.1 Color Palettes

1.6 Channel Controls




Figure 1.6 Channel Controls

1.6.1. Channel Selection (Off/On/Inv)

A channel may be switched on or off with its **Off/On/Inv** button (21) or (25). If the channel is on, its trace can be displayed in either normal or inverted mode.

Off The channel display is de-activated but the signal can still be used as a trigger source.

On The trace is a true representation of the input signal.

Inv The input signal is inverted before being displayed. If there is any DC component in the signal this will also be inverted and could cause the trace to disappear from the screen. Such an unwanted DC component can be removed by selecting AC coupling. Any vertical shift applied to the trace is not inverted. The trigger point remains at the same point on the waveform regardless of inversion.

1.6.2. Coupling (AC/DC/Gnd)

These buttons (20) & (24) control the type of coupling between the input signal and the instrument. DC is the most generally applicable, and AUTO SET UP will normally set this control to DC, where possible.

The input impedance is 1 M Ω in parallel with a capacitance of 15 pF, see Appendix 2.

AC This is used to remove any DC component from input signals. Suitable input signal range (i.e. the bandwidth) is from 4 Hz 200 MHz.

Gnd The input signal is internally disconnected from the inputs and the amplifier grounded. A 0 V reference signal is displayed.

DC The input signal is directly coupled to the instrument so all frequency components of the input signal will be displayed. The bandwidth will be from DC to 200 MHz.

1.7 Horizontal Adjustments




Figure 1.7 Horizontal Controls

1.7.1. TIME/DIVISION

Time/Div (32) & (33) This paddle controls the sweep rate of the trace. The timebase can be varied from 50 s/div to 25 ns/div in a 1, 2, 5 sequence of values. Moving towards "ns" decreases the time/div, moving towards "sec" increases the time/div.

With a timebase of say 0.2 s, each horizontal screen division represents 0.2 s worth of signal. The timebase is shown near the top of the display - e.g. TB = 0.2 s.

At timebase speeds of 200 ns and faster, the DSO uses Equivalent Time sampling (ETS) to build up a picture from a number of separate acquisitions by sampling the repetitive waveform at varying times relative to the trigger point, to eventually capture the entire input waveform. ETS ranges can only be used to capture repetitive signals.

1.7.2. Aliases

Assuming a 2 kHz signal is applied as mentioned earlier, when the timebase is set to 0.5 s/div, an interesting phenomenon may appear: an "alias".

An alias is a false image. The instrument is a digital oscilloscope and so takes frequent samples of the input signal in order to update the trace. Thus, if the signal frequency is higher than the sample frequency, one sample will be taken from a particular point on the waveform and the next sample may be taken from a point slightly further along on a subsequent cycle. It will then display the wave as being much slower than it is in reality. See Figure 1.7.2.




Figure 1.7.2 Alias Generation

There is a "Max/Min" glitch detection feature which can be used to detect aliases. With dot join on, this usually results in a filled-in wave envelope being seen on the screen, indicating a high frequency. See Section 3.4.

1.7.3. Position

Position (34) & (35) This paddle moves all traces to the right or left.

The position of the cursor (Section 2.4.) is fixed in relation to the trace so it will move with the applied shift. With X-magnified traces (Section 1.7.4.), the cursor can be off the part of the trace displayed on the screen. To bring it back into view use the CURSOR <> paddle (44) & (45).

1.7.4. Magnification

Mag (18) Switches horizontal magnification on or off. When switched on, a $\times 10$ expansion is applied to any displayed trace, which will expand around the center of the screen. The timebase displayed is adjusted to reflect the expansion.

The instrument displays 50 dots (samples) per horizontal screen division, each plotted dot value being obtained from the 512 byte acquisition memory. At an expansion of $\times 10$, there are five acquired dots per division, the remaining dots being produced by linear interpolation.

1.8. Vertical Adjustments

Each channel has its own set of vertical controls. See Figure 1.8.




Figure 1.8 Vertical Controls

1.8.1. VOLTS/DIVISION

V/DIV (36) to (39) These paddles adjust the sensitivity of the instrument over discrete calibrated ranges from 2 mV to 5 V per screen division in 1, 2, 5 steps. With a $\times 10$ probe the ranges are 20 mV to 50 V per division at the probe tip. See Section 3.4. If the **Uncal** light is on, then these paddles vary the sensitivity continuously. See Section 1.8.3.

1.8.2. Position

Position (46) to (49) These paddles move their respective traces up and down the display.

If **Trace Hold** is on (Section 2.1.) or a **S/Shot** capture has been made, these controls do not move the trace and the post storage **Pos** control should be used instead. See section 2.3.4.

1.8.3. Variable/Uncalibrated

Var (19) & (23) When this is set to "Uncal", the coarse setting of the attenuator remains unchanged, but a variable attenuation is applied to the input signal in the range of 1 to 0.4. Thus, with an initial setting of 1 V, the actual sensitivity of the channel could be set by this control to anywhere between 1 V and 2.5 V per division. The **V/DIV** paddles are used to vary the uncalibrated sensitivity.

Screen display explanation:

CH1=5V	Channel 1 is set to a sensitivity of 5 Volts per screen division.
CH2>20mV	Channel 2 is uncalibrated and the attenuator is set to a sensitivity greater than 20mV per screen division.
CH1=~5V	Channel 1 is set to a sensitivity of 5 volts per screen division and is AC coupled.
CH1=-5V	Channel 1 is set to a sensitivity of 5 volts per screen division and is inverted.
↑	shows that the trace is off the top or bottom of the screen depending upon the direction of the arrow.

1.8.4. Add

Add (22) Displays the sum, or if one channel is inverted the difference, of the input signals. The original traces disappear and the resultant trace is displayed as trace 2.

1.9 Trigger Control

Trigger facilities discussed here are controllable directly from the front panel. For the more advanced menu-controlled facilities see Section 3.4.

1.9.1 Selecting Source and Coupling

CH1/CH2/Ext/Line (29) Steps through the possible sources of trigger signals. When **Ext** is selected, the source is the "EXT TRIG" socket (58) in the lower right corner of the front panel.

Selecting line is meaningful only if the instrument is powered from the mains. Triggering is then from an internal pulse having a fixed phase relation to the mains voltage waveform. To change this phase relationship, use the trigger delay buttons. See Section 2.1.6.




Figure 1.9 Trigger Controls

hf rej/AC/DC (28) Steps through the available trigger coupling options; hf rej is a 15 kHz low-pass filter ("high frequency reject"). All the couplings can be used with any source except Line.

Coupling Input Frequencies

hf rej	15 kHz bandwidth
AC	4 Hz to 200 MHz
DC	DC to 200 MHz

Table 1.9.1. Useful Frequency Ranges of Coupling Types

1.9.2 Trigger Level

The trigger level is the threshold at which the instrument will respond to potential triggers; the trace actually has to pass through the level indicated in the appropriate direction as defined by Slope (section 1.9.4) for a trigger to be valid.

The level is indicated on the display by two bars, one on each side of the screen, and is adjusted by the level paddle (52) & (53). For an internal trigger the range is ± 10 divisions and on external approximately ± 3 V. If the trigger signal is AC coupled, the level bars will be offset from the actual trigger position on the screen by any DC offset present.

1.9.3 Trigger Point (T)

The trigger point is indicated on the display by a "T" near the bottom of the screen underneath the trigger. An arrow next to the T indicates that the trigger point is off the screen. An arrow and a vertical line indicates that the trigger is at 0 or 100% pretrigger (the left or right hand edge of the display).

1.9.4 Trigger Slope (+/-)

A trigger is generated when the selected source signal passes through the chosen trigger level in the selected direction. This transition may be either on a rising or a falling edge. The rising edge is considered to be a positive slope and the falling edge a negative slope.

+/- (27) This button selects positive (+) or negative (-) slope triggers.

1.9.5 Trigger Mode (Norm/Auto)

The trigger system operates in either Normal or Auto mode.

In Normal mode, acquisition triggers only occur when valid triggers are present.

In Auto mode, if no valid trigger has been received for 50 ms the instrument will generate its own trigger and initiate a capture. This ensures that the screen is constantly updated irrespective of the input signal. However, if valid input triggers are received at a rate of 20 Hz or more, the instrument will behave as if it is in normal mode.

Norm/Auto (26) This button selects the trigger mode in which the instrument is operating.

Triggered (57) This lights up when the instrument is receiving valid trigger signals.

1.10 Trigger Delay

The amount of data which is acquired for display before or after the trigger is determined by the pretrigger or trigger delay selected, see figure 1.0b. The value of this delay is shown in the bottom right hand of the trace display.




Figure 1.10a Trigger Delay Controls




Figure 1.10b Trace Capture with Delay

1.10.1 Pretrig

This allows a section of the trace that occurred before the trigger point to be included in the display. The amount of pre-trigger visible can be set with the front panel **Pre Trig/Delay** paddle. (50) & (51). Pre-trigger can be set anywhere between 0% and 98% of screen width, in steps as small as 0.4%.

1.10.2 Delay by time

With this set, the oscilloscope will acquire a trace following both the specified trigger and a specified delay. The amount of delay is shown at the bottom right of the display. Delay is controlled by the **Pre Trig/Delay** paddle. (50) & (51). The size of the steps by which the delay can be incremented or decremented is controlled by the **TIME/DIV** paddle, i.e. step size is $0.04 \times$ the time/div setting. To obtain long delays on a fast timebase, it can be easier to select a slower timebase, set the delay and then reselect the original fast timebase. Once set, the delay time remains the same regardless of the selected timebase range.

1.11 Operating Hints

This section explains how to perform a system reset and gives some of the problems more commonly met in operating digital oscilloscopes, how to correct them, and a brief explanation of what was wrong. Later sections of the manual may need to be consulted as some of the operating features have not yet been discussed.

1.11.1 System Reset

Should the system memory become corrupted, the instrument could lock out the front panel operation or begin to behave erratically. Since the internal system variables are held in battery-backed memory, turning the set off and on again may not clear them. In this unlikely event a system reset may be necessary.

A system reset should only be used as a last resort as all the internal memories will be cleared erasing all reference traces, calibration details, and set-up details.

To perform a system reset, switch the instrument off. Press and hold the **Hold All** button. Keep the **Hold All** button pressed and turn the instrument on using the **Power** button. When flashing lines appear on the screen, the **Hold All** button should be released. The instrument will then perform a full calibration and select its default setup.

A system reset must be followed by a full calibration once normal operating temperature is reached.

1.11.2 Problem: No picture on internal display.

External monitor selected, Front panel indicator illuminated

- Press the rear panel Monitor button to select the internal monitor.

1.11.3 Problem: Trace off the top or bottom of the screen.

Too much vertical shift

- Correct with that channel's **Position** paddle. (46) to (49)

Input has large DC offset

- AC couple input signal.
- Correct with **Position** paddles. (46) to (49)
- Use a less sensitive range.

1.11.4 Problem: Trace not being acquired.

Instrument in single capture mode

- Press **Run** (13)

Trigger level incorrect

- Select Auto and DC trigger, then adjust the level control until the trigger level indicator bars are lined up with the center of the trace.

Trigger source on the wrong input

- Change trigger source. (CH1, CH2, Ext, Line). (29)

Trigger coupling on an unsuitable setting

- Change trigger coupling. (hf rej, AC, DC). (28)

Trace Hold on

- Release **Trace Hold**. (14), (15) or (16)

Timebase on very slow acquisition

- Adjust **TIME/DIV**. (33)

1.11.5 Problem: Trace is unstable even when triggered.

Alias

- Check for alias using Max/Min (glitch detection), and select a faster timebase range.

Noisy input

- Select **hf rej** trigger coupling if the input signal is less than 15 kHz. (28)
- Adjust trigger **Level**. (52) & (53)

Trigger on Auto

- With low frequency inputs (below 20 Hz), **Auto** trigger will initiate triggers overriding the input triggers. Select **Norm** trigger. (26)

1.11.6 Problem: Trace has a very flat top or bottom.

Trace captured when off screen vertically and post storage Pos shift has been used

- Use less sensitive **V/DIV** range when acquiring trace. (36) to (39)
- Re-position trace prior to capture.

1.11.7 Problem: Auto Setup fails.

If Auto Setup fails it is most likely that the signal connected to the instrument is unsuitable for the automatic setup system for one or more of the following reasons.

Signal not repetitive.

- Auto Setup only works on repetitive signals

Signal amplitude too small or too large.

- Instrument needs to use a different **V/Div** range. Use a probe with a suitable gain, i.e. $\times 1$, $\times 10$, or $\times 100$.

Signal frequency too slow or too fast.

- The signal frequency is outside the range of Auto Setup.

Signal not constant.

- Amplitude and or frequency variations during the Auto Setup routine may interfere with its correct operation.

High frequency noise on signal.

- The noise may be interpreted as a high frequency signal instead of being ignored as noise on a lower frequency signal.

1.11.8 Problem: Cursor measurements apparently wrong.

Wrong probe gain selected.

- Select correct probe gain to suit probe in use. See section 3.4.

Datum not set correctly.

- Re-position datum on trace (40) to (43).

Cursors on wrong channel trace.

- Position cursors on trace of interest (31).

1.11.9 Problem: Single Shot acquisition takes longer than expected.

Averaging or persistence modes selected.

- Turn off both averaging and persistence.

An ETS timebase is in use with infrequent triggers.

- Use the **TIME/DIV** paddle to change to a non ETS timebase.

An ETS timebase is in use with non repetitive or non triggered signal.

- Change to a non ETS timebase.
- Adjust the trigger controls to obtain a trigger signal.

2. DSO Features**2.1 Capture Facilities**

The capture facilities allow the traces to be frozen.




Figure 2.1 The Capture Controls

2.1.1 Trace Hold

There are two ways to freeze the display: a single-shot capture whereby a full trace is acquired then frozen (Section 2.2.2), or by pressing one of the trace hold buttons (14), (15) or (16).

Trace Hold: (14), (15) & (16) Freezes the relevant trace or traces the moment they are pressed. A second press releases the trace(s).

2.1.2 Single Shot and Run

These buttons are used to set the instrument into either a capture-and-freeze mode (**S/Shot**), or a free running continuous capture and re-capture mode (**Run**).

S/Shot (12) Arms the instrument for a single-shot triggered acquisition. The Armed light will be illuminated to show that the button has been pressed.

Armed (54) Illuminates after the **S/Shot** button has been pressed; it will stay lit until either a valid trigger has been accepted or until the **Run** button is pressed.

Stored (55) Illuminates on completion of a single-shot acquisition. This is after the instrument has been Armed, triggered and a complete trace acquired. The light will stay on until the instrument is re-armed by pressing **S/Shot** again or **Run** is pressed.

Run (13) This button puts the instrument in continuous capture mode: the instrument will automatically re-arm itself after each capture is completed so that the display will update with each triggered sweep.

2.1.3 Acquisition Status - AFTS

These characters appear on the screen and can be used with the **Armed** and **Stored** lights to determine the status of the acquisition in progress.

- A** Stands for "Armed".
- F** Indicates that the acquisition store has been "flushed" and filled with enough pre-trigger information to be ready for a fresh trigger in pre-trigger acquisition. Until this condition is met and F displayed, triggers may be detected, as indicated by the trigger LED, but not accepted for the next acquisition.
- T** Stands for "Triggered": the instrument has accepted or generated a valid trigger; acquisition has begun.
- S** "Stored": acquisition is complete.

2.2 Display Modes

The following three display modes are directly selectable using the **Mode** button. (11).

2.2.1 Refreshed

The instrument will imitate the style of a conventional realtime 'scope: the trace is displayed from left to right as it is acquired.

2.2.2 Roll

This mode is like a chart recorder: the display scrolls from right to left until a trace has been acquired. The scrolling effect is most noticeable on the slower timebase ranges. The rolling display is frozen by the trigger in S/Shot mode and is unaffected by trigger in Run.

2.2.3 X-Y

This mode allows the CH1 socket input to control the X (horizontal) component of the trace, and the CH2 socket input to control the Y (vertical) component. It provides an X-Y display of the data captured by the timebase and trigger systems. The timebase should be set slow enough to capture the whole of the signal of interest. This mode is not available with magnified traces (**Mag**).

2.2.4 Persistence

A refreshed mode in which successive acquisitions are added to the current display. The number of acquisitions or the time before clearing the display is set in the Persistence Limits Testing menu accessed from the Post Storage Master Menu. The latest acquisition is shown brighter than the persisted acquisitions.

2.3 Cursor Measurements

The instrument allows you to take direct measurements from the screen display automatically, using datum lines and a cursor.




Figure 2.3 The Cursor and Datum Line Controls

2.3.1 Cursor and Datum Selection

The cursor and datum lines are switched on or off using the **Select Trace** button. (31).

Select Trace (31) Successively pressing this button places the cursor onto the displayed traces in turn, i.e. trace 1, trace 2, reference, off, trace 1 etc. If a trace is not in use, the cursor skips to the next valid selection.

2.3.2 The Cursor and Datum Lines

There are three lines, as indicated in Figure 2.3.2. Movement of them is achieved using the **DATUM** and **CURSOR** paddles as described below.




Figure 2.3.2 The Cursor and Datum Lines

Dat Selecting this option on the **Dat/Pos/Mag** button (30) allows the position of the datum lines to be controlled using the **DATUM** paddles. (40) to (43).

DATUM (40) to (43). Used for moving the two datum lines.

CURSOR (44) & (45) Moves the cursor horizontally.

2.3.3 Making Measurements

The instrument displays, at the bottom of the screen, the results of waveform measurements. The section of the trace to be measured is usually defined using the horizontal and vertical datum lines and the cursor.

The choice of points between which to make the measurements can influence the accuracy: while the measurements made will always be within design limits, placement of the cursor at the desired position is easier at those points where the slope of the waveform is at its steepest. For example, on a standard sine wave, the most accurate measurements of frequency are likely to be made if they are taken between two 0 V crossing points.

For details of the DSO's waveform measurement capabilities see section 5.1

2.3.4 Post Storage Manipulation

Pos/Mag These selections on the **Dat/pos/mag** button (30) allow the **DATUM** paddles to control post storage position and magnitude. They can only be used with stored waveforms. Pressing menu button 1 (opposite the restore message) will cancel the effect of pos and mag on the selected trace.

Pos This option on the **Dat/Pos/Mag** button (30) allows both X and Y shift to be applied to the trace on which the cursor is placed, using the **DATUM/POST STORAGE** paddles (40) to (43).

Mag The vertical magnitude of the selected trace can be varied from $\times 4$ to $\times 0.062$, using the **DATUM/POST STORAGE** paddles (40) to (43). The magnification factor is displayed near the top center of the CRT.

No horizontal magnification is available using this control, but $\times 10$ magnification may be applied to all stored traces using the horizontal mag button, (See Section 1.6.4.).

2.4 Plot

2.4.1 Internal Color Plotter Operation

When the internal color plotter is fitted to the DSO, plots of the instrument's display can be sent to it by selecting internal on the Plot Menu, see section 3.11.

The internal plotter is automatically selected after a cold start if it is fitted. If required the plot output can be directed via the RS423 or GPIB port to an external plotter by selecting RS423 or GPIB on the Plot Menu, see section 3.11.

2.4.2 Pens

Only use Gould pens - part number 4101175 for a pack of 4; 1 of each color or part number 4101265 for a pack of 4 black pens.

The normal pen sequence is:

Pen No.	Color
1	Black
2	Blue
3	Green
4	Red

The pen holder is color coded with this color sequence. When pens are fitted in this order, trace 1, the border and all the alphanumeric are plotted in black, trace 2 in blue, the reference trace in green and the graticule in red.

The cursor and datum lines and their measurements are plotted in the same color as the trace to which they relate.

2.4.3 Pen Changing

Underneath the plotter lid at the front of the plotter there are two small blue buttons. The right hand button when viewed from the front of the DSO is the Pen change button, and the left hand one is the paper advance button.

CAUTION: When changing a pen, extreme care should be taken not to damage the plotter mechanism. NEVER move the pen carriage by hand.

To change a pen, ensure that the instrument is switched on and then proceed as follows:

1. Press the pen change button once. This rotates the pen carriage and moves the carriage to the right hand side of the plotter.
2. Gently press the white grooved eject lever towards the front of the instrument. The top pen will be ejected from the pen carriage and can be removed from the plotter.

3. Insert the tip of the new pen into the carriage guide hole. Gently snap the other end of the pen into place.
4. When the pen has been changed, press the left hand button - the paper advance button - and the carriage will move back to the left hand side ready for the next pen change or plot.

2.4.4 Paper selection

Only use Gould paper - Part number 4101165 for a pack of 10 rolls. Other paper types may damage the mechanism.

2.4.5 Paper Loading

CAUTION: When loading paper, extreme care should be taken not to force the plotter mechanism. NEVER pull paper through by hand, always use the paper advance button to prevent damage to the plotter mechanism.

1. With scissors, cut the end of the paper square.
2. Open the plotter cover by depressing the catch and lifting the cover until it is fully open.
3. Remove the shaft from the paper cradle and if the plotter has been used previously remove the plastic or cardboard tube from the shaft.
4. Insert the shaft through the paper roll and fit the roll into the paper cradle.
5. Feed the paper from the top of the roll as shown in figure 2.4.5 below and push it through the slot in the rear of the printer mechanism.
6. Press the paper advance button - the left hand blue button at the front of the printer assembly - until the paper reappears at the front.
6. Feed enough paper through to pass through the top cover, ensure that it is running around the mechanism smoothly and that it is straight.
7. Close the plotter cover and ensure that it latches shut.




Figure 2.4.5. Paper Loading

2.4.6 Internal Plotting

When a plot is initiated, the Hold All LED lights and the message "PLOTING - PRESS PLOT TO ABORT" appears on the screen. After about 9 seconds the Hold All LED goes out indicating that the data has been transferred to the plot buffer and that the instrument can be used again. The plotting message will remain on the screen until the plot is complete when it will disappear.

In Auto Plot Mode, the instrument is re-armed after the plot data has been transferred to the plot buffer, but the front panel controls will remain in-active during plots.

If the plot button is pressed while the plot is in progress, the plot will be aborted. Any changes to the instrument status during a plot will have no effect on the plot as the data will have been transferred and stored in the plot buffer.

2.4.7 External plots

The parameters for the plotter interface and the plot format can be set as described in section 3.7 and 3.12.

A plot of the display can be sent to an external plotter by pressing the plot button (10). The display is held while a plot is in progress.

Plots can be aborted by a second press of the plot button. If the plot is aborted, the pen will be left in a random position and the external plotter may need to be reset to restore the pen to its start position.

2.4.8 Plot positioning and scaling

The output plot from the DSO has the relative positions shown in figure 2.4.8a. These may be shifted and scaled to position the plot exactly over a pre-defined grid using the following procedure with reference to figure 2.4.8b.

The sides of the pre-defined grid are X and Y, the exact positions of P1 and P2 are found by calculating the dimensions A, B, C and D:

Measure the vertical dimension of the required grid, note this as Y.

Measure the horizontal dimension of the required grid, note this as X.

Using these values of X and Y, A, B, C and D can be calculated as follows:

$$A = \frac{42 Y}{240} \quad B = \frac{196 X}{500}$$

$$C = \frac{703 X}{500} \quad D = \frac{310 Y}{240}$$

Measure and mark the exact positions of P1 and P2 from the grid edges using figure 2.4.8b and the values obtained above.

The P1 and P2 points can now be set on the plotter, refer to the plotter manual for details.




Figure 2.4.8a Relative Plot Positions




Figure 2.4.8b Plot Dimensions

2.5 Real Time Clock

The real time clock, if fitted to the instrument, enables the current date and time together with the date and time of acquisition to appear on any screen plot, and to be transferred to and from a computer when data is transferred using the GPIB or RS423 interfaces.

The clock will be kept running for at least ten years, even with the power disconnected, by its own internal battery back-up.

The date and time are set via the special functions menu. See section 3.7.

3. The Menu

The menu structure is summarized in Figure 3. The numbers 1 to 9 refer to the numeric buttons used to select the particular menus and menu items (Section 3.1.1.). All front panel controls remain “live” when menus are displayed, allowing the control status to be changed at any time.

3.1. Additional Buttons

3.1.1. The Numeric Buttons

The buttons 1 to 7 are used in conjunction with the menu system to provide a large number of extra functions not otherwise available directly from the front panel. Pressing these buttons when the menus are displayed operates the menu functions described in Sections 3.2 to 3.11.

3.1.2. Menu/Traces

Menu/Traces: (0) Toggles the display between the traces and the last used menu.

3.1.3. Menus

There are two Menu buttons which each select a menu to replace the current display

Control: (9) The current display, whatever it may be, is replaced with the Control Master Menu.

Post Store: (8) Brings the Post Storage Master Menu onto the display.




Figure 3 The Menu Structure




Figure 3.1 The Numeric and Menu Buttons

3.2. Control Master Menu

Each entry on the Control Master Menu is also a menu, covering one set of functions. The text is lined up with the numeric buttons 1-7 on the side of the display. To obtain any secondary menu simply press the relevant button.

<<CONTROL MASTER MENU>>	
STATUS	1
DISPLAY AND ACQUISITION	2
GRATICULE: Off On	3
REFERENCE TRACE	4
I/O INTERFACES	5
SPECIAL FUNCTIONS	6

Figure 3.2 The Control Master Menu

The options available on the Control Master Menu are as follows:

STATUS Displays information about the present setup of the instrument. See section 3.3.

DISPLAY AND ACQUISITION Controls probe sensitivity, averaging, interpolation, the Max/Min function, and Bandwidth. See section 3.4.

REFERENCE TRACE Either one of the currently displayed traces can be copied to the reference trace or the reference trace can receive data via the GPIB interface. See section 3.6.

I/O INTERFACES Setting the RS423 or GPIB interface, if fitted, and output protocol. See section 3.7.

SPECIAL FUNCTIONS Enables the user to disable the auto-calibration, calibrate either channel, force a full calibration and set the real time clock if it is fitted. See section 3.8.

GRATICULE: The display graticule can be switched on and off by pressing button 3. The current state is shown highlighted.

3.3. Status Menu

This menu allows the various horizontal, vertical and trigger settings of the instrument to be viewed. Because the front panel controls remain live, changes made to the instrument status will be immediately shown on this menu. A typical display is shown in Figure 3.3.

<<STATUS MENU>>		
MODE	Refresh	
MAX/MIN	Off	
	CH1	CH2
V/DIV:	=~2V	=~2V
Probe Set:	x1	x1
TIMEBASE: 0.2ms	X-MAG: x1	
TRIGGER:	SOURCE: CH2	
	COUPLING: AC	
	LEVEL: 0DIV	
	SLOPE: +ve	
	DELAY: 11 120ns	

Figure 3.3 A Status Menu

Mode: There are three possible display modes: Refresh, Roll and X-Y. They are described in Section 2.3.

Max/Min: The Max/min detector is selected using the Display and Trigger Menu. See section 3.4.

V/Div: The input sensitivity of the channels is shown in volts per division. The range is 2 mV to 5 V per division. If Add mode is selected, a + sign is shown between the channels.

Along with the input sensitivity of the channels, other information is also shown. The symbols used are as follows:

- Trace inverted.
- > Uncalibrated.
- ~ AC coupled.
- = Calibrated.

Probe Set: The probe gain settings are shown as $\times 1$, $\times 10$ or $\times 100$. These may be set using the Display and Trigger Menu. See Section 3.4.

Timebase: The sweep rate of the timebase is shown in s, ms, μ s or ns per division.

Trigger: This section of the display shows the selected trigger options. The choices of source are CH1, CH2, Ext and Line. The available couplings are AC, DC and high frequency reject. These are discussed in Section 2.1.

The trigger level is shown in terms of the number of screen divisions above the bottom of the graticule. The trigger slope is shown as either +ve (rising edge) or -ve (falling edge).

Following this is the trigger delay setting, given in s, ms, μ s or ns as appropriate. For pre-trigger operation, the figure is given as a percentage; 0% places the trigger point at the left-hand edge of the screen and 98% near the right-hand edge.

3.4. Display and Acquisition Menu

This menu controls probe ratios, bandwidth limit, max/min detection, interpolation, and the averaging function.

3

<<DISPLAY AND ACQUISITION>>									
CH1 PROBE:	<input checked="" type="checkbox"/> x1	x10	x100	1
CH2 PROBE:	<input checked="" type="checkbox"/> x1	x10	x100	2
BANDWIDTH:	Full	20MHz	3
MAX/MIN:	<input type="checkbox"/> Off	<input checked="" type="checkbox"/> On	4
DOT JOIN:	<input type="checkbox"/> Off	<input checked="" type="checkbox"/> On	5
AVERAGING:	<input type="checkbox"/> Off	<input checked="" type="checkbox"/> On	6
AVERAGING CYCLES	<input checked="" type="checkbox"/> 2	4	8	16	32	64	128	256	7

Figure 3.4 Display and Acquisition Menu

CH1 & CH2 Probe: An independent probe attenuation ratio can be set for each of the two input channels with successive presses of buttons 1 and 2. The ratios available are ×1, ×10 and ×100. Thereafter, probes of the chosen ratios may be attached to the appropriate inputs; the new sensitivities at the probe tip will be displayed correctly.

Bandwidth: To turn the 20 MHz low pass filter on and off press button 3 so that the required state is highlighted.

Max/Min: Using the number 4 button, the max/min function can be switched on or off.

The Max/Min function is designed to detect aliases (see section 1.7.2), and can be used to detect glitches which may occur between samples. It operates on the signal before it is placed in the acquisition store and can detect narrow glitches, down to 1 µs wide.

Glitches less than 1 µs will sometimes be detected and can give an aliasing effect. See section 1.7.2.

Any glitches detected will at least be displayed as a spike. They will be detected whether they are positive (max) or negative (min). The function works in the timebase ranges of 100 µs per division down to 50 s per division.

Dot Join: Button 5 selects the dot-joining function. On some X-magnified or high speed traces, gaps can be visible between the sample points; if **Off** is selected, the points alone will be displayed. Selecting **On** causes the data to be automatically joined by straight lines.

Averaging: It is possible to improve the signal to noise ratio of repetitive signals by averaging them. This function, which converts the display into weighted average of previous acquisitions is toggled **On** and **Off** by button 6. Button 7 is used to determine the averaging factor to be used in the algorithm.

$$A_n = \frac{a_n(f-1) + d}{f}$$

Where:

- | | | |
|----------------|---|-----------------------------|
| n | = | The data point (1 to 501) |
| A _n | = | New value at n |
| a _n | = | Old value at n |
| f | = | Averaging factor (2 to 256) |
| d | = | Latest value at n |

e.g. In continuous mode, if 8 acquisitions are selected, any single acquisition that deviates from an otherwise consistent level, contributes 1/8 of its deviation to the display. In S/Shot only the selected number of acquisitions contribute to the resultant held display.

3.5. Reference Trace

The menu provides the option of temporarily storing a trace for comparison with the two channels. It will be lost when it is replaced with an alternative trace.




Figure 3.5 Reference Trace Menu

To copy a currently displayed trace into the reference trace, simply press either button 2 or button 3 depending on which trace is required. A copy of the trace will then be taken.

To display a previously stored reference trace use the 1 button to toggle the selection to **On**.

3.6 I/O Interfaces Menu

This menu allows the parameters of the RS423 or GPIB interfaces to be set.




Figure 3.6 I/O Interface Menu

Full remote control, including trace data transfer, is possible using SCPI commands via GPIB or RS423 depending on which remote channel is selected. The SCPI commands are detailed in the separate SCPI manual.

GPIB The GPIB interface can be set to be Addressable or set to be a talk only device using button 1.

If the plot output has previously been set to GPIB, selecting ADDRESSABLE is not permitted. Attempting to do so will result in the screen error message:

PLOT OUTPUT MUST NOT BE GPIB

GPIB Address Press button 2 to set the GPIB address to any address number in the range 0 to 30.

The GPIB address line only appears if the GPIB is set to be addressable.

RS423 Baud Rate: This is selected with button 3. The baud rate may be 75, 150, 300, 600, 1200, 2400, 4800 or 9600 baud.

RS423 Handshake: Button 4 is used to select from handshaking Off, XON-XOFF, or CTS-RTS.

RS423 Format The data format is fixed with no parity, one start bit, eight data bits and one stop bit.

Remote Channel: Button 7, is used to select between GPIB and RS423 remote control.

Interface Connections

3.6.1. RS423 Plot Connections

The RS423 port is configured at the factory as shown in table 3.6.1. The instrument can be connected to a Gould colorwriter 6120 or 6320 or a HP7475 plotter using a Gould plotter cable. The connections of this cable are shown in figure 3.6.1.

Pin No.	Name	Description
1	0V	Protective Ground
2	RXD	Receive Data
3	TXD	Transmit Data
4	CTS	Clear to Send
5	RTS	Request to Send
7	0V	Signal Ground
9	0V	Ground
18	0V/5V	Limits Test Fail

Table 3.6.1 Standard RS423 Port Pin Connections




Figure 3.6.1 DSO to Gould 6120 or HP7475 Connections

3.6.2. RS423 Data Connections

To connect the DSO to a computer, use the connections shown in figure 3.6.2a or figure 3.6.2b. A prewired cable for each of these arrangements is available.




Figure 3.6.2a DSO to IBM-PC/XT Connections




Figure 3.6.2b DSO to IBM-AT Connections

3.6.3. IEEE Data Connections

To connect the DSO to a computer, use the IEEE connections shown in Appendix 5. A prewired cable for this connection is available.

3.7. Special Functions

This menu controls the selection of auto calibration and can force the instrument to perform a full calibration.

<<SPECIAL FUNCTIONS MENU>>			
AUTO-CAL:	Enable	Disable	1
CALIBRATE CURRENT SETUP			2
FULL CALIBRATION			3
(Connect 50R to EXT TRIG input)			
	INC		4
JULY 14 93 10:20:31			5
	DEC		6
SET DATE AND TIME			7

Figure 3.7 Special Functions Menu

AUTO-CAL: pressing button 1 enables or disables the instrument's automatic re-calibration procedure.

When Auto-cal is enabled, the change of any vertical or timebase range which is due for calibration will, after a 2 second pause, initiate a calibration of the new operating conditions. If the operating conditions are not changed, a recalibration is initiated at 15 minute intervals. Each calibration takes about one second.

If the occasional interruption of the normal function of the instrument is unacceptable to the user the Auto-cal facility can be disabled as described above. Recalibration is then recommended 30 minutes after switch on from cold, and additionally if there is a significant change in the ambient operating temperature.

CALIBRATE CURRENT SETUP: Pressing button 2 forces the instrument to recalibrate for the vertical range and mode and the timebase range at which it is currently set. The actual calibration occurs approximately 2 seconds after pressing the button. This feature does not operate when the instrument is in Continuous Roll mode.

FULL CALIBRATION: Button 3 forces the instrument to perform a complete internal recalibration ignoring existing information.

When performing a full calibration connect a 50 Ω termination to the EXT TRIG input. This ensures that the trigger input is correctly calibrated for a 50 Ω source signal.

All internal memories are cleared including the instrument status data and any stored traces. To obtain the best results from this calibration, the instrument must have been operating for a minimum of 30 minutes. This calibration should only be required if there have been repairs to the signal processing sections of the unit or if the internal battery maintaining the status memories has been totally discharged or disconnected.

Note: No auto-calibrations will be performed if the instrument is armed, in a data capture cycle, in continuous roll mode or if Auto-cal is disabled, they will simply be postponed until these conditions end. Full calibration is always available.

REAL TIME CLOCK: The real time clock is set using buttons 4, 5, 6 and 7 on this menu. The entire date and time is displayed, with one section highlighted. The highlighted element is selected using button 5 and can then be increased or decreased using button 4 or 6 as appropriate.

Once the correct date and time has been set, pressing button 7 enters the data. This makes it easy to set a time that is a few seconds in advance of real time and then press button 7 at a time signal. If the menu is exited without pressing button 7, then the date and time will remain unchanged.

The clock is kept running even with the power disconnected for at least three years by its own internal battery backup.

3.8 Post Storage Master Menu

The first three items on this menu provide access to three further menus which control the operation of the battery backed trace memories and the plotter.

<<POST STORAGE MASTER MENU>>		
SAVE TRACE	1
RECALL MEMORY	2
PLOT OPTIONS	3
CURSOR MEASUREMENTS	4
TRACE MANIPULATION	5
TRACE ARITHMETIC	6
PERSISTENCE/LIMITS TESTING	7

Figure 3.8 Post Storage Master Menu

The other four items on this menu are only available on instruments fitted with the waveform processing option. Their operation is described in section 5.

3.9. Save Trace Menu

This menu allows traces, including the reference trace, to be stored in the battery backed memories.

<<SAVE TRACE MENU>>		
Save Trace 1	1
Save Trace 2	2
Save Ref Trace	3
SAVE TRACE 2 TO:		
Memory 1	5
Memory 2	6

Figure 3.9 Save Trace Menu

Because these memories are battery-backed, the traces stored in them will not be lost even when the instrument is powered down.

SAVE TRACE: Using the 1, 2 or 3 buttons selects either Trace 1, Trace 2, or the Reference Trace respectively to be saved. Once the trace has been selected, a fresh option will appear, described below.

SAVE TRACE TO MEMORY: Either of the battery-backed memories may be selected as the destination in which to store the selected trace.

3.10. Recall Memory Menu

Traces previously saved using the Save Trace menu can be recalled using this menu.

<<RECALL MEMORY MENU>>	
Recall Memory 1 .	1
Recall Memory 2 .	2
RECALL MEMORY 2 TO:	
Trace 1 .	4
Trace 2 .	5
Ref Trace .	6

Figure 3.10 Recall Memory Menu

RECALL MEMORY: One of the memories may be recalled by pressing the appropriate button, 1 or 2. Having chosen a memory, you will be asked into which display trace you would like to place it.

RECALL MEMORY TO TRACE: Pressing button 4, 5 or 6 will cause the trace data from the previously selected memory to be displayed on trace 1, trace 2, or the reference trace.

Note: Unless the selected trace is held, or acquisition is not armed, the selected memory data could be over-written soon after it is displayed.

3.11. Plot Menu

This menu allows the user to set the format of the plot sent to the internal color plotter or to the external plotter via the RS423 or GPIB interface. Refer to Section 3.6 for RS423 connections.

<< PLOT MENU >>	
PLOT MODE: Single Auto .	1
PLOT WITH GRATICULE: Off On .	2
GRAT LINE TYPE: Solid Broken .	3
PLOT WITH CURSORS: Off On .	4
PLOT OUTPUT: Internal GPIB RS423 .	5
ADVANCE PAPER .	6

Figure 3.11 Plot Menu

PLOT MODE: This can be set to either Single or Auto with successive presses of the number 1 button. In Single plot mode one press of the Plot button will produce one plot output. In Auto mode, a press of the Plot button (10) will initiate a plot. The sequence thereafter continues automatically. At the end of the plot the trigger circuit is rearmed for the next acquisition, and at the end of an acquisition, the plot is started. An external plotter must have an auto feed facility to function correctly in this mode. If it does not, then the feed command from the DSO may confuse the plotter.

PLOT WITH GRATICULE: The user has the option of including the screen grid in the plots with On or excluding it with Off.

GRAT LINE TYPE: A solid or broken graticule can be selected for the plot, by successive presses of button 3.

PLOT WITH CURSORS: If On is selected, then any plots made will include the cursor and datum lines and the selected measurement data. Otherwise, they will be omitted.

PLOT OUTPUT: The internal plotter is automatically selected on cold start if it is fitted. If required the plot output can be directed, using button 5, via the RS423 or GPIB port to an external plotter by selecting RS423 or GPIB.

To plot via the GPIB it must be set to talk only mode. If GPIB is set to addressable on the I/O interface menu, GPIB cannot be set as the plot destination. Attempting to do so will result in the screen message

GPIB MUST NOT BE ADDRESSABLE

ADVANCE PAPER: To advance the paper approximately 15 mm on the internal plotter, pressing button 6.

4. Performance Checking

The aim of this section is to allow the user to verify the major analog performance parameters of the oscilloscope. Should any of these fail to be within specification then it is recommended that the instrument be re-calibrated. A skilled technician with the aid of the service manual should be able to perform this task; alternatively return the instrument to your local distributor.

4.1. Risetime

Equipment required:

Fast edge pulse generator <1 ns: Bradley oscilloscope calibrator type 192 or Tektronix PG506 or similar;
50 Ω precision coaxial cable;
50 Ω precision terminator.

Connect the pulse generator to a channel input through the coax cable and the terminator, which should be at the DSO end of the cable.

1. Select 100 mV per division on the input channel and set the timebase to 5 μ s per division.
2. Set the generator to give 600 mV peak to peak at a repetition rate of 1 MHz and adjust the trigger level to give a stable trace.
3. Select the cursor and change the timebase to the fastest range and select 50% pre trigger.
4. Apply $\times 10$ trace magnification using the **Mag** button, and adjust the horizontal **Position** buttons to center the fast edge.
5. Position the cursor and datum lines on the edge such that the cursor is 60 mV below the high level and the datum lines cross 60 mV above the low level.

The risetime can now be read from the cursor line on the bottom row of text. This figure should not be greater than 1.8 ns.

Note: On a set fitted with the measurements option, rise time can be selected from the cursor measurements menu.

4.2. Bandwidth

Equipment required:

Leveled signal generator: Tektronix SG503 or similar;
50 Ω coaxial cable;
50 Ω terminator.

Connect the signal generator to a channel input through the coax cable and the terminator, which should be at the DSO end of the cable.

1. Select 5 mV per division on the input channel and set the timebase to 50 μ s per division.
2. Set the amplitude of the signal generator to give six divisions at 50 kHz or similar reference frequency.
3. Change the timebase range to 0.5 μ s per division.
4. Increase the frequency on the signal generator until the peak to peak amplitude reduces to 4.2 divisions.

The measured frequency should be greater than 200 MHz.

4.3. Trigger Sensitivity

Equipment required:

Signal generator: Tektronix SG503 or similar;
50 Ω coaxial cable;
50 Ω terminator.

Connect the signal generator to a channel input through the coax cable and the terminator, which should be at the DSO end of the cable.

1. Select 100 mV per division on the input channel and set the timebase to 50 μ s per division.
2. Select **Auto** trigger.
3. Set the signal generator to 50 kHz or similar reference frequency and adjust the amplitude to give 0.3 of a division peak to peak.
4. Select **AC** Coupling and **Norm** on the trigger controls.

It should be possible to find a suitable trigger level to give a stable triggered trace.

4.4 Trigger Bandwidth

Equipment Required:

Leveled signal generator: Tektronix SG503 or similar.

50 Ω coaxial cable;

50 Ω terminator;

Connect the signal generator to a channel input through the coax cable and the terminator - which should be at the instrument end of the cable.

1. Select 100 mV per division on the input channel and set the timebase to 0.5 μ s per division.
2. Set the amplitude of the signal generator to give three divisions at 50 kHz or similar reference frequency.
3. Select AC coupling and Norm on the trigger controls.
4. Without adjusting its amplitude, set the signal generator to 200 MHz.

It should be possible to adjust the trigger level to give a stable trace.

4.5. Timebase Calibration

Equipment required:

Time calibrator: Bradley oscilloscope calibrator type 192 or Tektronix TG501 or similar;
50 Ω coaxial cable;
50 Ω terminator.

Connect the calibrator to a channel input through the coax cable and the terminator, which should be at the DSO end of the cable.

1. Select a suitable timebase range to view the signal and set the channel attenuator to give between two and five vertical divisions of signal.
2. Select DC Coupling and Norm on the trigger controls.
3. Adjust the trigger level to give a stable trace.
4. Change the timebase to 0.5 μ s per division.
5. Set the calibrator to produce markers every 0.5 μ s.
6. Select the cursors.

With the cursor and time datum on identical positions on any two markers, the time difference should read in multiples of 0.5 μ s to within 1%.

Note: Failure of this specification point is indicative of a major system fault and the instrument should be serviced as soon as is reasonably possible.

4.6. Vertical Calibration

Equipment required:

Oscilloscope calibrator: Bradley type 192 or similar;
Coaxial cable.

Connect the vertical calibration output of the oscilloscope calibrator to the DSO through the coax cable.

1. Set the timebase to 500 μ s per division and select 5 mV per division for the input channel.
2. Set the calibrator to give 30 mV peak to peak, i.e. 6 screen divisions.
3. Adjust the trigger level to give a stable picture.
4. Switch the cursor on.

The peak to peak measurement should be 30 mV to within 3% and the trace should be 6 divisions high to ± 0.1 divisions.

These measurements should be repeated on all the attenuator ranges, each time setting the calibrator to 6 screen divisions for the selected range.

4.7. Max-Min (Alias Detector)

Equipment required:

Signal generator: Tektronix SG503 or similar;
50 Ω coaxial cable;
50 Ω terminator.

Connect the signal generator to an input channel through the coax and the terminator, which should be at the DSO end of the cable.

1. Set the timebase to 0.5 μ s per division and select 100 mV per division on the input channel.
2. Set the generator to give approximately 5 divisions at 0.4 MHz and adjust the trigger level to give a stable trace.
3. Select 1 ms per division on the timebase. You should notice that the screen picture will change considerably with small changes in input frequency. The result on the screen is an alias.
4. Select the Max-Min function from the Display and Trigger Menu.

If Max-Min is functioning correctly a wide band will be displayed showing the peak excursions of the signal.

5. WAVEFORM PROCESSING FUNCTIONS

All the waveform processing functions are accessed through the Post-Storage Master Menu. Selections 1, 2 and 3 on this menu perform as described in section 3.8 to 3.11.

Selections 4 to 7 provide the waveform processing functions.

When performing any waveform processing that modifies a displayed trace, the new data could be overwritten almost immediately by a fresh acquisition unless the selected trace is held or further acquisitions are prevented e.g. the instrument is in single shot mode and the trace stored or no triggers are provided.

5.1 Cursor Measurements

The DSO has 3 user controlled lines for use with this section of facilities. Their operation is fully described in section 2.4. The cursor is moved along the selected trace using the cursor paddle (44) & (45), the two datum lines are moved using the datum paddles (40) to (43); the time datum line moves with < and > and the voltage datum with ^ and v.

Pressing button 4 on the Post Storage Master Menu changes the display to the Cursor Measurements Menu - figure 5.1a. The cursor is used to determine the trace of interest and for some measurements the cursor and time datum lines define the portion of the trace to be measured. Most trace measurements are with respect to the voltage datum line.

<< CURSOR MEASUREMENTS MENU>>		
CALCULATION 1:		
Freq, Period & Duty-cycle	2	
CALCULATION 2:		
Pulse width	3	
CALCULATION 3:		
Voltage & Time	4	
REFERENCE: Pulse Width Left.	5	
	INC .	6
30%		
	DEC.	7

Figure 5.1a. Cursor Measurements Menu

Three simultaneous calculations are possible using buttons 2, 3 and 4. Each calculation is selected from a roll around list containing the following options: Voltage & Time, Peak to Peak, Max & Min, Risettime (falltime), Overshoot (preshoot), Pulse Width, Frequency, Period, Duty Cycle, RMS, Area and off.

Several of these calculations automatically perform a Top and Base measurement (see section 5.1.1) to obtain the requested result.

A calculation can only be selected once e.g. if calculation 1 is set to its default of Voltage & Time, then Voltage & Time will not appear in the possible selections for calculations 2 or 3.

If any of the calculations are set to either Pulse Width or Risettime, lines 5, 6 and 7 are displayed. See sections 5.1.4 and 5.1.6

The calculation results are displayed in the three lines at the bottom of the trace display; figure 5.1b shows an example. Cursor measurements on ETS - equivalent time sampling - timebase ranges, are only valid on traces that the cursor is on and that are triggered.

If all the cursor measurements are set to off, the cursor data line on the display will show a message of the form; "TR1 CURSOR MEASUREMENTS OFF", and if the data is invalid for the measurement selected, the cursor line will display a message of the form "TR1 INVALID DATA". The trace number in both the above messages will change according to the selected trace.

CH1=0.2V TB=0.5μS	CH2=20mV Y-MAG: x1.438	X-MAG ON AFTS RESTORE 1
TR1 LIMIT TEST: PASS		
TR1 RISE/FALL (10%/90%)		DEL= 12.80μs
TR1 Max 2.87V		123.4μs
TR1 12.0kHz 83.00μs		MIN -2.6V
		48.2%

Figure 5.1b. Example of Calculations on Trace

5.1.1 Top and Base Measurement

To obtain some waveform measurements, the DSO performs an automatic Top & Base measurement as defined in the IEEE Standard on Pulse Measurement and Analysis by Objective Techniques: 181-1977.

The IEEE 194-1977 standard defines various parts of a pulse or edge waveform.

Under most circumstances the Top and Base levels, of a waveform between the time datum and cursor lines, are determined by taking the most common point above the mean of the waveform as the top, and the most common point below the mean as the base.




Figure 5.1.1 Waveform Measurement Points

Two kinds of waveforms can change the method of determining the Top and base.

Firstly, if these points do not occur for more than 10% of the time, the maximum and minimum of the waveform is taken to be the Top and Base. This prevents noisy signals producing erroneous results.

Secondly, if the difference between the mean and the maximum or the mean and the minimum levels of the waveform is less than 1/4 of a division, the maximum and minimum of the waveform is taken to be the Top and Base. This ensures that waveforms such as pulse trains with a low mean do not give erroneous results.

5.1.2 Voltage & Time

The display shows the voltage between the voltage datum line and the point where the cursor line crosses the trace and the time between the time datum line and the cursor line.




Figure 5.1.2. Voltage & time Measurement

5.1.3 Peak to Peak

The display will show the peak to peak voltage difference between the most positive and negative points of the trace between the cursor and the time datum.




Figure 5.1.3. Peak to Peak Measurement

5.1.4 Max & Min

The display shows the voltages of the maximum and minimum points of the waveform between the cursor and time datum measured with respect to the voltage datum.




Figure 5.1.4. Max & Min Measurement

5.1.5 Risetime (falltime)

The cursor and the time datum enclose the rising or falling edge of interest, the edge measured will be the first edge from the left hand side of the defined area. The DSO will perform a top & base measurement to determine the 0% and 100% points and then calculate the rise or fall time between the low and high percentage points of the waveform.




Figure 5.1.5. Risetime Measurement

The default percentage points are 10% and 90%. Using buttons 5, 6 and 7 these values can be changed. Button 5 selects the point to be changed, either Risetime High or Risetime Low. When the appropriate point is selected, it can be changed by pressing button 6 or 7 as required. Low can be set from 0% to 49% in 1% steps and high from 51% to 100% also in 1% steps.

Percentages set are retained even on power down, but are reset to their default values if a full calibration is performed.

If Pulse Width is also selected as one of the calculations, pressing button 5 steps around 4 entries; Risetime Low, Risetime high, Pulse Width Left and Pulse Width Right.

5.1.6 Overshoot (preshoot)

The cursor and the time datum enclose the overshoot or preshoot area of interest, the measured result will be the first over or pre shoot voltage from the left hand side of the defined area.

The DSO performs a Top & Base measurement to determine the 0% and 100% points and then calculates the overshoot as a percentage of the voltage difference between the 0% and 100% points.




Figure 5.1.6 Overshoot Measurement

5.1.7 Pulse Width

The cursor and the time datum define the pulse to be measured. The first pulse from the left hand side of the defined area will be measured and if the leading edge of this pulse is noisy, the noise may be taken as a pulse and be measured rather than the pulse of interest.

The DSO performs a Top & Base measurement and then measures the time between the 50% - or user defined percentage points of a pulse.

Either positive or negative pulses can be measured.




Figure 5.1.7. Pulse Width Measurement

The default percentage points are 50% and 50%. Using buttons 5, 6 and 7 these values can be changed. Button 5 selects the point to be changed, either Pulse Width Left or Pulse Width Right. When the appropriate point is selected, it can be changed by pressing button 6 or 7 as required. Both of them can be set from 5% to 95% in 1% steps.

Percentages set are retained even on power down, but are reset to their default values if a full calibration is performed.

If Risetime is also selected as one of the calculations, pressing button 5 steps around 4 entries; Pulse Width Left, Pulse Width Right, Risetime Low and Risetime High.

5.1.8 Frequency, Period, Duty Cycle

The three parameters frequency, period and duty cycle of a waveform are displayed with this selection. The voltage datum defines the zero crossing voltage. The cursor and time datum must enclose at least three zero crossings.

If the voltage datum does not cross the trace, the mean of the waveform will be taken as the zero crossing line.

The frequency is the inverse of the period calculated above.

The duty cycle is the ratio of the mark to whole pulse period expressed as a percentage. The left most of either the time datum or cursor defines which part of the waveform is defined as the mark and which the space. e.g if the datum is to the left of the cursor and intersects a low part of the waveform, the space is considered to be the low part of the waveform.




Figure 5.1.8. Frequency, Period and Duty Cycle Measurement

For duty cycle measurements, if the voltage datum does not cross the trace, the mid point of the waveform between its top and base levels will be taken as the zero crossing line. This is known as the mesial level.

5.1.9 RMS & AC RMS

This selection calculates and displays both the RMS voltage with respect to the voltage datum and the AC-RMS voltage with respect to the mean of the trace. Both voltages are calculated on the waveform bounded by the cursor and time datum.

5.1.10 Area

This selection calculates the area bounded by the trace and the cursor and the datum lines.




Figure 5.1.10. Area Measurement

The result is given in volt-seconds or similar units.

If the trace falls below the voltage datum (area B in figure 5.1.10) then the area below the datum will be negative. Positive and negative areas are added algebraically to obtain the displayed result.

5.2 Trace Manipulation

Pressing button 5 on the Post Storage Master Menu changes the display to the Trace Manipulation Menu - figure 5.2. The trace to be manipulated is selected with the cursor and the required function with button 2, 3 or 5.

<< TRACE MANIPULATION MENU>>	
FILTER FREQUENCY:556Hz	1
FILTER CURRENT TRACE	2
INVERT CURRENT TRACE	3
INTEGRATE SCALING:	
x1 x0.5 x0.2 x0.1	4
INTEGRATE CURRENT TRACE	5
RESTORE	7

If no trace is selected when button 2, 3 or 5 is pressed, the warning message "NO TRACE SELECTED" will be displayed.

Trace manipulations are with respect to the voltage datum line.

After any trace manipulation has been performed pressing button 7 labeled Restore, will return the display to the original stored waveform.

5.2.1 Filter Frequency

The trace can be filtered by a single low pass filter and the 3 dB point displayed on the trace display.

The frequency of the filter applied to the waveform when button 2 is pressed is selected using button 1.

One of six filter stages can be chosen from the roll-around list. The actual frequencies available depend on the current timebase as shown in table 5.2.1.

Figure 5.2. Trace Manipulation Menu

Timebase	F1	F2	F3	F4	F5	F6
50 s	111 mHz	45.5 mHz	21.3 mHz	10.3 mHz	5.05 mHz	2.51 mHz
20 s	278 mHz	114 mHz	53.2 mHz	25.8 mHz	12.6 mHz	6.27 mHz
10 s	556 mHz	227 mHz	106 mHz	51.5 mHz	25.3 mHz	12.5 mHz
5 s	1.11 Hz	455 mHz	213 mHz	103 mHz	50.5 mHz	25.1 mHz
2 s	2.78 Hz	1.14 Hz	532 mHz	258 mHz	126 mHz	62.7 mHz
1 s	5.56 Hz	2.27 Hz	1.06 Hz	515 mHz	253 mHz	125 mHz
500 ms	11.1 Hz	4.55 Hz	2.13 Hz	1.03 Hz	505 mHz	251 mHz
200 ms	27.8 Hz	11.4 Hz	5.32 Hz	2.58 Hz	1.26 Hz	627 mHz
100 ms	55.6 Hz	22.7 Hz	10.6 Hz	5.15 Hz	2.53 Hz	1.25 Hz
50 ms	111 Hz	45.5 Hz	21.3 Hz	10.3 Hz	5.05 Hz	2.51 Hz
20 ms	278 Hz	114 Hz	53.2 Hz	25.8 Hz	12.6 Hz	6.27 Hz
10 ms	556 Hz	227 Hz	106 Hz	51.5 Hz	25.3 Hz	12.5 Hz
5 ms	1.11 kHz	455 Hz	213 Hz	103 Hz	50.5 Hz	25.1 Hz
2 ms	2.78 kHz	1.14 kHz	532 Hz	258 Hz	126 Hz	62.7 Hz
1 ms	5.56 kHz	2.27 kHz	1.06 kHz	515 Hz	253 Hz	125 Hz
500 µs	11.1 kHz	4.55 kHz	2.13 kHz	1.03 kHz	505 Hz	251 Hz
200 µs	27.8 kHz	11.4 kHz	5.32 kHz	2.58 kHz	1.26 kHz	627 Hz
100 µs	55.6 kHz	22.7 kHz	10.6 kHz	5.15 kHz	2.53 kHz	1.25 kHz
50 µs	111 kHz	45.5 kHz	21.3 kHz	10.3 kHz	5.05 kHz	2.51 kHz
20 µs	278 kHz	114 kHz	53.2 kHz	25.8 kHz	12.6 kHz	6.27 kHz
10 µs	556 kHz	227 kHz	106 kHz	51.5 kHz	25.3 kHz	12.5 kHz
5 µs	1.11 MHz	455 kHz	213 kHz	103 kHz	50.5 kHz	25.1 kHz
2 µs	2.78 MHz	1.14 MHz	532 kHz	258 kHz	126 kHz	62.7 kHz
1 µs	5.56 MHz	2.27 MHz	1.06 MHz	515 kHz	253 kHz	125 kHz
0.5 µs	11.1 MHz	4.55 MHz	2.13 MHz	1.03 MHz	505 kHz	251 kHz
0.25 µs	22.2 MHz	9.09 MHz	4.26 MHz	2.06 MHz	1.01 MHz	501 kHz
0.2 µs	27.8 MHz	11.4 MHz	5.32 MHz	2.58 MHz	1.26 MHz	627 kHz
0.1 µs	55.6 MHz	22.7 MHz	10.6 MHz	5.15 MHz	2.53 MHz	1.25 MHz
50 ns	111 MHz	45.5 MHz	21.3 MHz	10.3 MHz	5.05 MHz	2.51 MHz
25 ns	222 MHz	90.9 MHz	42.6 MHz	20.6 MHz	10.1 MHz	5.01 MHz

Table 5.2.1. Filter Frequencies

5.2.2 Filter Current Trace

To perform the filtering, using the frequency previously set, press button 2.

5.2.3 Invert Current Trace

To invert the selected trace about the voltage datum, press button 3. To revert the display to the original trace, press button 1.

5.2.4 Integrate Scaling

To allow an integrated waveform to fit on the screen a scaling factor can be applied to the integrate function. Pressing button 4 steps around the factors $\times 1$, $\times 0.5$, $\times 0.2$ and $\times 0.1$. The selected factor is highlighted.

5.2.5 Integrate Current Trace

When button 5 is pressed, the display will show the integrated waveform of the selected trace. The voltage datum is taken as zero for integration and the cursor reads out the value in Vs - volt-seconds - or similar units.

5.3 Trace Arithmetic

Pressing button 6 on the Post Storage Master Menu selects the Trace Arithmetic Menu shown below in figure 5.3

<< TRACE ARITHMETIC MENU>>			
TR1	TR2	REF	1
ADD	SUBTRACT	MULTIPLY	2
TR1	TR2	REF	3
RESULT TO:	TR1	TR2	REF
SCALE:	x1	x0.5	x0.2
	x0.1		5
EXECUTE			7

Figure 5.3. Trace Arithmetic Menu

Using buttons 1, 2 and 3 the traces involved and the calculation required can be chosen with the selected option being highlighted.

When multiply is selected the scale line next to button 5 appears so that a scale factor can be applied to the calculation result to allow it to fit on the screen

The arithmetic result will be stored in the trace selected with button 4.

Pressing button 7 - Execute - causes the calculation to happen.

5.4 Persistence/Limits Testing

Button 7 on the Post Storage Master Menu selects the Persistence/Limits Testing Menu - figure 5.4.

<< PERSISTENCE/LIMITS TESTING>>	
SET UPPER LIMIT	1
SET LOWER LIMIT	2
TEST LIMITS:	
Off On Stop-on-fail	3
DISPLAY LIMITS: Off On	4
PERSISTENCE: Off Time Cycles	5
PERSISTENCE TIME (s):	
0.5 2.0 5.0 15 30 90 ∞	6
PERSISTENCE CYCLES:	
10 20 50 100 200 500 ∞	7

Figure 5.4. Persistence/Limits Testing Menu

5.4.1 Limits

Captured traces can be compared against pre-defined limit traces providing a pass/fail indication.

To set the upper and lower limits select the required trace using the select trace button (31) and press either button 1 or 2 as required. Repeat for the other limit. When a limit has been successfully set, the message LIMIT SET is displayed.

Limit traces may be transferred between the DSO and an external computer, through the GPIB or RS423 interface.

When display limits is on, the band between the upper and lower limits will be displayed.

Limit testing may be turned On or Off or set to Stop-on-fail by pressing button 3. Limits testing will be performed on all the data points of both the upper and lower limit traces within the area bounded by the cursor and time datum lines. When turned On, each successive acquisition is tested and a warning message displayed when a trace is outside the limits. This warning and trace will be overwritten by the next acquisition.

If the limits mode is set to Stop-on-fail, acquisitions are halted when a trace that is outside the limits is captured, allowing it to be examined. This screen picture can be plotted, and with the internal color plotter, the upper and lower limits will be in the same color as the reference trace to distinguish them from the failed trace.

During limits testing the trigger level and position markers are not displayed.

Test Limits and Display Limits cannot be turned on if the DSO is in X-Y mode or if X-Mag is turned on. Similarly, X-Mag or X-Y mode cannot be selected if either Test Limits or Display Limits is on. If any of these situations occur one of the following messages will be displayed as appropriate.

NO LIMITS DISPLAY IN XY

NO XY WHEN LIMITS DISPLAYED

NO LIMITS DISPLAY IN X-MAG

NO LIMITS TESTING WITH X-MAG

NO X-MAG WHEN LIMITS DISPLAYED

NO X-MAG WITH LIMITS TESTING

Also, Display Limits cannot be turned on if persistence is on. Trying to select this mode results in the message;

NOT WHEN PERSISTENCE ON

A record of all failing traces can be automatically plotted by setting the limits testing mode to stop on fail, and selecting Auto Plot from the plotter menu. Any acquired trace that then falls outside the limits will be plotted. If the plot button is not pressed to initiate a continuous sequence, only the first failing trace will be acquired and plotted.

The Limits fail line (pin 18) on the rear panel RS423 connector will go high if limits test fails.

5.4.2 Persistence

To obtain a persisted display, either the number of acquisitions accumulated before the display is cleared or the absolute time between display clearances can be set from the Persistence/Limits Menu.

The choice of Persistence for time or number of acquisitions is made using button 5 with the actual time or number of cycles set by button 6 or 7 as appropriate.

When using the persistence mode, the trigger level and position markers are not displayed.

If Display Limits is on, then persistence cannot be selected and the message NOT WHEN LIMITS DISPLAYED is shown if button 5 is pressed.

6. Alphabetical Summary of Controls

- AC/Gnd/DC** (20) & (24) Controls the type of coupling between the instrument and the input signal. **AC** is used to remove DC components from signals of between 4 Hz and 200 MHz. **DC** couples the input signal directly to the instrument, so all frequency components of the signal up to the instrument limit will be displayed. **Gnd** internally disconnects the inputs from the instrument; a 0 V reference signal is displayed instead.
- Add** (22) Displays the sum (or difference if one channel is inverted) of the channels. The original traces disappear and the resultant trace is displayed as a new Channel 2 trace.
- Armed** (54) Illuminates after **S/Shot** is pressed; it will stay lit until either the acquisition is complete or the **Run** button has been pressed.
- AUTO SETUP** (17) Will attempt to arrange the display so that two to five complete cycles appear, with the amplitude set so that the height of the trace is between two and five screen divisions. Also, it selects **Auto** trigger to ensure that the screen is frequently updated and a trace will be visible. If the frequency of the input signal is less than 20 Hz, this function may not operate correctly.
- CH1/CH2/Ext/Line** (29) Steps through trigger sources.
- CH1 (X)** (60) One of two channel signal input sockets, this one being for the connection of peak signals up to ≤ 400 V to Channel 1. It is used for the X component of an X-Y mode trace. It can also be a trigger source if selected using **CH1/CH2/Ext/Line**.
- CH2 (Y)** (59) As CH1, but CH2 is used for the Y component of an X-Y trace, where CH1 is the X component. It can also be a trigger source if selected using **CH1/CH2/Ext/Line**.
- Color Palettes** (rear panel switch) Each press of this switch selects the next colour palette for the display colors.
- Control** (9) Selects the control master menu.
- CURSOR** (44) & (45) These two buttons control the movement of the cursor.
- Δ /Pos/Mag** (30). **Δ** : Allows the **DATUM/POST STORAGE** paddles to be used to control the movement of the datum lines. **Mag**: this allows the vertical magnitude of a stored waveform to be varied using the **DATUM/POST STORAGE** paddles. **Pos**: this allows the trace on which the cursor is placed to be shifted using the **DATUM/POST STORAGE** paddles.
- EXT TRIG** Socket (58) for the connection of external triggers of up to ≤ 400 V peak.
- hf rej/AC/DC** (28) Selects trigger coupling. The **hf rej** (high frequency reject) option is a 15 kHz low-pass filter. Any coupling may be used with any trigger source.
- Hold** (15) & (16) Freezes the relevant trace or traces until pressed again.
- Hold All** (14) Freezes all traces until pressed again.
- Int/Ext Monitor** (rear panel switch) Selects the display destination for the instrument to be either the internal color display or an external multi-sync monitor.
- Level** (52) & (53) Adjusts the trigger level, which is indicated by two trigger bars on the display.
- Mag** (18) Used to control the horizontal magnification of the traces; when selected, a $\times 10$ expansion around the center of the screen is applied to the traces. The timebase display is altered to reflect the expansion.
- Menu/Traces** (0) Swaps the display between the last used menu and the trace display.
- Norm/Auto** (26) Selects the trigger mode. **Norm** means that The instrument will only initiate captures when a valid trigger is received. **Auto** triggering is the same as **Norm** except that if no valid trigger has been received for some time, an artificial trigger will be generated: the instrument will generate its own triggers if no valid trigger has been received for 0.05 s (i.e. 20 Hz is the lower limit).
- Off/On/Inv** (21) & (25) Switches the channel **On** or **Off**. If the channel is on, its trace can be displayed **Inverted**.
- Plot** (10) Produces a plot of the current display on a suitable plotter. If a plot is in progress, pressing this button will abort it.

Position (46) to (49) These paddles move the appropriate channel's trace vertically.

Position (34) & (35) Moves all traces horizontally.

Post Store (8) Selects the post storage master menu.

POWER (63) Used to switch the instrument on or off.

Pretrig/Delay (50) & (51) Used in conjunction with the menus to control the degree of pre-trigger% or trigger delay.

Refr/Roll/X-Y (11) Selects one of three display modes. **Refreshed** mode is the normal oscilloscope mode whereby the trace is acquired from left to right. **Roll** mode is like a chart recorder: the display scrolls from right to left as the trace is acquired. **X-Y** mode takes the **CH1(X)** input as the X (horizontal) component and the **CH2(Y)** input as the Y (vertical) component.

Run (13) Puts the instrument in continuous capture mode; the instrument automatically re-arms itself after each acquisition.

Select Trace (31) Places the cursor onto a displayed trace.

S/Shot (12) Arms the instrument for a single-shot triggered acquisition sweep (capture). The **Armed** light will be illuminated to show that this button has been pressed.

Stored (55) Illuminates on completion of a single-shot acquisition. It will stay lit until the instrument is re-armed or until **Run** is pressed.

TIME/DIV (32) & (33) Controls the sweep rate of the trace. The timebase can be varied from 50 s/div to 25 ns/div, in a 1, 2, 5 sequence of values.

Triggered (57) This lights up when the instrument is receiving valid triggers.

Uncal (56) Controlled by the **Var** button. When lit, the coarse setting of the attenuator remains unchanged, but a variable gain is applied to the input signal. This control applies attenuation in the range of 1 to 0.4. Thus, with an initial setting of 1 V, the actual sensitivity of the channel may be set anywhere between 1 V and 2.5 V per division. The **V/DIV** buttons are used to vary the sensitivity.

Var (19) & (23) Toggles between **Uncal** and **Cal**.

V/DIV (36) to (39) Adjusts the sensitivity of the instrument over discrete calibrated ranges from 2 mV/div to 5 V/div in 1, 2, 5 steps. With a $\times 10$ probe the ranges are 20 mV/div to 50 V/div at the probe tip. Peak input voltage must not exceed ± 400 V. If the **Uncal** light is on, then these paddles control the sensitivity over an uncalibrated continuous range of values.

+/- (27) Selects triggering on positive or negative slopes.

Appendix 1: Screen Messages

When something is wrong, an error message will be displayed in inverse text near the bottom of the display. Also in some cases a message appears to confirm that an action has occurred.

Brief explanations of when these messages occur are given below in alphabetical order.

GPIB and RS423 messages are not shown in this list, see the separate list in the remote command section.

1. **CALIBRATION DISABLED**
If calibrate current setup is pressed while Autocal is disabled.
2. **GPIB MUST BE ADDRESSABLE**
If remote channel GPIB is selected while the mode is set to talk only.
3. **GPIB MUST NOT BE ADDRESSABLE**
If GPIB is selected as the plot destination while set to addressable.
4. **GPIB REMOTE:- PRESS PLOT TO ABORT**
Appears when the instrument has been driven remote by the GPIB interface.
5. **LEVEL FIXED WHEN SOURCE = LINE**
If the trigger level controls are touched when line trigger is selected.
6. **MUST BE ADDRESSABLE WHEN REMOTE**
If GPIB talk only is selected while the remote channel is set to be GPIB.
7. **NO ADD IN XY MODE**
If trying to select ADD when in X-Y mode.
8. **NO ADD WHEN HELD**
If the add button is pressed when either or both CH1 or CH2 are held.
9. **NO BINARY WITH X-ON X-OFF**
If X-ON X-OFF is selected and binary number base is also selected.
10. **NO CURSORS IN XY**
If either the Datum or Cursor position paddles or the select trace button is pressed in X-Y mode.
11. **NO HORIZONTAL MAG**
If post storage horizontal magnification is attempted.
12. **NO LIMITS DISPLAY IN XY**
If limit display is turned on while the instrument is in XY mode.
13. **NO LIMITS DISPLAY IN X-MAG**
If limit display is turned on while the instrument is in X-MAG mode.
14. **NO LIMITS TESTING ON REF TRACE**
If limit testing is turned on while the cursor is on the reference trace.
15. **NO LIMITS TESTING WITH X-MAG**
If limit testing is turned on while the cursor is in X-MAG mode.
16. **NO POST STORAGE IN XY**
If the cursor is selected and then the unit is switched to X-Y mode and then a post storage paddle is pressed.
17. **NO TRACE SELECTED**
If the cursor is off and either the restore, cursor position or post storage movement paddles are pressed.
18. **NO X-MAG IN ACTIVE ROLL**
 - a) If the X-MAG button is pressed while the instrument is in ROLL mode on timebase ranges slower than 20 ms/div with the traces not stored and neither channel held.
 - b) If in ROLL mode on timebase ranges faster than 50ms/div with continuous acquisitions and X-MAG on, and then the timebase range is changed to be 50 ms/div or slower.
19. **NO X-MAG IN XY MODE**
If X-MAG is pressed when in X-Y mode.
20. **NO X-MAG WHEN LIMITS DISPLAYED**
If X-MAG is pressed while display limits is on.
21. **NO X-MAG WITH LIMITS TESTING**
If X-MAG is pressed while the instrument is in limits testing mode.
22. **NO XY WHEN LIMITS DISPLAYED**
If XY is pressed while display limits is on.
23. **NO XY WHEN CHANNELS ADDED**
If trying to select X-Y mode when channel ADD is on.

- 24. NO XY WITH X-MAG**
If trying to select X-Y mode when X-MAG is on.
- 25. NOT WHEN LIMITS DISPLAYED**
If persistence is turned on while display limits is on.
- 26. NOT WHEN PERSISTENCE ON**
If display limits is turned on while the instrument is in persistence mode.
- 27. PLOT OUTPUT MUST NOT BE GPIB**
If addressable GPIB mode is selected while the plot destination is set to GPIB.
- 28. PLOTTING - PRESS PLOT TO ABORT**
Appears whilst plot is in progress.
- 29. RS423 REMOTE:- PRESS PLOT TO ABORT**
Appears when the instrument has been driven remote by the RS423 interface.
- 30. TR1 CURSOR MEASUREMENTS OFF**
If all three cursor measurement options are set to off, this message appears.
- 31. TR1 INVALID DATA**
If the data is invalid for the measurement selected.
- 32. TRACE COPIED**
To confirm that a trace has been copied to the reference trace.

(Note also that if a trace is copied to the reference trace, the reference trace is automatically turned on as well).
- 33. TRACE MEMORY UNUSED**
a) If trying to turn the reference trace on when it has not been previously copied/saved.
b) If an attempt is made to recall a backup memory when that memory has not been previously saved.
- 34. TRACE NOT YET STORED**
If the cursor is selected and a post-storage paddle pressed but the trace is not stored or held.
- 35. TRACE RECALLED**
To confirm that a trace has been recalled.
- 36. TRACE SAVED**
To confirm that a trace has been saved.
- 37. USE CH1 POS'N KEYS IN XY**
If the horizontal position paddle is pressed when in X-Y mode.
- 38. WAITING FOR TRIGGER**
If S/SHOT has been selected but no trigger has been detected within 2 s.
- 39. X-MAG RESTORED WHEN STORED/HELD**
If the traces are stored or held in ROLL mode. Then if X-MAG is selected and either S/SHOT or RUN is pressed, or either channel unheld.

i.e. X-MAG has been turned off while the display is in active roll mode, but it will be restored when the display is once again stored or held.
- 40. 25ns TO 100µs/DIV, NO MAX-MIN**
If max/min is selected when timebase is faster than 100 µs/DIV.

Appendix 2: Specification

DISPLAY

LCD: 6 inch diagonal, backlit color liquid crystal display.

Graticule: Electronically generated 8×10 divisions with 0.2 sub divisions.

Colors: 8 switch selectable color palettes for Traces, Graticule and Alphanumerics.

VERTICAL SYSTEM

Two identical channels, CH1 and CH2. Inputs via BNC connectors.

Sensitivity: 2 mV/div to 5 V/div in 1-2-5 sequence.

Accuracy: $\pm 2.5\%$ of reading ± 1 digitizing level (1/30 of a division).

Variable Sensitivity: $>2.5:1$ range allowing continuous adjustment of sensitivity between ranges.

Input Impedance: $1\text{ M}\Omega/15\text{ pF}$.

Input Coupling: DC-GND-AC.

Bandwidth:

DC: 0 - 200 MHz (-3 dB)

AC: 4 Hz - 200 MHz (-3 dB)

Bandwidth Limit: 20MHz selected from menu

Input protection: $\leq 400\text{ V}$ DC or peak AC. (10 kHz or less on all ranges below 0.2 V/div.)

Expansion: Post storage $\times 0.062$ to $\times 4.00$.

HORIZONTAL SYSTEM (Timebase)

Sweep rate: 29 ranges in 1-2-5 sequence

Transient capture: 250 ns/div to 50 s/div

Repetitive sampling: 100, 50 and 25 ns/div

Sample rate accuracy: $\pm 0.01\%$ of sample time.

Expansion: $\times 10$ with linear dot interpolation.

TRIGGER DELAY

Trigger delay range: 20 ns to 5000 s.

Trigger delay accuracy: $\pm 0.01\%$, $\pm 1\text{ ns}$.

Pre-trigger: 0% to 98% of sweep in 0.4% steps.

Resolution: 2% of time/div, 20 ns min.

TRIGGER SYSTEM

Variable level control with Auto/Normal facility, resolution of less than 0.1 div.

Auto/Normal Mode: In Auto the timebase free runs when insufficient signal (20 Hz-200 MHz) is present or when the selected level is outside the range of the input signal.

Source: CH1, CH2, External or Line.

Coupling: DC, AC, high frequency reject filter.

Slope: +ve or -ve.

Sensitivity:

Internal	DC Coupled	$<0.3\text{ div}$ DC to 20 MHz $<1.5\text{ div}$ 10 MHz to 200 MHz
	AC Coupled	$<0.3\text{ div}$ 10 Hz to 20 MHz $<1.5\text{ div}$ 4 Hz to 200 MHz
External	DC Coupled	$<150\text{ mV}$ DC to 20 MHz $<600\text{ mV}$ 10 MHz to 200 MHz
	AC Coupled	$<150\text{ mV}$ 10 Hz to 20 MHz $<600\text{ mV}$ 4 Hz to 200 MHz

Range: Internal ± 10 divisions.

External $\pm 3\text{ V}$.

External input impedance: $1\text{ M}\Omega/15\text{ pF}$.

External input protection: $\leq 400\text{ V}$ DC or peak AC.

Trigger jitter, non ETS ranges: (50 s/div to 500 ns/div), $\pm 2\%$ of time/div (unexpanded), $\pm 2\text{ ns}$.

Trigger Jitter, ETS Ranges: $\pm 0.5\text{ ns}$.

DISPLAY MODES

Refreshed: Stored data and display updated by triggered sweep.

Roll: Stored data and display updated continuously for timebases 50 ms/div to 50 s/div. Trigger stops the updating process.

Refresh and roll operate as repetitive single shot for timebase ranges faster than 50 ms/div.

Dot join: Dots are joined by vertical raster lines. Linear dot interpolation is provided when the trace is horizontally magnified (using Mag).

X-Y: X-Y display is 8×8 divisions. Stored data and display are updated by triggered sweep. There is no dot joining, $\times 10$ expansion or cursor in this mode. CH1 is used as the X (8 bit resolution, 25 steps/div) and CH2 as the Y (7 bit resolution, 15 levels/div) deflection.

Single trace: CH1 or CH2.

Dual trace: CH1 and CH2.

Add: CH1 and CH2 can be added to give the algebraic sum of the two channels. Addition is pre-storage.

Invert: Both channels may be independently inverted.

Single Shot: Freezes store at the end of a single triggered sweep.

Display trace hold: (all) Freezes the display immediately.

Channel 1 trace hold: Freezes channel 1 display immediately.

Channel 2 trace hold: Freezes channel 2 display immediately.

Reference trace: One reference trace can be displayed in addition to the two input channels. This can display a waveform memory of a trace copied from CH1 or CH2.

ACQUISITION SYSTEM

Maximum sample rate: 200 megasamples/sec simultaneously on each channel.

Vertical resolution: 8 Bits (1 in 256) 30 levels per division.

Record Length: 501 points per channel.

ACQUISITION MODES

Normal mode: Transient and repetitive signal capture. (Repetitive capture is only on timebase ranges faster than 200 ns/div. This gives an equivalent sample rate of 2 ns/sample on the 100 ns/div range).

X-Y Mode: Bandwidth 200 MHz (-3 dB). Phase difference $<3^\circ$ at 1 MHz. Acquisition rate dependent on the timebase range.

Averaging: Averages can be set from 2 to 256 in binary sequence, selected from the menu system. Averaging operates continuously or, using single shot for the set number of acquisitions, (weighted average).

Peak detection: Minimum pulse width 1 μ s. 100% probability of capture. Operates on timebase range 100 μ s/div or slower.

MEMORY

Waveform memory: 2 reference memories are selectable for waveform data storage. These memories are Non-volatile.

Set-Up: The control set-up is retained in memory during power down.

Retention time: The memory support is trickle charged and will retain information for 1 month after power down.

ON SCREEN MEASUREMENTS and ALPHANUMERIC DISPLAY

Datum Lines: Horizontal and vertical full screen amplitude time and voltage datums.

Cursor: The measurement cursor can be assigned to a trace and measurements made in time and voltage with respect to the datums.

Cursor measurement display: Δ Voltage and Δ Time displayed on screen.

Accuracy: Voltage $\pm 2.5\%$ of reading, ± 1 digitizing level (1/30 of a division).
Time $\pm 0.01\%$ of reading ± 1 digit.

Resolution: Voltage 0.4% of F.S.D.
Time 0.2% of F.S.D.

Trigger Indication: On screen trigger level and trigger point indication.

Alphanumerics: Display on screen to indicate vertical sensitivity and input coupling for each channel, timebase speed and pre-trigger or trigger delay. Arrow for off screen indication of trigger point and traces.

MENU SELECTION

Control master menu: Selects menus for prime functions:- Status, display and trigger facilities, graticule, reference trace control, I/O interfaces, and special functions.

Menu/traces: Alternately switches between trace display and last menu selection.

Post storage master menu: Selects menus for fast access to save/recall trace, plot output parameters and waveform processing functions.

AUTO SET UP

Automatically sets the front panel controls to display any applied repetitive input signal for frequencies greater than 20 Hz.

RS423 INTERFACE

Serial interface port which permits full remote control of the instrument.

Baud rate: 75, 150, 300, 600, 1200, 2400, 4800, 9600.

Data bits: 8.

Parity: None.

Start-stop: Fixed: one start, one stop bit.

IEEE-488 Interface

Parallel data interface which permits full remote control of the instrument

Address: menu selectable 00 to 30

Internal Color Plotter

Paper type: Gould part No. 4101165 (10 roll pack).

Paper length: 45 meters, equivalent to approximately 250 plots.

Pen type: Gould part No. 4101175 (4 color pack).

Pen life: Minimum of 250 meters line length, approximately 175 plots.

DIGITAL PLOTTER OUTPUT

The instrument can directly output to suitable HPGL format plotters via the RS423 or GPIB interface port.

Plot mode: Manual or auto selection to output a stored trace.

Annotation: Range and scaling annotation, graticule cursors and cursor readout can all be included in the plot output.

MONITOR OUTPUT

The instrument provides RGB and sync signals to drive any multi sync monitor. This output is activated by a rear panel switch.

Level: 0–700 mV signal.

Line Rate: 31.25 kHz.

Frame Rate: 50 Hz.

WAVEFORM PROCESSING FUNCTIONS**Cursor Measurements****Voltage and Time**

The cursor measures the voltage and time relative to the voltage and time datum lines respectively.

Peak-Peak

Calculates peak-to-peak voltage of the waveform bracketed between the time datum and cursor.

Max-Min

Displays maximum and minimum voltage excursions of a waveform relative to the voltage datum position. The cursor and datum bracket the waveform of interest.

Risetime (falltime)

Calculates the rise or fall time between the 10% and 90% or customer defined percentage points of a signal; The cursor and datum bracket the waveform of interest and the 0% and 100% points are automatically detected by the instrument.

Overshoot (preshoot)

Calculates the over or pre shoot of a signal as a percent of the 100% point; The cursor and datum bracket the waveform of interest and the 0% and 100% points are automatically detected by the instrument.

Pulse Width

Calculates the time between 50% or customer defined percentage points of a pulse, with the pulse being bracketed between the time datum and the cursor.

Frequency, Period, Duty Cycle

Calculates the average frequency, period and duty cycle of a waveform. Uses either the voltage datum as the zero crossing point or the mean of the waveform. The cursor and time datum set the limits of the area of interest.

RMS

Calculates the root mean square (RMS) voltage of a waveform bracketed between the cursor and time datum. The voltages are calculated with respect to both the voltage datum (DC-RMS) and the mean of the waveform (AC-RMS).

Area

Calculates the area under a waveform bracketed between the cursor and the voltage and time datum lines.

Trace Manipulation**Filter**

6 selectable stages of low pass filter for each timebase range.

Invert

Inverts the trace about the voltage datum.

Integrate

Calculates the definite integral and displays the resultant waveform. A scaling factor of $\times 1$, $\times 0.5$, $\times 0.2$ or $\times 0.1$ can be applied to the integrated waveform.

Trace Arithmetic**Add**

Adds any two traces and displays the result in a selected trace.

Subtract

Subtracts any two traces and displays the result in a selected trace.

Multiply

Multiplies any two traces and displays the result in a selected trace. A scaling factor of $\times 1$, $\times 0.5$, $\times 0.2$ or $\times 0.1$ can be applied to the multiplied waveform.

Limits testing

Tests a waveform with respect to two definable limit waveforms and will display a TEST FAILED message if the acquired signal fall outside the limits. Acquisition can be continuous or stop-on-fail.

Persistence

Either the time, or number of acquisitions between screen clearances can be set to give a persisted trace display. Times of 0.5, 2.5, 5, 15, 30 or 90 seconds or multiple acquisitions of 10, 20, 50, 100, 200 or 500 traces can be selected. Both options can be set to infinity to give a permanent persistence display.

REAL TIME CLOCK

24 hour time and date set via a menu. Printed out on plots to give a permanent record of acquisition time. The time and date is maintained for approximately ten years with the instrument's power disconnected.

ENVIRONMENTAL

Temperature: Full specification: $+15^{\circ}\text{C}$ to $+35^{\circ}\text{C}$.

Operating: 0°C to $+50^{\circ}\text{C}$.

Storage: -40°C to $+70^{\circ}\text{C}$.

Humidity: Operating IEC68-2-56 at $+40^{\circ}\text{C}$ with 95% RH.

Non-operating IEC68-2-30 cycling $+25^{\circ}\text{C}$ to $+45^{\circ}\text{C}$ with 95% RH, 6 cycles (144 hours).

Vibration: Operating: MIL spec 810D. Random frequency vibrations of 5-500 Hz at 1 g rms for 15 minutes.

Non-operating: Sinusoidal, 15 cycles of 1 minute duration 10 Hz to 1 kHz in each of the three major axis. 10 Hz to 55 Hz at 0.6 mm pk-pk displacement and 55 Hz to 1 kHz at 4g peak.

Shock: Operating: 3 shocks of 30 g peak, half sine, 11 ms duration on each of the three major axes.

Safety: Designed for EN 61010-1 standard.

EMC: Emission: EN55022, VDE 0871, FCC PT. 15 all to Class A.

Immunity: IEC 801:Pt. 2 Class 3 (ESD), Pt. 3 Class 2 (EMR), Pt. 4 Level 2 (transient burst).

MISCELLANEOUS

Calibrator: 1 V peak to peak $\pm 1\%$, frequency approx 1 kHz calibration signal on front panel.

Ground: Front panel ground reference.

POWER REQUIREMENTS

AC Voltage: 90-132 V or 180-264 V.

Frequency: 45-440 Hz.

DC Voltage: 12-33 V.

Power: 85 V·A approx.

WEIGHT

9.5 kg (21lb) approx.

DIMENSIONS

166 mm height \times 341 mm width \times 483 mm depth ($6\frac{1}{2} \times 13\frac{1}{2}$ inches) excluding handle.

ACCESSORIES SUPPLIED

Operator Manual
SCPI Operator Manual
Line Cord
2 Probes PB47 300 MHz \times 10

OPTIONAL ACCESSORIES

Sliding Rack Mounting Kit	4094960
Carrying Case (soft padded)	4101273
Carrying Case (hard, foam lined)	4101274
Front Facia Cover	4101276
Accessory Pouch	4101223
Probe DC to 250 MHz switched \times 1 and \times 10	PB20
Probe DC to 250 MHz 1200 V \times 100	PB17
Probe DC to 10 MHz 3.2 kV \times 100	PB49
Probe DC to 7 MHz 15 kV \times 1000	PB27
Active Probe DC to 500 MHz \times 10	PB50
Active Probe DC to 500 MHz switched \times 1 and \times 10	PB51
External TV Trigger Unit	4101245
DC Cable Reel 6m (19'8")	4090491
DC Power Connector	458432
Pack of 4 Pens (Red, Green, Blue, Black)	4101175
Pack of 4 Pens (Red)	4101358
Pack of 4 Pens (Black)	4101265
Pack of 10 Rolls of plotter paper	4101165

Appendix 3

Remote DC Operation of the DSOs

The DSO can be operated from external DC voltages between 12 V and 33 V measured at the DSO. This has the advantage of uninterruptable operation which an oscilloscope powered from an inverter type of DC supply does not have. Inverter type DC supplies are powered by batteries and generate AC power in the absence of an incoming AC supply. In order for them to start working they first have to detect the loss of the AC supply which can take a few seconds.

Any applications which require continuous operation of a DSO regardless of AC supply fluctuations or drop-outs, as well as those requiring a remote power source will benefit from the versatility of the DSO's DC power feature. Some examples of these applications are uninterruptable power supply development and troubleshooting, and troubleshooting of supply interference caused by large electric machines.

The DC operation power dissipation of the instrument varies from about 60 W to 64 W depending on its activity and increases by about 5 W when printing. This dissipation is a constant power load to the source.

This means that less current is drawn at higher voltages and conversely more current at lower voltages. The user should ensure that there is sufficient source voltage to overcome cable and connector voltage losses that may occur because of the relatively high current involved. See table A3.1

Figure A3.2 below shows the DSO's internal arrangement of the power connections. It can be seen that current will be drawn from the AC supply as long as the external DC input voltage is lower than the AC input voltage minus the two diode voltage drops in the bridge rectifier.

This simple diode ORing of the two power sources means that switching from one source to another is very quick - there is no interruption in the operation of the instrument while one source takes over from the other.

The diode in series with the external DC source protects the instrument against reverse polarity voltages and allows both the AC and DC supplies to be connected at the same with the source supplying the higher voltage being the one from which current is drawn.

Table of Annealed Copper wire sizes vs. length for 0.5 V drop at 5 Amp current

Diameter (mm)	Cross Sectional Area (mm ²)	Length m
0.8	0.5	2.9
0.98	0.75	4.35
1.26	1.25	7.25
1.78	2.5	14.5
2.26	4.0	23.2
2.76	6.0	34.8
3.19	8.0	46.4
3.57	10.0	58.0

Table A3.1 Copper Wire Sizes




Figure A3.1 Internal Power Connections

A3

APPENDIX 4**Interfacing the DSO to a HP310 computer via the RS423 Port**

When interfacing the DSO to a HP 310 via the RS423 port, the cable should be wired as follows:




Figure A4 PC Interface Connections

To test the interface and connections, connect the above cable to the DSO and port 9 on the HP310, turn ON Channel 1 and Hold all and use the I/O Interface Menu to set the DSO operating conditions to be:

SPEED	2400
HANDSHAKE	CTS-RTS
NUMBER BASE	ASCII

Now run the following short HP BASIC program:

```


10  DIM T$(4),C$(1050),D$(1050)
20  Bd=2400
30  CONTROL 9,3;Bd
40  ASSIGN @Scope_ad to 9
50  T$="":TRAC:STAR 0;STOP 500"
60  S$="":FORMAT ASCII"
70  U$="":TRACE? TRACE1"
80  OUTPUT @Scope_ad USING "K";T$
90  OUTPUT @Scope_ad USING "K";S$
100 OUTPUT @Scope_ad USING "K";U$
110 ENTER @Scope_ad USING "#,523A";C$
120 END

```

This sets up the HP 310 interface 9 to 2400 baud, sets the trace start point to 0 and stop point to 500, sets the data format to ASCII and requests trace 1 data. The response from the DSO is put into string C\$.


This program is only intended as a guide to using the data transfer facility. Other languages or versions of BASIC may require different commands and different host computers may need different cable assemblies.

Appendix 5
Connector Pinouts




Pin	Signal	Description
1	0 V	Protective Ground
2	RXD	Receive Data
3	TXD	Transmit Data
4	CTS	Clear to Send
5	RTS	Request to Send
7	0 V	Signal Ground
9	0 V	Ground
18	0 V/5 V	Test Limits Fail

Figure A5a RS423 Connector Pinout



Pin	Signal	Description	Pin	Signal	Description
1	DIO1	Data input output line 1	13	DIO5	Data input output line 5
2	DIO2	Data input output line 2	14	DIO6	Data input output line 6
3	DIO3	Data input output line 3	15	DIO7	Data input output line 7
4	DIO4	Data input output line 4	16	DIO8	Data input output line 8
5	EOI	End or identify	17	REN	Remote enable
6	DAV	Data valid	18	(DAV)	Return line
7	NRFD	Not ready for data	19	(NRFD)	Return line
8	NDAC	Data not accepted	20	(NDAC)	Return line
9	IFC	Interface clear	21	(IFC)	Return line
10	SRQ	Service request	22	(SRQ)	Return line
11	ATN	Attention	23	(ATN)	Return line
12	Shield		24		Logic Ground

Figure A5b GPIB Connector Pinout



Pin	Signal
1	Red
2	Green
3	Blue
5	Ground
6	Ground
7	Ground
8	Ground
13	Horizontal Sync
14	Vertical Sync

Figure A5c Monitor Connector Pinout





Figure A5d DC Connector Pinout



Service Facilities

Gould and its distributors and agents maintain comprehensive after sales facilities and, whether or not it is still under guarantee, the instrument should be returned to the local Gould service centre or distributor through whom it was supplied for servicing if this is necessary. The type and serial number of the instrument should always be quoted, together with full details of any fault and service required.

Equipment returned for servicing must be adequately packed, preferably in the box in which the product was supplied and shipped, with transportation charges prepaid. We accept no responsibility for instruments arriving damaged.

Our Sales and Service Departments and those of approved distributors and agents are ready to assist you at all times.

The Gould Service Department and those of approved distributors and agents can provide maintenance and repair information by telephone or letter, if required.

PRINCIPAL GOULD SERVICE OFFICES

UNITED KINGDOM

Gould Instrument Systems Limited,
Roebuck Road, Hainault,
Ilford, Essex, IG6 3UE
Telephone (0181) 500 1000
Fax (081) 501 0116
Telex 263785

GERMANY

Gould Instrument Systems GmbH,
Waldstrasse 66, 63128 Dietzenbach.
Telephone (06074) 4908-0.
Fax (06074) 4908-48
Telex 4 197 644 Gould

ITALY

Gould Instrument Systems Filiale Italiana
Via Torino 25,
20063 Cernusco S/N (MI).
Telephone (02) 9210 7461
Fax (02) 9210 7456

FRANCE

Gould Instruments S.A.
57 Rue Saint Sauveur, Ballainvilliers,
91165 Longjumeau, Cédex
Telephone (1) 69 10 22 40.
Telex 600824 GOULD
Fax (1) 6934 2073

USA

Gould Instrument Systems, Inc.
8333, Rockside Road,
Valley View, OH. 44125-6104.
Telephone (216) 328 7000
Fax (216) 328 7400

	Contents
	Introduction
1	Getting Started
2	DSO Features
3	The Menus
4	Performance Checking
5	Waveform Processing
6	Alphabetical Summary
A1	Error Messages
A2	Specification
A3	Remote DC Operation
A4	RS423 to PC Interfacing
A5	Connector Pinouts
A6	Front and Back Pictures
	Service Facilities