


# Intermec EasyCoder 401 – Spare Parts & Options

## CPU-BOARD



Pos.	Part No.	Description	Remarks
–	<b>1-040700-90</b>	CPU-board assy	Includes these circuits:
IC 07	<b>1-989539-15</b>	IC-32CG16-15	
IC 402	<b>1-989495-10</b>	IC-HPC 46083-XXXV20YTM	
FY-300	<b>1-985157-25</b>	Fuse 6.3A 5x20 FST IEC (spare part)	Also available as spare part
		<b>Accessories</b> (not incl. in 1-040700-90):	
IC 100-101	<b>1-972xxx-xx</b>	Intermec Fingerprint firmware	Contact Intermec
IC 102-105	–	Application programs, fonts etc.	128 kbyte
IC 106-109	<b>1-989645-00</b>	IC-HN 628128 LP-10 RAM 1 Mb	Optional
IC 20	<b>1-989518-00</b>	IC-RTC72421 Clock circuit	Optional (for 20 mA CL)
IC 205-206	<b>1-985319-00</b>	IC-6N139 Optocoupler	Optional (for RS 422)
IC 207	<b>1-989744-00</b>	RS 422 Circuit	