



PC6 Reset	PC5 ADC5	28 DB7
PD0 RxD	PC4 ADC4	DB6
PD1 TxD	PC3 ADC3	DB5
PD2 INT0	PC2 ADC2	DB4
PD3 INT1	PC1 ADC1	E
PD4 T0	PC0 ADC0	RS
VCC	GND	
GND	AREF	
PB6 XTAL1	AVCC	
PB7 XTAL2	PB5 SCK	
PD5 T1	PB4 MISO	
PD6 AIN0	PB3 MOSI	A2
PD7 AIN1	PB2 OC1B	A1
PB0 ICP1	PB1 OC1A	A0

