



- X1 Digitaler Bildspeicher (Reserve)
- X2 Digitaler Bildspeicher
- X3 CPU
- X4 Bus-Steckplätze CPU (Reserve)
- X5 Bus-Steckplätze CPU (Reserve)
- X6 Video-Wandler
- X7 EDX-Inner face
- X8 Dig. Rastergenerator
- X9 Video-Wandler
- X10 Reserve
- X11 Overlay (Service)
- X12 V.24 A
- X13 V.24 B
- X14 V.24 A,B zur CPU
- X17 +5V
- X19 +15V
- X21 -15V
- X54 XY'INC'
- X55 Reset
- X58 +5V zur SYS
- X60 +15V zur SYS
- X62 -15V zur SYS

C1 - 30, R1 - 30, X56, F1
nicht bestückt

Hierzu: 34 83 32-9024 (1)
-7011.241 (4)