

Mode	S1	S2	S3	S4	Action
F1	0	0	0	0	Dispense as long as foot switch is pressed.
F2	1	0	1	1	Press foot switch once: dispense according to the preset time/interval. Stop: Press foot switch again.
F3	0	1	1	1	Dispense continuously after pressing foot switch. Stop: Press foot switch again.
F4	1	1	1	1	Automatically dispense according to timer settings. Foot switch not active.
F5	1	0	0	0	Press foot switch, dispense 1x according to the preset time/interval.
F6	0	1	0	0	Press foot switch, dispense out 2x according to the preset time/interval.
F7	1	1	0	0	As F6 but 3x
F8	0	0	1	0	As F6 but 4x
F9	1	0	1	0	As F6 but 5x
F10	0	1	1	0	As F6 but 6x
F11	1	1	1	0	As F6 but 7x
F12	0	0	0	1	As F6 but 8x
F13	1	0	0	1	As F6 but 9x
F14	0	1	0	1	As F6 but 10x
F15	1	1	0	1	As F6 but 11x
F16	0	0	1	1	As F6 but 12x