



Tabelle der Ausgangsfrequenzen

Angaben in Hz

Schalter			4	0	0	0	0	1	1	1	1
			5	0	0	1	1	0	0	1	1
1	2	3	6	0	1	0	1	0	1	0	1
0	0	0		60k	6,0k	600	60	6,0	0,6	0,06	0,006
0	0	1		6k	600	60	6	0,6	0,06	0,006	0,0006
0	1	0		30k	3,0k	300	30	3,0	0,3	0,03	0,003
0	1	1		20k*	2,0k	200	20	2,0	0,2	0,02	0,002
1	0	0		15k	1,5k	150	15	1,5	0,15	0,015	0,0015
1	0	1		12k**	1,2k	120	12	1,2	0,12	0,012	0,0012
1	1	0		10k	1,0k	100	10	1,0	0,1	0,01	0,001
1	1	1		5k	500	50	5	0,5	0,05	0,005	0,0005
0	0	0		100k	10k	1k	100	10	1	1/10	1/100
0	0	1		10k	1,0k	100	10	1	1/10	1/100	1/1000
0	1	0		50k	5,0k	500	50	5	1/2	1/20	1/200
0	1	1		33,3k*	3,3k	333,3	33,3	3,33	1/3	1/30	1/300
1	0	0		25k	2,5k	250	25	2,5	1/4	1/40	1/400
1	0	1		20k**	2,0k	200	20	2	1/5	1/50	1/500
1	1	0		16,6k	1,6k	166,6	16,6	1,6	1/6	1/60	1/600
1	1	1		8,3k	833,3	83,3	8,3	0,83	1/12	1/120	1/1200

* Duty 1/3 ** Duty 2/5