



- 1) ALL RESISTANCE VALUES ARE INDICATED IN "OHM" (1M = 1000K OHM , 1K = 1000 OHM)
 2) ALL CAPACITANCE VALUES ARE INDICATED IN "UF" (1u = .001 uF , 1p = .001 nF)
 3) 04, 024 : KTC3195 (T) . 012, 13, 20 : KTA1267 (T) . 015, 17, 28, 32 : KTC3198 (T) .
 05 TO 11, 14, 18, 19, 21, 22, 23, 25, 28, 27, 33, 34 : KTC3198 (T) . 016 : KTA1266 (T) .