

All connectors and sockets have
 Pin 1: - Minus, negative
 Pin 2: + Plus, positive
 GND: only aGND Solar Input

