

16Bit Pointer with max 256x256 resolution					Elements					
XML Name	box	label	button	gfx	list	checkbox	radiobutton	subwindow	window	shortcut
Byte	Box	Label	Button	GFX	List	Checkbox	Radiobutton	SubWindow	window	Shortcut
1	1	2	3	4	5	6	7	8	9	10
2	X pos	X pos	X pos	X pos	X pos	X pos	X pos	X pos	FocusPrevKey	ShortCutKey
3	Y pos	Y pos	Y pos	Y pos	Y pos	Y pos	Y pos	Y pos	FocusNextKey	Action NumberL
4	X size	Options	X size	X size	X size	X size	X size	X size	FocusEnterKey	Action NumberH
5	Y size	Text PointerL	Y size	Y size	Y size	Y size	Y size	Y size		Window JumpL
6	Options	Text PointerH	Options	Options	Options	Options	Options	Options	FocusPrevKey	Window JumpH
7	Action NumberL	Fonts	Action NumberL	Action NumberL	Action NumberL	Action NumberL	Action NumberL	Action NumberL	FocusNextKey	
8	Action NumberH		Action NumberH	Action NumberH	Action NumberH	Action NumberH	Action NumberH	Action NumberH	FocusEnterKey	
9	Window JumpL		Window JumpL	Window JumpL	Window JumpL	Window JumpL	Window JumpL	Window JumpL		
10	Window JumpH		Window JumpH	Window JumpH	Window JumpH	Window JumpH	Window JumpH	Window JumpH		
11	Color		Text PointerL	Gfx PointerL	Text PointerL	Text PointerL	Text PointerL	Text PointerL		
12			Text PointerH	Gfx PointerH	Text PointerH	Text PointerH	Text PointerH	Text PointerH		
13			Fonts		Fonts	Fonts	Fonts	Fonts		
14					ListNumber	CheckboxNumber	RadioButtonNumber			
15					DownKey					
16					UpKey					
17					PageDownKey					
18					PageUpKey					
19										
20										
21										
22										
23										
24										
Relevant Options:	Focusable	Storage Method	Focusable	Focusable	Focusable	Focusable	Focusable			
			Rectangle	Rectangle	Storage Method	Rectangle=0	Rectangle=0			
			Storage Method	Compressed		Storage Method	Storage Method			
				Storage Method						

Options: 1: Bit: Focusable, 2. Bit: Rectangle, 3: Bit: Compressed, 4: Bit: Storage Method  
Focusable: 0: No, 1:Yes  
Fonts: Low4Bit: Font without focus, High4Bit: Font with focus, a label uses all 8 bit for a single font  
Type: 0: Info, 1: Error, 2: Warning, 3: Yes/No question, 4: Yes/No/Abort question  
Storage Method: 0: Within Menu Data, 1: In pointer Array  
RadioButtonNumber: Low4Bit: Index in Table, High4Bit: Value within the Group

Required order of parameters, unused may be omitted:	If the object has an Action Number and screen jump, they all must start at the same offset (except for the shortcut) Then the options must start at the same address too
X pos	
Y pos	
X size	
Y size	
Options	Data format for GFX: Converting everything to one long array, beginning at the left top position, processing a line (and not column) first
Type	Uncompressed: One byte each 8 pixel, MSB is leftmost pixel, LSB is rightmost pixel
ShortCutKey	Compressed: MSB codes the color, reaming 7 bits say how often the color repeats
Action NumberL	
Action NumberH	
Window JumpL	Data format for text:
Window JumpH	Simple ASCII String must end with a \0 byte
Text/GFX PointerL	

Text/GFX PointerH
Fonts
Color
List/Checkbox/RadioButton Number
DownKey
UpKey
PageDownKey
PageUpKey
FocusPrevKey
FocusNextKey
FocusEnterKey

An Action code of 0xffff has the special meaning for returning from an SubWindow to a previous Window and restores the focus

The first drawn window must start at address 1 in the binary data, the byte at address 0 is ignored

If an object should not perform a window jump, all address bytes have to be set to zero

After a window or subwindow, the objects for the window have to follow, the order of the objects determines the drawing and tab order  
The objects for the window end, if a next window or subwindow or 0 byte as next object is found

24Bit Pointer	with max 256x256	resolution			Elements					
XML Name	box	label	button	gfx	list	checkbox	radiobutton	subwindow	window	shortcut
Byte	Box	Label	Button	GFX	List	Checkbox	Radiobutton	SubWindow	Screen	Shortcut
1	1	2	3	4	5	6	7	8	9	10
2	X pos	X pos	X pos	X pos	X pos	X pos	X pos	X pos	FocusPrevKey	ShortCutKey
3	Y pos	Y pos	Y pos	Y pos	Y pos	Y pos	Y pos	Y pos	FocusNextKey	Action NumberL
4	X size	Options	X size	X size	X size	X size	X size	X size	FocusEnterKey	Action NumberH
5	Y size	Text PointerL	Y size	Y size	Y size	Y size	Y size	Y size		Window JumpL
6	Options	Text PointerH	Options	Options	Options	Options	Options	FocusPrevKey		Window JumpH
7	Action NumberL	Text PointerHx	Action NumberL	Action NumberL	Action NumberL	Action NumberL	Action NumberL	FocusNextKey		Window JumpHx
8	Action NumberH	Fonts	Action NumberH	Action NumberH	Action NumberH	Action NumberH	Action NumberH	FocusEnterKey		
9	Window JumpL		Window JumpL	Window JumpL	Window JumpL	Window JumpL	Window JumpL			
10	Window JumpH		Window JumpH	Window JumpH	Window JumpH	Window JumpH	Window JumpH			
11	Window JumpHx		Window JumpHx	Window JumpHx	Window JumpHx	Window JumpHx	Window JumpHx			
12	Color		Text PointerL	Gfx PointerL	Text PointerL	Text PointerL	Text PointerL			
13			Text PointerH	Gfx PointerH	Text PointerH	Text PointerH	Text PointerH			
14			Text PointerHx	Gfx PointerHx	Text PointerHx	Text PointerHx	Text PointerHx			
15			Fonts		Fonts	Fonts	Fonts			
16					ListNumber	CheckboxNumber	RadioButtonNumber			
17					DownKey					
18					UpKey					
19					PageDownKey					
20					PageUpKey					
21										
22										
23										
24										