

K1-6 5V OUT ??
 K1-5 WW Hall Sensor IN
 K1-4 Tank 1 IN
 K1-3 Tank 2 IN
 K1-2 GND
 K1-1 12V

