






1 USB-C-Buchse




2 Boot/Reset




3 Pin-Header



4 FPC-Connect



5 Status-LED



Sheet: /
File: 3.0.kicad_sch

Title:

Size: A4	
KiCad E.D.A. 8.0.7	

Date:

Rev:
Id: 1/1