

PIC1
PIC18F4550-I/P
PIC2
PIC16F877A-I/P
IC1
MC34063
IC2
MCP41010
IC3A
IC3B
74LS07N
IC3C
IC3D
IC3E
IC3F
74LS07N
IC4A
IC4B
IC4C
IC4D
74HCT125N
IC5A
IC5B
IC5C
IC5D
74HC4066
IC6A
IC6B
IC6C
IC6D
74HC126N
74HC126N
T1
BC237
T2
BC327
T3
BC327
T4
BC327
D1
1N4148
D2
5.1V
Q1
20MHz
USB
Programmer
Jumper
Programmer-Debugger
Molex
ICSP-1
ICSP-2
ICSP-3
ICSP-4
ICSP-5
ICSP-6
* optional
VDD
GND
PSP[0..7]
1RA[0..7],1RC[0..7]