

# **C55/C55i**

## **Hardware description**



**Contents**

<b>0</b>	<b>INTRODUCTION .....</b>	<b>5</b>
0.1	GENERAL .....	5
0.2	THE DIFFERENCE BETWEEN C55 AND C55I MODULES .....	6
0.3	USED ABBREVIATIONS .....	6
0.4	RELATED DOCUMENTS .....	8
<b>1</b>	<b>SECURITY .....</b>	<b>9</b>
1.1	GENERAL INFORMATION .....	9
1.2	EXPOSURE TO RF ENERGY .....	9
1.3	EFFICIENT MODEM OPERATION .....	9
1.4	ANTENNA CARE AND REPLACEMENT .....	10
1.5	DRIVING .....	10
1.6	ELECTRONIC DEVICES .....	10
1.7	VEHICLE ELECTRONIC EQUIPMENT .....	10
1.8	MEDICAL ELECTRONIC EQUIPMENT .....	10
1.9	AIRCRAFT .....	10
1.10	CHILDREN .....	11
1.11	BLASTING AREAS .....	11
1.12	POTENTIALLY EXPLOSIVE ATMOSPHERES .....	11
1.13	NON-IONISING RADIATION .....	11
<b>2</b>	<b>SAFETY STANDARDS .....</b>	<b>12</b>
<b>3</b>	<b>TECHNICAL DATA .....</b>	<b>13</b>
3.1	TECHNICAL SPECIFICATIONS OF GSM/GPRS ENGINE .....	13
3.2	POWER CONSUMPTION FOR C55, ONLY .....	17
3.3	OPERATING TEMPERATURES .....	17
3.4	AIR INTERFACE OF THE C55 GSM/GPRS ENGINE, ONLY .....	18
<b>4</b>	<b>GSM/GPRS APPLICATION INTERFACE .....</b>	<b>19</b>
4.1	DESCRIPTION OF OPERATING MODES .....	19
4.1.1	Normal mode operation .....	19
4.1.2	Power down .....	20
4.1.3	Alarm mode .....	20
<b>5</b>	<b>HARDWARE INTERFACES .....</b>	<b>21</b>
5.1	INTERFACES ON THE C55/C55I .....	21
5.2	DESCRIPTION OF THE 40-PIN DOUBLE-ROW CONNECTOR .....	22
5.3	DETERMINING THE EXTERNAL EQUIPMENT TYPE .....	25
5.4	SPECIAL FUNCTIONALITY PINS .....	25
5.4.1	Power supply .....	25
5.4.2	Power supply pins (14...18) on the board-to-board connector .....	26
5.4.3	Enable pin (Pin 12) .....	26
5.4.4	Turn on the C55/C55i module using the SOFT_ON line (Power on) .....	27
5.4.5	Turn off the GSM/GPRS engine of C55/C55i module .....	27
5.4.6	Automatic shutdown .....	29
5.4.7	Features supported on the first and second serial interfaces of GSM/GPRS engine .....	30
5.4.8	SIM interface .....	30
5.5	RTC BACKUP FOR GSM/GPRS ENGINE OF C55/C55I .....	33
5.6	AUDIO INTERFACE .....	34
5.6.1	Microphone circuit .....	34
5.7	OUTPUTS .....	34
5.7.1	Synchronization signal .....	34
5.7.2	Using the SYNC pin to control a status LED .....	35
5.7.3	Behaviour of the RING_0 line (ASC0 interface) .....	36

5.8	AUTOMATIC GPRS MULTISLOT CLASS CHANGE .....	38
5.9	POWER SAVING .....	38
5.9.1	No power saving (AT+CFUN=1) .....	38
5.9.2	NON-CYCLIC SLEEP mode (AT+CFUN=0) .....	39
5.9.3	CYCLIC SLEEP mode (AT+CFUN=5, 6, 7, 8) .....	39
5.9.4	CYCLIC SLEEP mode AT+CFUN=9 .....	39
5.9.5	Timing of the CTS signal in CYCLIC SLEEP modes .....	40
5.9.6	Wake up C55/C55i from SLEEP mode .....	41
5.10	SUMMARY OF STATE TRANSITIONS (EXCEPT SLEEP MODE) .....	42
5.10.1	Summary of POWER DONE and Normal Mode .....	42
5.10.2	Summary of Alarm Mode .....	42
5.10.3	Resetting the GSM module by AT+CFUN=1,1 .....	43
5.11	GSM 07.05 AND 07.07 COMMANDS .....	43
<b>6</b>	<b>FIRST STEPS TO MAKE IT WORKS.....</b>	<b>44</b>
6.1	MINIMUM SET-UP CONNECTION .....	44
6.1.1	Mounting the C55/C55i .....	44
6.1.2	Antenna interface.....	44
6.1.3	SIM interface .....	45
6.1.4	Serial communication signals .....	45
6.1.5	Backup battery .....	46
6.1.6	Power supply .....	46
6.1.7	Turn on the GSM/GPRS engine of C55 .....	47
<b>7</b>	<b>HOUSING .....</b>	<b>48</b>
<b>8</b>	<b>EMC AND ESD REQUIREMENTS.....</b>	<b>49</b>
<b>9</b>	<b>GSM EVALUATION KIT (GSM EVAL-KIT) .....</b>	<b>50</b>

### Version history

Version number	Author	Changes
1.00	Fadil Beqiri	Initial version
1.02	Fadil Beqiri	The pin <a href="#">20</a> on the 40 pin connector updated.
1.02	Fadil Beqiri	Throughout the document the Soft_ON pin updated. Figure 4 updated, too.

## Cautions

**Information furnished herein by FALCOM is believed to be accurate and reliable. However, no responsibility is assumed for its use. Also the information contained herein is subject to change without notice.**

Please, read carefully the safety precautions.

If you have any technical questions regarding this document or the product described in it, please contact your vendor.

General information about FALCOM and its range of products is available at the following internet address: <http://www.falcom.de/>

## Trademarks

Some mentioned products are registered trademarks of their respective companies.

## Copyright

**The C55/C55i hardware description is copyrighted by FALCOM GmbH with all rights reserved. No part of this user's guide may be produced in any form without the prior written permission of FALCOM GmbH.**

## FALCOM GmbH.

No patent liability is assumed with respect to the use of the information contained herein.

## 0 Introduction

### 0.1 General

The C55/C55i is designed for use on any GSM network in the world. The C55/C55i is a tri-band GSM/GPRS engine that works on three frequencies GSM 900 MHz, DCS 1800 MHz and PCS 1900 MHz.

This full type approved integrated modem constitutes a self contained, fully integrated implementation of the GSM/GPRS. C55/C55i features GPRS class B, class 10 (making download at speeds up to 85 kbps) and supports the GPRS coding schemes CS-1, CS-2, CS-3 and CS-4.

The C55/C55i module incorporates all your needs to create high-performance GSM/GPRS solutions: base band processor, power supply ASIC, complete radio frequency circuit including a power amplifier, internal and external SIM interfaces, and an antenna interface as well.

The physical interface to the cellular application is made through a board-to-board connector. It consists of 40 pins, required for controlling the unit, transferring data and audio signals and providing power supply lines.

The external dual band or triple band antenna can directly be connected to the integrated 50  $\Omega$  connector on the side of module.

The C55/C55i is a mobile station for transmission of voice, data calls and FAX as well as short messages (SMS - Short Message Service) in GSM Network.

To control the GSM module there is an advanced set of AT commands according to GSM ETSI (European Telecommunications Standards Institute) 07.07 and 07.05 implemented.



Figure 1: Views of C55/C55i

Users are advised to proceed quickly to the „Security“ chapter and read the hints carefully.

## 0.2 The difference between C55 and C55i modules

**C55** The **C55** is a Tri-band device which operates on three frequencies GSM 900 MHz, DCS 1800 MHz and PCS 1900 MHz, and is available to use in the European and Asian Networks.

**C55i** The **C55i** is also a Tri-band device which operates on three frequencies GSM 900 MHz, DCS 1800 MHz and PCS 1900 MHz, and is available to use in the European and Asia Networks. The C55i provides a specific software and hardware (internal TCP/IP stack software with hardware extension) which has been internally implemented for using the embedded TCP/IP stack software. Regarding to the 40-pin board-to-board connector, the name of pin 20 (OUT 20) has to be changed to the BOOT pin that enables reprogramming of the extended internal *TCP/IP-module*.

The integration of TCP/IP stack with hardware extension (*a TCP/IP-module added*) into the equipment converts it to a stand-alone client that can be connected to the internet via GPRS network. The module can also send and receive data by GSM and GPRS network using TCP/IP stack. It supports SMS, DATA and FAX calls. The **C55i** module can be easily controlled by using TCP and AT commands. The "TCP Command Set" manual is also issued as separate document and is available on the distributed CD for the C55i's users.

Please note that, according to your requirement you can choose the desired device.

## 0.3 Used abbreviations

Abbreviation	Description
AD	Analogue/Digital
ADC	Analogue-to-Digital Converter
AFC	Automatic Frequency Control
AGC	Automatic Gain Control
AMP	Advanced Power Management
ANSI	American National Standards Institute
ARFCN	Absolute Radio Frequency Channel Number
ARP	Antenna Reference Point
ASC0	Asynchronous Controller. Abbreviations used for serial interface of C55
ASIC	Application Specific Integrated Circuit
B2B	Board-to-board connector
BER	Bit Error Rate
BTS	Base Transceiver Station
CB or CBM	Cell Broadcast Message
CE	Conformité Européene (European Conformity)
CHAP	Challenge Handshake Authentication Protocol
CPU	Central Processing Unit
CS	Coding Scheme
CSD	Circuit Switched Data

<b>Abbreviation</b>	<b>Description</b>
CTS	Clear to Send
DAC	Digital-to-Analogue Converter
dBW	Decibel per Watt
dBm0	Digital level, 3.14 dBm0 corresponds to full scale, see ITU G.711, A-law
DCE	Data Communication Equipment
DRX	Discontinuous Reception
DSP	Digital Signal Processor
DSR	Data Set Ready
DTE	Data Terminal Equipment (typically computer, terminal, printer or, for example, GSM application)
DTR	Data Terminal Ready
DTX	Discontinuous Transmission
EFR	Enhanced Full Rate
EGSM	Enhanced GSM
EMC	Electromagnetic Compatibility
ESD	Electrostatic Discharge
ETS	European Telecommunication Standard
FCC	Federal Communications Commission (U.S.)
FDMA	Frequency Division Multiple Access
FR	Full Rate
GMSK	Gaussian Minimum Shift Keying
GPRS	General Packet Radio Service
GSM	Global Standard for Mobile Communications
HiZ	High Impedance
HR	Half Rate
I/O	Input/Output
IC	Integrated Circuit
IF	Intermediate Frequency
IMEI	International Mobile Equipment Identity
ISO	International Standards Organization
ITU	International Telecommunications Union
kbps	kbits per second
LED	Light Emitting Diode
LNA	Low Noise Amplifier
Mbps	Mbits per second
MMI	Man Machine Interface
MO	Mobile Originated
MS	Mobile Station (GSM engine), also referred to as TE
MSISDN	Mobile Station International ISDN number
MSK	Minimum Shift Key
MT	Mobile Terminated
NC	Not Connected
PA	Power Amplifier
PAP	Password Authentication Protocol
PBCCH	Packet Switched Broadcast Control Channel
PCB	Printed Circuit Board
PCL	Power Control Level

Abbreviation	Description
PCM	Pulse Code Modulation
PCN	Personal Communications Network, also referred to as DCS 1800
PCS	Personal Communication System, also referred to as GSM 1900
PDU	Protocol Data Unit
PLL	Phase Locked Loop
PPP	Point-to-point protocol
PSU	Power Supply Unit
R&TTE	Radio and Telecommunication Terminal Equipment
RAM	Random Access Memory
RF	Radio Frequency
RMS	Root Mean Square (value)
ROM	Read-only Memory
RP	Receive Protocol
RTC	Real Time Clock
Rx	Receive Direction
SAR	Specific Absorption Rate
SELV	Safety Extra Low Voltage
SIM	Subscriber Identification Module
SMS	Short Message Service
SRAM	Static Random Access Memory
TA	Terminal adapter (e.g. GSM engine)
TDMA	Time Division Multiple Access
TE	Terminal Equipment, also referred to as DTE
Tx	Transmit Direction
UART	Universal asynchronous receiver-transmitter
URC	Unsolicited Result Code
USSD	Unstructured Supplementary Service Data
VSWR	Voltage Standing Wave Ratio
WAAS	Wide Area Augmentation System
FD	SIM fix dialing phonebook
LD	SIM last dialing phonebook (list of numbers most recently dialed)
MC	Mobile Equipment list of unanswered MT calls (missed calls)
ME	Mobile Equipment phonebook
ON	Own numbers (MSISDNs) stored on SIM or ME
RC	Mobile Equipment list of received calls
SM	SIM phonebook

Table 1: Used abbreviations

## 0.4 Related documents

1. ETSI GSM 07.05: "Use of Data Terminal Equipment-Data Circuit terminating Equipment interface for Short Message Service and Cell Broadcast Service"
2. ETSI GSM 07.07 "AT command set for GSM Mobile Equipment"
3. ITU-T V.25ter "Serial asynchronous automatic dialling and control"
4. C55/C55i AT Command Set
5. gprs\_startup\_user\_guide\_rev\_1.00\_preliminary
6. C55i TCP Command Set



# 1 Security

IMPORTANT FOR THE EFFICIENT AND SAFE OPERATION OF YOUR GSM MODEM, READ THIS INFORMATION BEFORE USE!

Your cellular engine C55/C55i is one of the most exciting and innovative electronic products ever developed. With it you can stay in contact with your office, your home, emergency services and others, wherever service is provided.

This chapter contains important information for the safe and reliable use of the C55/C55i. Please read this chapter carefully before starting to use the cellular engine C55/C55i.

## 1.1 General information

Your C55/C55i modem utilises the GSM standard for cellular technology. GSM is a newer radio frequency („RF“) technology than the current FM technology that has been used for radio communications for decades. The GSM standard has been established for use in the European community and elsewhere.

Your modem is actually a low power radio transmitter and receiver. It sends out and receives radio frequency energy. When you use your modem, the cellular system handling your calls controls both the radio frequency and the power level of your cellular modem.

## 1.2 Exposure to RF energy

There has been some public concern about possible health effects of using GSM modem. Although research on health effects from RF energy has focused for many years on the current RF technology, scientists have begun research regarding newer radio technologies, such as GSM. After existing research had been reviewed, and after compliance to all applicable safety standards had been tested, it has been concluded that the product is fit for use.

If you are concerned about exposure to RF energy there are things you can do to minimise exposure. Obviously, limiting the duration of your calls will reduce your exposure to RF energy. In addition, you can reduce RF exposure by operating your cellular modem efficiently by following the guidelines below.

## 1.3 Efficient modem operation

In order to operate your modem at the lowest power level, consistent with satisfactory call quality please take note of the following hints.

- If your modem has an extendible antenna, extend it fully. Some models allow you to place a call with the antenna retracted. However, your modem operates more efficiently with the antenna fully extended.
- Do not hold the antenna when the modem is „IN USE“. Holding the antenna affects call quality and may cause the modem to operate at a higher power level than needed.

## **1.4 Antenna care and replacement**

Do not use the modem with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Replace a damaged antenna immediately. Consult your manual to see if you may change the antenna yourself. If so, use only a manufacturer-approved antenna. Otherwise, have your antenna repaired by a qualified technician.

Use only the supplied or approved antenna. Unauthorised antennas, modifications or attachments could damage the modem and may contravene local RF emission regulations or invalidate type approval.

## **1.5 Driving**

Check the laws and regulations on the use of cellular devices in the area where you drive. Always obey them. Also, when using your modem while driving, please pay full attention to driving, pull off the road and park before making or answering a call if driving conditions so require. When applications are prepared for mobile use they should fulfil road-safety instructions of the current law!

## **1.6 Electronic devices**

Most electronic equipment, for example in hospitals and motor vehicles is shielded from RF energy. However, RF energy may affect some malfunctioning or improperly shielded electronic equipment.

## **1.7 Vehicle electronic equipment**

Check your vehicle manufacturer's representative to determine if any on board electronic equipment is adequately shielded from RF energy.

## **1.8 Medical electronic equipment**

Consult the manufacturer of any personal medical devices (such as pacemakers, hearing aids, etc.) to determine if they are adequately shielded from external RF energy.

Turn your C55/C55i modem OFF in health care facilities when any regulations posted in the area instruct you to do so. Hospitals or health care facilities may be using RF monitoring equipment.

## **1.9 Aircraft**

Turn your C55/C55i OFF before boarding any aircraft.

Use it on the ground only with crew permission.

Do not use it in the air.

To prevent possible interference with aircraft systems, Federal Aviation Administration (FAA) regulations require you to have permission from a crew member to use your modem while the plane is on the ground. To prevent interference with cellular systems, local RF regulations prohibit using your modem whilst airborne.

## **1.10 Children**

Do not allow children to play with your C55/C55i modem. It is not a toy. Children could hurt themselves or others (by poking themselves or others in the eye with the antenna, for example). Children could damage the modem or make calls that increase your modem bills.

## **1.11 Blasting areas**

To avoid interfering with blasting operations, turn your unit OFF when in a “blasting area” or in areas posted: „turn off two-way radio“. Construction crew often use remote control RF devices to set off explosives.

## **1.12 Potentially explosive atmospheres**

Turn your C55/C55i modem OFF when in any area with a potentially explosive atmosphere. It is rare, but your modem or its accessories could generate sparks. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include fuelling areas such as petrol stations; below decks on boats; fuel or chemical transfer or storage facilities; and areas where the air contains chemicals or particles, such as grain, dust or metal powders.

Do not transport or store flammable gas, liquid or explosives, in the compartment of your vehicle which contains your modem or accessories.

Before using your modem in a vehicle powered by liquefied petroleum gas (such as propane or butane) ensure that the vehicle complies with the relevant fire and safety regulations of the country in which the vehicle is to be used.

## **1.13 Non-ionising radiation**

As with other mobile radio transmitting equipment users are advised that for satisfactory operation and for the safety of personnel, it is recommended that no part of the human body be allowed to come too close to the antenna during operation of the equipment.

The radio equipment shall be connected to the antenna via a non-radiating 50 Ohm coaxial cable.

The antenna shall be mounted in such a position that no part of the human body will normally rest close to any part of the antenna. It is also recommended to use the equipment not close to medical devices as for example hearing aids and pacemakers.

## 2 Safety standards

This GSM modem complies with all applicable RF safety standards.

The embedded GMS modem meets the safety standards for RF receivers and the standards and recommendations for the protection of public exposure to RF electromagnetic energy established by government bodies and professional organisations, such as directives of the European Community, Directorate General V in matters of radio frequency electromagnetic energy.

## 3 Technical data

### 3.1 Technical specifications of GSM/GPRS engine

❖ *Power supply:*

- Supply voltage +5 V DC  $\pm 10\%$  (see chapter 3.2 for further details)

❖ *Power saving (GSM):*

- Minimizes power consumption in SLEEP mode to 13 mA

❖ *Temperature range:*

- Normal operation: -20 °C to +55 °C (see chapter 3.3 for further details)

❖ *Evaluation kit*

- The C55/C55i Evaluation Kit is designed to test and consider it as a Reference-Design for your HW-application, thus, you can save time and money. In this way you can reduce the Time-To-Market. (see chapter 9).

❖ *Physical characteristics:*

- Size:  $64.0 \pm 0.15$  mm x  $41.5 \pm 0.15$  mm x  $10.5 \pm 0.15$  mm (for more details see chapter 7 “Housing”)
- Weight:  $40 \pm 2$  g

❖ *C55i firmware upgrade*

- C55i firmware upgradeable over serial interface

❖ *Frequency bands:*

- Tri-band: EGSM 900, GSM 1800, GSM 1900
- Compliant to GSM Phase 2/2+

❖ *GSM class:*

- Small MS

❖ *Transmit power:*

- Class 4 (2 W) at EGSM900
- Class 1 (1 W) at GSM 1800 and GSM 1900

❖ *GPRS connectivity:*

- GPRS multi-slot class 10
- GPRS mobile station class B

❖ *DATA:*GPRS ⇒

- GPRS data downlink transfer: max. 85.6 kbps (see table 3).
- GPRS data uplink transfer: max. 42.8 kbps (see table 3).
- Coding scheme: CS-1, CS-2, CS-3 and CS-4.
- C55/C55i supports the two protocols PAP (Password Authentication Protocol) and CHAP (Challenge Handshake Authentication Protocol) commonly used for PPP connections.
- Support of Packet Switched Broadcast Control Channel (PBCCH) allows you to benefit from enhanced GPRS performance when offered by the network operators.

CSD ⇒

- CSD transmission rates: 2.4, 4.8, 9.6, 14.4 kbps, non-transparent, V.110.
- Unstructured Supplementary Services Data (USSD) support.

WAP ⇒

- WAP compliant.

❖ *SMS:*

- MT, MO, CB, Text and PDU mode
- SMS storage: SIM card plus 25 SMS locations in the mobile equipment
- Transmission of SMS alternatively over CSD or GPRS. Preferred mode can be user-defined.

❖ *MMS:*

- MMS compliant

❖ *FAX:*

- Group 3: class 1, class 2

❖ *SIM interface:*

- Supported SIM card: 3 V
- Integrated SIM card slot (for small SIM card, only)
- External SIM interface, which can be connected via provided pins on the 40-pin board-to-board connector (note that extra card reader is not part of C55/C55i)

❖ *Casing:*

- Fully shield

❖ ***Temperature control and auto switch-off:***

- Constant temperature control prevents damage to C55/C55i when the specified temperature is exceeded. When an emergency call is in progress the automatic temperature shutdown functionality is deactivated. (see chapter 3.3 for further details)

❖ ***External antenna:***

- Connected via 50 Ohm antenna connector.

❖ ***Audio interfaces:***

- An analogue audio interface

❖ ***Audio features:***

Speech code modes:

- Half Rate (ETS 06.20)
- Full Rate (ETS 06.10)
- Enhanced Full Rate (ETS 06.50/06.60/06.80)
- Adaptive Multi Rate (AMR)

Handsfree operation

- Echo cancellation
- Noise reduction

❖ ***One serial interface (ASC0):***

- 2.65V level, bi-directional bus for AT commands and data
- ASC0↔full-featured 8-wire serial interface. Supports RTS0/CTS0 hardware handshake and software XON/XOFF flow control. Multiplex ability according to GSM 07.10 Multiplexer Protocol.
- Baud rate: 300 bps ... 230 kbps on ASC0
- Autobauding detects 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400 bps

❖ ***Phonebook management:***

- Supported phonebook types: SM, FD, LD, MC, RC, ON, ME

❖ ***SIM Application Toolkit:***

- Supports SAT class 3, GSM 11.14 Release 98

❖ ***Ringing tones:***

- Offers a choice of 7 different ringing tones/melodies, easily selectable with AT command

❖ ***Real time clock:***

- Implemented

❖ **Timer function:**

- Programmable via AT command

❖ **Support of TTY/CTM:**

- To benefit from TTY communication via GSM, CTM equipment can be connected to one of the three audio interfaces.

❖ **Internal memory for C55i, only:**

- Combo-Memory (2 MB Flash–512 KB SRAM)

❖ **Software for C55i, only:**

- TCP/IP stack (Internet protocols stack which handles the Internet's link, network, transport and application layers). The embedded software interface that runs on C55i module for establishing an internet connectivity using IP commands. TCP/IP software description is also available, see related documents [6].

Coding scheme	1 Timeslot	2 Timeslots	4 Timeslots
CS-1:	9.05 kbps	18.1 kbps	36.2 kbps
CS-2:	13.4 kbps	26.8 kbps	53.6 kbps
CS-3:	15.6 kbps	31.2 kbps	62.4 kbps
CS-4:	21.4 kbps	42.8 kbps	85.6 kbps

**Table 2:** Coding schemes and maximum net data rates over air interface

Please note that the values listed above are the maximum ratings which, in practice, are influenced by a great variety of factors, primarily, for example, traffic variations and network coverage.



### 3.2 Power consumption for C55, only

POWER CONSUMPTION (using the GSM Eval-Board)					
	Min	Typ.	Max	Unit	Description
GSM/GPRS engine					
Supply voltage	4.7	5	5.2	V	Voltage must stay within the min/max values, including voltage drop, ripple and spikes.
Average supply current					
		60	110	μA	POWER DOWN mode
		9		mA	SLEEP mode @ DRX = 6
GSM					<b>MODE</b>
					<b>BAND (XF55, only)</b>
		15		mA	IDLE mode
		15			EGSM 900
		250			GSM 1800/1900
		170		mA	TALK mode
GPRS					EGSM 900 <sup>*)</sup>
					GSM 1800/1900 <sup>**)</sup>
		15		mA	IDLE GPRS
		15			EGSM 900
		290			GSM 1800/1900
		220		mA	DATA mode GPRS, (4 Rx, 1 Tx)
					EGSM 900 <sup>*)</sup>
					GSM 1800/1900 <sup>**)</sup>
		440		mA	DATA mode GPRS, (3 Rx, 2 Tx)
					EGSM 900 <sup>*)</sup>
					GSM 1800/1900 <sup>**)</sup>
<b>Peak</b> supply current.		1,6		A	Power control level <sup>*)</sup> During transmission slot every 4.6 ms.

**Table 3:** Power supply

- <sup>\*)</sup> Power Control Level (PCL 5).  
<sup>\*\*)</sup> Power Control Level (PCL 0).

### 3.3 Operating temperatures

Parameter	Min	Typ.	Max	Unit
Ambient temperature (according to GSM 11.10)	-20	25	50	°C
Restricted operation <sup>*)</sup>	-25 to -20		55 to 70	°C
Automatic shutdown C55/C55i board temperature	-29 °C		>70 °C	°C

**Table 4:** Operating temperature

- <sup>\*)</sup> C55/C55i works, but deviations from the GSM specification may occur.

### 3.4 Air interface of the C55 GSM/GPRS engine, only

Test conditions:

All measurements have been performed at  $T_{amb} = 25\text{ }^{\circ}\text{C}$ ,  $V_{VC5\text{ typ.}} = 5\text{ V}$ .

Parameter		Min	Typ.	Max	Unit
Frequency range Uplink (MS $\rightarrow$ BTS)	GSM 900	880		915	MHz
	GSM 1800	1710		1785	MHz
Frequency range Downlink (BTS $\rightarrow$ MS)	GSM 1900	1850		1910	MHz
	GSM 900	925		960	MHz
	GSM 1800	1805		1880	MHz
	GSM 1900	1930		1990	MHz
RF power @ ARP with 50 $\Omega$ load	GSM 900	31	33	35	dBm
	GSM 1800	28	30	32	dBm
	GSM 1900	28	30	32	dBm
Number of carriers	GSM 900		174		
	GSM 1800		374		
	GSM 1900		299		dBm
Duplex spacing	GSM 900		45		MHz
	GSM 1800		95		MHz
	GSM 1900		80		MHz
Carrier spacing			200		kHz
Multiplex, Duplex		TDMA/FTDMA, FDD			
Time slots per TDMA frame			8		
Frame duration			4.615		ms
Time slot duration			577		$\mu\text{s}$
Modulation		GMSK			
Receiver input sensitivity @ ARP	GSM 900	-102	-107		dBm
	GSM 1800	-102	-106		dBm
BER Class II < 2.4 %	GSM 1900	-102	-105.5		dBm

**Table 5:** Air Interface

## 4 GSM/GPRS application interface

### 4.1 Description of operating modes

The chapter below briefly summarizes the various operating modes referred to in the following chapters.

#### **Definition of the GPRS class B mode of operation:**

The definition of GPRS class B mode is, that the MS can be attached to both GPRS and other GSM services, but the MS can only operate one set of services at a time. Class B enables making or receiving a voice call, or sending/receiving a SMS during a GPRS connection. During voice calls or SMS, GPRS services are suspended and then resumed automatically after the call or SMS session has ended.

#### **4.1.1 Normal mode operation**

##### ***4.1.1.1 GSM/GPRS SLEEP***

Various power save modes set with AT+CFUN command. Software is active to minimum extent. If the module was registered to the GSM network in IDLE mode, it is registered and paging with the BTS in SLEEP mode, too. Power saving can be chosen at different levels: The NON-CYCLIC SLEEP mode (AT+CFUN=0) disables the AT interface. The CYCLIC SLEEP modes AT+CFUN=5, 6, 7, 8 and 9 alternatively activate and deactivate the AT interfaces to allow permanent access to all AT commands.

##### ***4.1.1.2 GSM IDLE***

Software is active. Once registered to the GSM network, paging with BTS is carried out. The module is ready to send and receive.

##### ***4.1.1.3 GSM TALK***

Connection between two subscribers is in progress. Power consumption depends on network coverage individual settings, such as DTX off/on, FR/EFR/HR, hopping sequences, antenna.

##### ***4.1.1.4 GPRS IDLE***

Module is ready for GPRS data transfer, but no data is currently sent or received. Power consumption depends on network settings and GPRS configuration (e.g. multislots settings).

##### ***4.1.1.5 GPRS DATA***

GPRS data transfer in progress. Power consumption depends on network settings (e.g. power control level), uplink/downlink data rates and GPRS configuration (e.g. used multislots settings).

#### **4.1.2 Power down**

Normal shutdown after sending the AT^SMSO command. The Power Supply ASIC (PSU-ASIC) disconnects the supply voltage from the base band part of the circuit. Only a voltage regulator in the PSU-ASIC is active for powering the RTC. Software is not active. The serial interfaces are not accessible. Operating voltage (connected to VC5) remains applied.


#### **4.1.3 Alarm mode**

Alarm mode restricted operation launched by RTC alert function while the module is in POWER DOWN mode. Module will not be registered to GSM network. Limited number of AT commands is accessible.

## 5 Hardware interfaces

### 5.1 Interfaces on the C55/C55i

In figure 2 the interfaces of the C55/C55i module are to be seen



**Figure 2:** Provided interfaces on the C55/C55i module

Interface specifications	
Interface A	40-pin connector Tyco (AMP) 2-0177986-1 <sup>2)</sup>
Interface B	GSM 50 $\Omega$ , MC-Card (Radiall)
Interface C	card reader for small SIM cards (3 V)
Interface D	<p>holes for fixing after mounting</p> <p>recommended screws: 2,2 x 16 mm</p> <p>The screw could be longer and it depends on the customer's application.</p>

**Table 6:** Interface specifications

<sup>2)</sup> 40-pin connector Tyco (AMP) 2-0177986-1

Counterpart for application<sup>3)</sup>:

CON 100	5-179010-1 (13 mm height)
CON 101	5-177985-1 (Standard 5 mm height)
CON 102	5-179180-1 (9 mm height)


<sup>3)</sup> The module C55/C55i is for flat mounting and the space between the highest point of the module and its bottom is 1,5 mm.

## 5.2 Description of the 40-pin double-row connector

Please note that the reference voltages listed in table 7 are the values measured directly on the C55/C55i module. C55/C55i module is equipped with a 40-pin board-to-board connector that connects to the cellular application platform.

The Tyco (AMP) board-to-board connector is a 40-pin double-row receptacle. Names and the positions of the pins can be seen from figure 3 below which shows the bottom view of C55/C55i.

This interface incorporates several sub-interfaces described in chapters below. To avoid any mistake on structured table below, note that, all sub-interfaces included on the board-to-board connector are grouped, sequencing is not taken into account.



**Figure 3:** Pin assignment on the 40-pin connector (bottom view on C55/C55i)

PIN	GSM modem	I/O	DESCRIPTION	LEVEL
5	SIMGND	-	<b><u>SIM interface</u></b>  SIMPRES = high, SIM card holder closed (no card recognition) Maximum cable length 200 mm to SIM card holder. All signals of SIM interface are protected against ESD with a special diode array. Usage of SIMGND is mandatory.	0 V (Ground)
19	SIMPRES	I		$V_{ILmax} = 0.5 \text{ V}$ $V_{IHmin} = 2.15 \text{ V}$ at $I = 20 \mu\text{A}$ , $V_{IHmax} = 3.3 \text{ V}$ at $I = 30 \mu\text{A}$
1	SIMRST	O		$V_{OLmax} = 0.25 \text{ V}$ at $I = 1 \text{ mA}$ $V_{OHmin} = 2.3 \text{ V}$ at $I = -1 \text{ mA}$ $V_{OHmax} = 2.73 \text{ V}$
3	SIMDATA	I/O		$V_{ILmax} = 0.5 \text{ V}$ $V_{IHmin} = 1.95 \text{ V}$ , $V_{IHmax} = 3.3 \text{ V}$ $V_{OLmax} = 0.4 \text{ V}$ at $I = 1 \text{ mA}$ $V_{OHmin} = 2.15 \text{ V}$ at $I = -1 \text{ mA}$ $V_{OHmin} = 2.55 \text{ V}$ at $I = -20 \mu\text{A}$ $V_{OHmax} = 2.96 \text{ V}$
2	SIMCLK	O		$V_{OLmax} = 0.4 \text{ V}$ at $I = 1 \text{ mA}$ $V_{OHmin} = 2.15 \text{ V}$ at $I = -1 \text{ mA}$ $V_{OHmax} = 2.73 \text{ V}$

4	SIMVCC	O		$\text{SIMVCC}_{\text{max}} = 2.96 \text{ V}$ $I_{\text{max}} = -20\text{mA}$
6	GND	-	Negative operating voltage (grounds).	0 V
7				
8				
9				
10				
11	OUT11	-	NC	--
12	ENABLE	I	Internal power enable (HIGH=enable)	$V_{\text{OFFmin}} = 0 \text{ V}$ , $V_{\text{OFFmax}} = 0.4 \text{ V}$ . $V_{\text{Onmin}} = 2 \text{ V}$ , $V_{\text{Onmax}} = 5 \text{ V}$ .
13	SYNC	O	Indicates increased current consumption during uplink transmission burst. Note that timing is different during handover. Alternatively used to control status LED (see chapter 5.7.2). If not used leave it open.	$V_{\text{OLmax}} = 0.2 \text{ V}$ at $I = 1\text{mA}$ $V_{\text{OHmin}} = 2.35\text{V}$ at $I = -1\text{mA}$ $V_{\text{OHmax}} = 2.73 \text{ V}$ 1 Tx, 877 $\mu\text{s}$ impulse each 4.616 ms and 2 Tx, 1454 $\mu\text{s}$ impulse each 4.616 ms, with 300 $\mu\text{s}$ forward time.
14	VC5	I	Power supply input. 5 VC5 pins to be connected in parallel. 5 GND pins to be connected in parallel. The power supply must be able to meet the requirements of current consumption in a Tx burst (up to 2 A). Sending with two timeslots doubles the duration of current pulses to 1154 $\mu\text{s}$ (every 4.616 ms)!	$V_I = +5 \text{ V} \pm 10 \%$ $I_{\text{max}} < 2 \text{ A}$ (during Tx burst) 1 x Tx, peak current 577 $\mu\text{s}$ every 4.616 ms 2 x Tx, peak current 1154 $\mu\text{s}$ every 4.616 ms
15				
16				
17				
18				
20	OUT20*	-	NC	--
21	OUT21			
22	OUT22			
23	OUT23			


25	OUT25	-	NC	--
30	OUT30			
24	VCCRTC	I/O	Supplies the RTC with power via an external capacitor or buffer battery if no VC5 is applied. If not used leave it open.	$R_I = 1\text{ k}\Omega$ $V_{Omax} = 4.0\text{ V}$ (output) $V_{Imin} = 2.2\text{ V}$ , $V_{Imax} = 5.5\text{ V}$ (input) $I_{Ityp} = 10\text{ }\mu\text{A}$ at $VC5+ = 0\text{ V}$ Mobile in POWER DOWN mode: $V_{Imin} = 1.2\text{ V}$
26	RESET		Reset - active Low (see next chapter)	SCHMITT input $V_{RESET} = 0\text{ V}$
29	SOFT-ON	I	Input to switch the module ON. The line must be SET to HIGH for $\geq 100\text{ ms}$ and not earlier than 1 second after system is powered on.	$V_{Openmin} = 2.5\text{ V}$ $V_{Openmax} = VC5$ ON  Active HIGH $\geq 100\text{ ms}$
27	RX_O	O	The serial interface (ASC0) for AT commands or data stream. To avoid floating if output pins are high-impedance, use pull-up resistors tied to external power source ( $V_{min} < 2.2$ and $V_{max} = 3.3\text{ V}$ , $I_{max} = 10\text{ mA}$ ) or pull-down resistors tied to GND. See chapter 5.4.5.1. If not used leave it open.	$V_{OLmax} = 0.2\text{ V}$ at $I = 1\text{ mA}$ $V_{OHmin} = 2.35\text{ V}$ at $I = -1\text{ mA}$ $V_{OHmax} = 2.73\text{ V}$ $V_{ILmax} = 0.5\text{ V}$ $V_{IHmin} = 1.95\text{ V}$ , $V_{Ihmax} = 3.3\text{ V}$ DTR_0, RTS_0: $I_{max} = -90\text{ }\mu\text{A}$ at $V_{IN} = 0\text{ V}$ TX_0: $I_{max} = -30\text{ }\mu\text{A}$ at $V_{IN} = 0\text{ V}$
28	TX_O	I		
31	RING_O	O		
32	DCD_O	O		
33	DSR_O	O		
34	RTS_O	I		
35	DTR_O	I		
36	CTS_O	O		
37	SPK1P	O(+)	Analogue audio interfaces balanced audio output. Can be used to directly operate an earpiece. If not used leave it open.	$V_{Omax} = 1.3\text{ Vpp}$
38	SPK1N	O(-)		
39	MIC1P	I(+)	Balanced microphone input. Can be used to directly feed an active microphone. If not used leave it open.	$R_I \approx 50\text{ k}\Omega$ differential $V_{Imax} = 20\text{ mVpp}$
40	MIC1N	I(-)		

Table 7: Description of the 40-pin connector (interface A)

\* Using the C55i module the name of this pin is “BOOT”, and it can be used for reprogramming of the internal Flash (TCP/IP-module) of the C55i module. Set this pin the GND (0V) to update the firmware.



### 5.3 Determining the External Equipment Type

Before you connect the provided serial port on the C55/C55i board-to-board connectors to external host application, you need to determine if its external hardware serial ports are configured as DTE or DCE.

The terms DTE (Data Terminal Equipment) and DCE (Data Communications Equipment) are typically used to describe serial ports on devices. Computers (PCs) generally use DTE connectors and communication devices such as modems and DSU/CSU devices generally use DCE connectors. As a general rule, DTE ports connect to DCE ports via straight through pinned cables. In other words, a DTE port never connects directly to another DTE port. In a similar manner, a DCE port never connects directly to another DCE port. The signalling definitions were written from the perspective of the DTE device; therefore, a Receive Data signal becomes an input to DTE but an output from DCE.

The C55/C55i is designed for use as a DCE. Based on the aforementioned conventions for DCE-DTE connections it communicates with the customer application (DTE) using the following signals:

C55/C55i (DCE)	to	Application (DTE)
TX_0	◀-----	TXD
RX_0	-----▶	RXD
RTS_0	◀-----	RTS
CTS_0	-----▶	CTS
DTR_0	◀-----	DTR
DSR_0	-----▶	DSR
DCD_0	-----▶	DCD
RING_0	-----▶	RING

**Table 8:** Definitions between DTE and DCE ports.

### 5.4 Special functionality pins

#### 5.4.1 Power supply

The power supply for the GSM/GPRS engine of the C55/C55i module has to be a single voltage source of  $V_{VC5+} = 4.5 \dots 5.5$  V. It must be able to provide sufficient current in a transmit burst which typically rises to 1.6 A.

All the key functions for supplying power to the device are handled by an ASIC power supply. The ASIC0 provides the following features:

- ❖ Stabilizes the supply voltages for the GSM base band using low drop linear voltage regulators.
- ❖ Controls the module's power up and power down procedures.

- ❖ A watchdog logic implemented in the base band processor periodically sends signals to the ASIC, allowing it to maintain the supply voltage for all digital C55/C55i components. Whenever the watchdog pulses fail to arrive constantly, the module is turned off.

#### 5.4.2 Power supply pins (14...18) on the board-to-board connector

Five VC5 pins of the board-to-board connector are dedicated to connect the supply voltage, five GND pins are recommended for grounding.


The values stated below are measured directly at the reference points on the C55/C55i board.

The VCCRTC pin can be used to back up the RTC.

Signal name	I/O	Parameter	Description
VC5+	I	4.5 V...5,5 V, $I_{typ} \leq 1.6$ A during transmit burst. The minimum operating voltage must not fall below 4.5 V, not even in case of voltage drop.	Positive operating voltage.
GND	-	0 V	Ground
VCCRTC	I/O	$U_{OUT,max} < V_{VC5}$ $U_{IN} = 2.0$ V...5.5 V $R_i = 1$ k $\Omega$ $I_{in,max} = 30$ $\mu$ A	Can be used to back up the RTC when $V_{VC5}$ is not applied.

**Table 9:** Pin description of 40-pin board-to-board connector (secondary application interface)

In order to connect the VC5 pin on the board-to-board to the external power source (+5 VDC), the circuit below has to be externally implemented on the user application platform.



#### 5.4.3 Enable pin (Pin 12)

The enable signal is an input for the internal voltage regulator. The internal regulator comes with an active-high enable pin that allows it to be disabled while voltage  $V_{VC5+}$  is permanently applied to the module. This pin is CMOS input level.


- Forcing the Enable pin to LOW disables the regulator and sends the C55/C55i module into an off-mode state. The off-mode state takes effect as long as the Enable pin is forced to the LOW. The GSM engine will automatically be logged-off from the registered network. The serial interface is momentarily not accessible. Forcing the Enable pin back to HIGH while voltage  $V_{VC5+}$  is permanently applied to the

module, enables the output voltage. Then the module will be turned on after the SOFT\_ON pin is also set to HIGH level for at least 100 ms and not earlier than 1 second after system is powered on.

- If not used leave the enable signal open.

#### 5.4.4 Turn on the C55/C55i module using the SOFT\_ON line (Power on)

To switch on the C55/C55i module the SOFT\_ON signal needs to be set to HIGH level for at least 100 ms and not earlier than 1 second after system is powered on.



**Figure 4:** Power-on by Soft\_on signal

If the module is configured to a fix baud rate, the GSM/GPRS engine of the C55/C55i will send the result code ^SYSSTART to indicate that it is ready to operate. This result code does not appear when autobauding is active.

Ensure that  $V_{VC5}$  does not fall below 4,7 V while the SOFT\_ON line is driven. Otherwise the module cannot be activated.

- To switch on the C55/C55i module the SOFT\_ON signal needs to be set to HIGH level for at least 100 ms and not earlier than 1 second after system is powered on.
- For switching the module off refer to the next section 5.4.5.

It is not recommended to switch the module on and off by means of the power supply (e.g. by tying the SOFT\_ON constantly to HIGH). The module will so have no possibility to log-off correctly from the network and this will cause problems at the next attempt to register.

#### 5.4.5 Turn off the GSM/GPRS engine of C55/C55i module

To switch the module off the following procedures may be used:

- ❖ Normal shutdown procedure: Software controlled by sending the AT^SMSO command over the serial application interface. See chapter 5.4.5.1.

- ❖ *Emergency shutdown*: Hardware driven by switching the RESET line (Pin 26) of the board-to-board connector to ground = immediate shutdown of supply voltages.
- ❖ *Automatic shutdown*: See chapter 5.4.6
  - a) Takes effect if under voltage is detected.
  - b) Takes effect if C55/C55i board temperature exceeds critical limit.

#### 5.4.5.1 Turn off GSM/GPRS engine of the C55/C55i module using AT command

The best and safest approach to powering down the C55/C55i GSM/GPRS engine is to issue the AT^SMSO command. This procedure lets GSM engine log off from the network and allows the software to enter into a secure state and save data before disconnecting the power supply. The mode is referred to as POWER DOWN mode. In this mode, only the RTC stays active.

Before switching off the device sends the following response:

```
^SMSO: MS OFF
```

```
OK
```

```
^SHUTDOWN
```

After sending AT^SMSO do not enter any other AT commands. There are two ways to verify when the module turns off:

- ❖ Wait for the URC “SHUTDOWN”. It indicates that data have been stored non-volatile and the module turns off in less than 1 second.

Be sure not to disconnect the operating voltage  $V_{VC5+}$  before the URC “SHUTDOWN” has been issued. Otherwise you run the risk of losing data.

While the GSM engine is in POWER DOWN mode the application interface is switched off and must not be fed from any other source. Therefore, your application must be designed to avoid any current flow into any digital pins of the application interface.

**Note:** In POWER DOWN mode, the output pins of the ASC0 interface RX\_0, CTS\_0, DCD\_0, DSR\_0, RING\_0 are switched to high impedance state.

If this causes the associated input pins of your application to float, you are advised to integrate an additional resistor (100 k $\Omega$ , 1 M $\Omega$ ) at each line. In the case of the serial interface pins you can either connect pull-up resistors to an external power source ( $V_{min} < 2.2$  and  $V_{max} = 3.3$  V,  $I_{max} = 10$  mA), or pull down resistors to GND.

#### 5.4.5.2 Maximum number of turn-on/turn-off cycles

Each time the module is shut down, data will be written from volatile memory to flash memory. The guaranteed maximum number of write cycles is limited to 100.000.

#### 5.4.5.3 Emergency shutdown using RESET line


**!!!Caution:** Use the RESET pin only when, due to serious problems, the software is not responding for more than 5 seconds. Pulling the RESET pin causes the loss of all information stored in the volatile memory since power is cut off immediately. Therefore, this

*procedure is intended only for use in case of emergency, e.g. if C55/C55i fails to shut down properly.*

The RESET signal is available on the board-to-board connectors. To turn the GSM engine off, the RESET line has to be driven to ground for  $\geq 3.2$  s.

#### 5.4.5.3.1 How does it work?

- Voltage  $V_{VC5+}$  is permanently applied to the module.
- The module is active while the internal reset signal is kept at high level. During operation of C55/C55i the base band controller generates watchdog pulses at regular intervals. Once the RESET pin is grounded these watchdog pulses are cut off from the power supply ASIC. The power supply ASIC shuts down the internal supply voltages of C55/C55i after max. 3.2 s and the module turns off.



**Figure 5:** Deactivating GSM engine by RESET signal

### 5.4.6 Automatic shutdown

Automatic shutdown takes effect if

- ❖ the C55/C55i board is exceeding the critical limits of over temperature or under temperature.
- ❖ under voltage is detected.

The automatic shutdown procedure is equivalent to the power-down initiated with the `AT^SMSO` command, i.e. C55/C55i logs off from the network and the software enters a secure state avoiding loss of data.

**NOTE:** This does not apply if over voltage conditions or unrecoverable hardware or software errors occur (see below for details).

Alert messages transmitted before the device switches off are implemented as Unsolicited Result Codes (URCs).

#### 5.4.6.1 *Temperature control during emergency call*

If the temperature limit is exceeded while an emergency call is in progress the engine continues to measure the temperature, but deactivates the shutdown functionality. If the temperature is still out of range when the call ends, the module switches off immediately (without another alert message).

#### 5.4.6.2 *Over voltage shutdown*

For over voltage conditions, no software controlled shutdown is implemented. If the supply voltage exceeds the maximum value specified in [Table 4](#), loss of data and even unrecoverable hardware damage can occur.

Keep in mind that several C55/C55i components are directly linked to VC5+ and, therefore, the supply voltage remains applied at major parts of C55. Especially the power amplifier is very sensitive to high voltage and might even be destroyed.

#### 5.4.7 Features supported on the first and second serial interfaces of GSM/GPRS engine

The GSM/GPRS engine of the C55/C55i module offers an unbalanced, asynchronous serial interfaces conforming to ITU-T V.24 protocol DCE signaling. The electrical characteristics do not comply with ITU-T V.28. The significant levels are 0 V (for low data bit or ON condition) and 2.65 V (for high data bit or OFF condition). See chapter [5.3](#) to determinate the DTE-DCE connection.

##### ASC0:

- ↔ 8-wire serial interface
- ↔ Includes the data lines TX\_0 and RX\_0, the status lines RTS\_0 and CTS\_0 and, in addition, the modem control lines DTR\_0, GSM\_DSR0, DCD\_0 and RING\_0.
- ↔ It is designed for voice calls, CSD calls, fax calls and GPRS services and for controlling the GSM engine with AT commands. Full Multiplex capability allows the interface to be partitioned into three virtual channels, yet with CSD and fax services only available on the first logical channel.
- ↔ The DTR\_0 signal will only be polled once per second from the internal firmware of C55/C55i.
- ↔ The RING\_0 signal serves to indicate incoming calls and other types of URCs (Unsolicited Result Code). It can also be used to send pulses to the host application, for example to wake up the application from power saving state. For further details see chapter 4.9.2.3.
- ↔ Autobauding is selectable on this interface and supports the following bit rates: 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400 bps.
- ↔ ASC0 interface is intended for firmware upgrade of the GSM/GPRS engine.
- ↔ This interface is configured for 8 data bits, no parity and 1 stop bit, and can be operated at bit rates from 300 bps to 230400 bps.
- ↔ XON/XOFF software flow control can be used on this interfaces (except if power saving is active).

#### 5.4.8 SIM interface

The C55/C55i module includes two SIM interfaces which could not concurrently be used:

- an integrated SIM card holder, part of C55/C55i module, for small SIM cards (only 3 V).
- and an integrated 6-pin interface on board-to-board connector for user application. This SIM circuit can be implemented outside the module on the application platform. See section “SIM Interface on board-to-board connector”.

#### 5.4.8.1 SIM Interface on board-to-board connector

The base band processor has an integrated SIM interface compatible with the ISO 7816 IC card standard. This is wired to the host interface (board-to-board connector) in order to be connected to an external SIM card holder. Six pins on the board-to-board connector are reserved for the SIM interface. The SIMPRES pin serves to detect whether a tray (with SIM card) is present in the card holder. Using the SIMPRES pin is mandatory for compliance with the GSM 11.11 recommendation if the mechanical design of the host application allows the user to remove the SIM card during operation. See chapter 5.4.8.2 for details. It is recommended that the total cable length between the board-to-board connector pins on C55/C55i and the pins of the SIM card holder does not exceed 200 mm in order to meet the specifications of 3GPP TS 51.010-1 and to satisfy the requirements of EMC compliance.

Signal	Description
SIMGND	Separate ground connection for SIM card to improve EMC.
SIMCLK	Chip card clock, various clock rates can be set in the base band processor.
SIMVCC	SIM supply voltage from PSU-ASIC
SIMDATA	Serial data line, input and output.
SIMRST	Chip card reset, provided by base band processor.
SIMPRES	Input on the base band processor for detecting a SIM card tray in the holder. The SIMPRES pin is mandatory for applications that allow the user to remove the SIM card during operation. The SIMPRES pin is solely intended for use with a SIM card. It must not be used for any other purposes. Failure to comply with this requirement may invalidate the type approval of C55/C55i.

**Table 10:** Signals of the SIM interface (board-to-board connector)

#### 5.4.8.2 Requirements for using the SIMPRES pin

According to ISO/IEC 7816-3 the SIM interface must be immediately shut down once the SIM card is removed during operation. Therefore, the signal at the SIMPRES pin must go low *before* the SIM card contacts are mechanically detached from the SIM interface contacts. This shut-down procedure is particularly required to protect the SIM card as well as the SIM interface of C55/C55i from damage. An appropriate SIM card detect switch is required on the card holder. For example, this is true for the model supplied by Molex, which has been tested to operate with C55/C55i and is part of the FALCOM reference equipment submitted for type approval. Molex ordering number is 91228-0001.

The start-up procedure of module involves a SIM card initialization performed within 1 second after getting started. An important issue is whether the initialization procedure ends up with a high or low level of the SIMPRES signal:

- a) If, during start-up of C55/C55i, the SIMPRES signal on the SIM interface is high, then the status of the SIM card holder can be recognized each time the card is inserted or ejected. A low level of SIMPRES indicates that no SIM card tray is inserted into the holder. In this case, the module keeps searching, at regular intervals, for the SIM card. Once the SIM card tray with a SIM card is inserted, SIMPRES is taken high again.
- b) If, during start-up of C55/C55i, the SIMPRES signal is low, the module will also attempt to initialize the SIM card. In this case, the initialization will only be successful when the card is present. If the SIM card initialization has been done, but the card is no more operational or removed, then the module will never search again for a SIM card and only emergency calls can be made. Removing and inserting the SIM card during operation requires the software to be reinitialized. Therefore, after reinserting the SIM card it is necessary to restart C55/C55i. It is strongly recommended to connect the contacts of the SIM card detect switch to the SIMPRES input and to the SIMVCC output of the module as illustrated in the sample diagram in figure 6 below.

**Note:** No guarantee can be given, nor any liability accepted, if loss of data is encountered after removing the SIM card during operation. Also, no guarantee can be given for properly initializing any SIM card that the user inserts after having removed a SIM card during operation. In this case, the application must restart C55/C55i.

#### 5.4.8.3 Design considerations for SIM card holder

The schematic below is a sample configuration that illustrates the Molex SIM card holder. X503 is the designation used for the SIM card holder.




Figure 6: SIM card holder


Pin	Signal name	I/O	Function
1	SIMVCC	I	Supply voltage for SIM card, generated by the GSM engine
2	SIMRST	I	Chip card reset, prompted by the GSM engine
3	SIMCLK	I	Chip card clock
4	SIMGND	-	Individual ground line for the SIM card to improve EMC



5	CCVPP	-	Not connected
6	SIMDATA	I/O	Serial data line, bi-directional
7	CCDET1	-	Connect to SIMVCC
8	CCDET2	-	Connects to the SIMPRES input of the GSM engine. Serves to recognize whether a SIM card is in the holder.

**Table 11:** Pin assignment of Molex SIM card holder on DSB45 Support Box

Pins 1 through 8 (except for 5) are the minimum requirement according to the GSM recommendations, where pins 7 and 8 are needed for SIM card tray detection through the SIMPRES pin.




**Figure 7:** Pin numbers of Molex SIM card holder

## 5.5 RTC backup for GSM/GPRS engine of C55/C55i


The internal Real Time Clock of the C55/C55i module is supplied from a separate voltage regulator in the power supply ASIC which is also active when the GSM/GPRS engine of the C55/C55i is in POWER DOWN status. An alarm function is provided that allows to wake up C55/C55i without logging on to the GSM network.

In addition, you can use the VCCRRTC pin on the board-to-board connector to backup the RTC from an external capacitor or a battery (rechargeable or non-chargeable). The capacitor is charged by the VC5 line of C55/C55i. If the voltage supply at VC5 is disconnected the RTC can be powered by the capacitor. The size of the capacitor determines the duration of buffering when no voltage is applied to the GSM/GPRS engine of the C55/C55i, i.e. the greater capacitor the longer the GSM/GPRS engine of the C55/C55i will save the date and time.


The following figures show various sample configurations. The voltage applied at VCCRRTC can be in the range from 2 to 5.5V. Please refer to [Table 7](#) for the parameters required.



**Figure 8:** RTC supply from capacitor



**Figure 9:** RTC supply from rechargeable battery



**Figure 10:** RTC supply from non-chargeable battery

## 5.6 Audio interface

The C55/C55i comprises an audio interface available on the 40-pin board-to-board connector:

- ❖ An analogue audio interface, with a balanced analogue microphone input and a balanced analogue earpiece output.

### 5.6.1 Microphone circuit


This interface with a microphone supply circuit and can be used to feed an active microphone. It has an impedance of 50 kΩ.

## 5.7 Outputs

### 5.7.1 Synchronization signal

The synchronization signal serves to indicate growing power consumption during the transmit burst. The signal is generated by the SYNC pin. Please note that this pin can adopt two different operating modes which you can select by using the `AT+SSYNC` command (mode 0 and 1). For details refer to the following chapter and to [4]. To generate the synchronization signal the pin needs to be configured to mode 0 (= default). This setting is recommended if you want your application to use the synchronization signal for better power supply control. Your platform design must be such that the incoming signal accommodates sufficient power supply to the C55/C55i module if required. This can be achieved by lowering the current drawn from other components installed in your application. The timing of the synchronization signal is shown

below. High level of the SYNC pin indicates increased power consumption during transmission.



**Figure 11:** SYNC signal during transmit burst

\*) The duration of the SYNC signal is always equal, no matter whether the traffic or the access burst are active.

### 5.7.2 Using the SYNC pin to control a status LED

As an alternative to generating the synchronization signal, the SYNC pin can be used to control a status LED on your application platform.

To avail of this feature you need to set the SYNC pin to mode 1 by using the `AT+SSYNC` command. For details see [4].

When controlled from the SYNC pin the LED can display the functions listed in table 12 below.

LED mode	Operating status
Off	C55/C55i is off or run in SLEEP or Alarm mode
600 ms On/ 600 ms	Off No SIM card inserted or no PIN entered, or network search in progress, or ongoing user authentication, or network login in progress.
75 ms On/3 s	Off Logged to network (monitoring control channels and user interactions). No call in progress.
75 ms on/75 ms Off/ 75 ms On/ 3 s Off	One or more GPRS contexts activated.
Flashing	Indicates GPRS data transfer: When a GPRS transfer is in progress, the LED goes on within 1 second after data packets were exchanged. Flash duration is approximately 0.5 s.
On	Depending on type of call: <i>Voice call:</i> Connected to remote party. <i>Data call:</i> Connected to remote party or exchange of parameters while setting up or disconnecting a call.

**Table 12:** Coding of the status LED

LED Off = SYNC pin low.

LED On = SYNC pin high (if LED is connected as illustrated in figure 12)

To operate the LED, a buffer, e.g. a transistor or gate, must be included in your application. A sample configuration can be gathered from figure 12. Power

consumption in the LED mode is the same as for the synchronization signal mode. For details see [Table 7](#), SYNC pin.




Figure 12: LED Circuit (Example)

### 5.7.3 Behaviour of the RING\_0 line (ASC0 interface)

The RING\_0 line is available on the first serial interface (ASC0). The signal serves to indicate incoming calls and other types of URCs (Unsolicited Result Code). Although not mandatory for use in a host application, it is strongly suggested that you connect the RING\_0 line to an interrupt line of your application. In this case, the application can be designed to receive an interrupt when a falling edge on RING\_0 occurs. This solution is most effective, particularly, for waking up an application from power saving. Note that if the RI\_ line is not wired, the application would be required to permanently poll the data and status lines of the serial interface at the expense of a higher current consumption. Therefore, utilizing the RING\_0 line provides an option to significantly reduce the overall current consumption of your application.

The behaviour of the RING\_0 line varies with the type of event:

- ✓ When a *voice call* comes in the RING\_0 line goes low for 1 s and high for another 4 s. Every 5 seconds the ring string is generated and sent over the RX\_0 line. If there is a call in progress and call waiting is activated for a connected handset or handsfree device, the RING\_0 line switches to ground in order to generate acoustic signals that indicate the waiting call.






Figure 13: Incoming voice call

- ✓ Likewise, when a *fax* or *data call* is received, RING\_0 goes low. However, in contrast to voice calls, the line remains low. Every 5 seconds the ring string is generated and sent over the RXD0 line.



**Figure 14:** Incoming data call

- ✓ All types of Unsolicited Result Codes (URCs) also cause the RING\_0 line to go low, however for 1 second only. For example, C55/C55i may be configured to output a URC upon the receipt of an SMS. As a result, if this URC type was activated with AT+CNMI=1, 1, each incoming SMS causes the RING\_0 line to go low. See [4] for detailed information on URCs.



**Figure 15:** URC transmission

Function	Pin	Status	Description
Ring indication	RING_0	0	SLEEP mode CFUN=0 or CYCLIC SLEEP mode CFUN=5 or 6, the module is caused to wake up to full functionality. If CFUN=7 or 8, power saving is resumed after URC transmission or end of call.
		1	No operation

**Table 13:** ASC0 ring signal

## 5.8 Automatic GPRS Multislot Class change

Temperature control is also effective for operation in GPRS Multislot class 10. If the board temperature increases to the limit specified for restricted operation (See 3.3 for temperature limits known as restricted operating) while data are transmitted over GPRS, the module automatically reverts from GPRS Multislot class 10 (3 RX x 2 TX) to class 8 (4 RX x 1 TX). This reduces the power consumption and, consequently, causes the temperature of board to decrease. Once the temperature drops to a value of 5 degrees below the limit of restricted operation, C55/C55i returns to the higher Multislot class. If the temperature stays at the critical level or even continues to rise, C55/C55i will not switch back to the higher class. After a transition from Multislot class 10 to Multislot 8 a possible switchback to Multislot class 10 is blocked for one minute. Please note that there is not one single cause of switching over to a lower GPRS Multislot class. Rather it is the result of an interaction of several factors, such as the board temperature that depends largely on the ambient temperature, the operating mode and the transmit power. Furthermore, take into account that there is a delay until the network proceeds to a lower or, accordingly, higher Multislot class. The delay time is network dependent. In extreme cases, if it takes too much time for the network and the temperature cannot drop due to this delay, the module may even switch off as described in chapter 5.4.6.1. For GPRS connection see related document [5].

## 5.9 Power saving

SLEEP mode reduces the functionality of the GSM/GPRS engine of the C55/C55i module to a minimum and, thus, minimizes the current consumption to the lowest level. Settings can be made using the AT+CFUN command. For details see below and [4]. SLEEP mode falls into two categories:

- ✓ NON-CYCLIC SLEEP mode AT+CFUN=0
- ✓ CYCLIC SLEEP modes, selectable with AT+CFUN=5, 6, 7, 8 or 9.

IMPORTANT: Please keep in mind that power saving works properly only when PIN authentication has been done. If you attempt to activate power saving while the SIM card is not inserted or the PIN not correctly entered, the selected <fun> level will be set, though power saving does not take effect. For the same reason, power saving cannot be used if the GSM/GPRS engine of the C55/C55i operates in Alarm mode.

To check whether power saving is on, you can query the status of AT+CFUN if you have chosen CYCLIC SLEEP mode. If available, you can take advantage of the status LED controlled by the SYNC pin (see chapter 5.7.2). The LED stops flashing once the module starts power saving. The wake-up procedures are quite different depending on the selected SLEEP mode. Table 1 compares the wake-up events that can occur in NON-CYCLIC and CYCLIC SLEEP modes.

### 5.9.1 No power saving (AT+CFUN=1)

The functionality level <fun>=1 is where power saving is switched off. This is the default after start-up.

### 5.9.2 NON-CYCLIC SLEEP mode (AT+CFUN=0)

If level 0 has been selected (AT+CFUN=0), the serial interface is blocked. The module shortly deactivates power saving to listen to a paging message sent from the base station and then immediately resumes power saving. Level 0 is called NON-CYCLIC SLEEP mode, since the serial interface is not alternatingly made accessible as in CYCLIC SLEEP mode.

The first wake-up event fully activates the module, enables the serial interface and terminates the power saving mode. In short, it takes the GSM/GPRS engine of the C55/C55i back to the highest level of functionality <fun>=1. RTS\_0 is not used for flow control, but to wake up the module.

### 5.9.3 CYCLIC SLEEP mode (AT+CFUN=5, 6, 7, 8)

The major benefit over the NON-CYCLIC SLEEP mode is that the serial interface is not permanently blocked and that packet switched calls may go on without terminating the selected CYCLIC SLEEP mode. This allows the GSM/GPRS engine of the C55/C55i to become active, for example to perform a GPRS data transfer, and to resume power saving after the GPRS data transfer is completed.

The CYCLIC SLEEP modes give you greater flexibility regarding the wake-up procedures:

For example, in all CYCLIC SLEEP modes, you can enter AT+CFUN=1 to permanently wake up the module. In modes CFUN=7 and 8, the GSM/GPRS engine of the C55/C55i automatically resumes power saving, after you have sent or received a short message or made a call. CFUN=5 and 6 do not offer this feature, and therefore, are only supported for compatibility with earlier releases. Please refer to [Table 1](#) for a summary of all modes.

The CYCLIC SLEEP mode is a dynamic process which alternatingly enables and disables the serial interface. By setting/resetting the CTS signal, the module indicates to the application whether or not the UART is active. The timing of CTS is described below.

Both the application and the module must be configured to use hardware flow control (RTS/CTS handshake). The default setting of the GSM/GPRS engine of the C55/C55i is AT\Q0 (no flow control) which must be altered to AT\Q3. See [\[4\]](#) for details.

### 5.9.4 CYCLIC SLEEP mode AT+CFUN=9

Mode AT+CFUN=9 is similar to AT+CFUN=7 or 8, but provides two additional features:

- ❖ RTS\_0 is not intended for flow control (as in modes AT+CFUN=5, 6, 7 or 8), but can be used to temporarily wake up the module. This way, the module can quickly wake up and resume power saving, regardless of the CTS timing controlled by the paging cycle.
- ❖ The time the module stays active after RTS was asserted or after the last character was sent or received, can be configured individually using the command AT^SCFG. Default setting is 2 seconds like in AT+CFUN=7. The entire range is from 0.5 seconds to 1 hour, selectable in tenths of seconds. For details see [\[4\]](#).



### 5.9.5 Timing of the CTS signal in CYCLIC SLEEP modes

The CTS signal is enabled in synchrony with the paging cycle of module. It goes active low each time when the module starts listening to a paging message block from the base station. The timing of the paging cycle varies with the base station. The duration of a paging interval can be calculated from the following formula:

$$4.615 \text{ ms (TDMA frame duration)} * 51 \text{ (number of frames)} * \text{DRX value.}$$


DRX (Discontinuous Reception) is a value from 2 to 9, resulting in paging intervals from 0.47 to 2.12 seconds. The DRX value of the base station is assigned by the network operator. Each listening period causes the CTS signal to go active low: If DRX is 2, the CTS signal is activated every 0.47 seconds, if DRX is 3, the CTS signal is activated every 0.71 seconds and if DRX is 9, the CTS signal is activated every 2.1 seconds. The CTS signal is active low for 4.6 ms. This is followed by another 4.6 ms UART activity. If the start bit of a received character is detected within these 9.2 ms, CTS will be activated and the proper reception of the character will be guaranteed.

CTS will also be activated if any character is to be sent.

After the last character was sent or received the interface will remain active for:

- ✓ another 2 seconds, if AT+CFUN=5 or 7,
  - ✓ another 10 minutes, if AT+CFUN=6 or 8,
  - ✓ or for an individual time defined with AT^SCFG, if AT+CFUN=9.
- Assertion of RTS has the same effect.

In the pauses between listening to paging messages, while CTS is high, the module resumes power saving and the AT interface is not accessible. See figure 16 and figure 17.



**Figure 16:** Timing of CTS signal (example for a 2.12 s paging cycle)

Figure 17 illustrates the CFUN=5 and CFUN=7 modes, which reset the CTS signal 2 seconds after the last character was sent or received.






Figure 17: Beginning of power saving if CFUN=5 or 7

### 5.9.6 Wake up C55/C55i from SLEEP mode

A wake-up event is any event that causes the module to draw current. Depending on the selected mode the wake-up event either switches SLEEP mode off and takes C55/C55i back to AT+CFUN=1, or activates C55/C55i temporarily without leaving the current SLEEP mode.

Definitions of the state transitions described in table 19 below:

- Quit = C55/C55i exits SLEEP mode and returns to AT+CFUN=1.  
 Temporary = C55/C55i becomes active temporarily for the duration of the event and the mode-specific follow-up time after the last character was sent or received on the serial interface.  
 No effect = Event is not relevant in the selected SLEEP mode. C55/C55i does not wake up.

Event	Selected mode AT+CFUN=0	Selected mode AT+CFUN=5 or 6	Selected mode AT+CFUN=7, 8, 9
Ignition line	No effect	No effect	No effect
RTS0 <sup>1)</sup> (falling edge)	Quit	No effect (RTS is only used for flow control)	Mode 7 and 8: No effect (RTS is only used for flow control) Mode 9: Temporary
Unsolicited Result Code (URC)	Quit	Quit	Temporary
Incoming voice or data call	Quit	Quit	Temporary
Any AT command (incl. outgoing voice or data call, outgoing SMS)	Not possible (UART disabled)	Temporary	Temporary
Incoming SMS depending on mode selected by AT+CNMI: AT+CNMI=0,0 (= default, no indication of received SMS) AT+CNMI=1,1 (= displays URC upon receipt of SMS)	No effect  Quit	No effect  Quit	No effect  Temporary
GPRS data transfer	Not possible (UART disabled)	Temporary	Temporary

	disabled)		
RTC alarm <sup>2)</sup>	Quit	Quit	Temporary
AT+CFUN=1	Not possible (UART disabled)	Quit	Quit

**Table 14:** Wake-up events in NON-CYCLIC and CYCLIC SLEEP modes

- 1) During the CYCLIC SLEEP modes 5, 6, 7, and 8, RTS0 is conventionally used for flow control: The assertion of RTS\_0 signal that the application is ready to receive data - without waking up the module. If the module is in CFUN=0 mode the assertion of RTS0 serves as a wake-up event, giving the application the possibility to intentionally terminate power saving. If the module is in CFUN=9 mode, the assertion of RTS\_0 can be used to temporarily wake up C55/C55i for the time specified with the AT^SCFG command (default = 2 s).
- 2) Recommendation: In NON-CYCLIC SLEEP mode, you can set an RTC alarm to wake up C55/C55i and return to full functionality. This is a useful approach because, in this mode, the AT interface is not accessible.

## 5.10 Summary of state transitions (except SLEEP mode)

### 5.10.1 Summary of POWER DONE and Normal Mode

Further mode	POWER DOWN	Normal mode <sup>*)</sup>
Present mode		
POWER DOWN mode	--	SOFT_ON >100 ms at low level
Normal mode <sup>*)</sup>	AT^SMSO or exceptionally RESET pin >3.2 s at low level	--
Alarm mode	Alarm mode AT^SMSO or exceptionally RESET pin >3.2 s at low level	SOFT_ON >100 ms at low level

**Table 15:** Summary of state transitions

\*) Normal mode covers TALK, DATA, GPRS, IDLE and SLEEP modes

### 5.10.2 Summary of Alarm Mode

Further mode	Alarm mode
Present mode	
POWER DOWN mode	Wake-up from POWER DOWN mode (if activated with AT+CALA)
Normal mode <sup>*)</sup>	AT+CALA followed by AT^SMSO. C55/C55i enters Alarm mode when specified time is reached
Alarm mode	--

**Table 16:** Summary of state transitions

\*) Normal mode covers TALK, DATA, GPRS, IDLE and SLEEP modes

### **5.10.3 Resetting the GSM module by AT+CFUN=1,1**

This command can only be used if the serial interface is enabled.

If the GSM software is still running, while the user feels the need to reset the module, AT+CFUN=1,1 can be used. The module will properly be logged-off from the registered network, resets and restarts the module to full functionality. After reset and restart, PIN authentication is necessary (AT+CPIN). If autobauding is enabled, it is recommended to wait 3 to 5 seconds before entering the first AT command.

The control status LED on SYNC pin (see section 5.7.2) shortly toggle to OFF and back to ON again to show the progress.

Keep in mind that, the reset command described above, does not change the level of C55/C55i functionality but only restarts the C55/C55i module.

## **5.11 GSM 07.05 and 07.07 commands**

The GSM modem of the C55/C55i is controlled by an advanced set of AT commands. For further information it is recommended to read the ETSI GSM recommendation or have a look at the AT command set of the C55/C55i which the AT command set of the C55/C55i can be downloaded from FALCOM's homepage [www.falcom.de>Service>Download>C55/C55I](http://www.falcom.de>Service>Download>C55/C55I). See related documents [4].

## 6 First steps to make it works


The quickest way to get first results with the C55 embedded GSM/GPRS module is to operate it with the GSM-EVAL-KIT which is available by FALCOM upon request. It saves design, time and reduces “Time-to-Market” period. For more details about the FALCOM GSM-EVAL-KIT, refer to the chapter “[GSM Evaluation Kit \(GSM EVAL-KIT\)](#)”.

**NOTE:** The GSM/GPRS module C55 are compatible to the C2D module as far as the pin-out on the 40-pin board-to-board connector is concerned. By evaluating the C55 module a C2D adapter board is required to perform the connection between the C55/C55i and GSM-EVAL-KIT. This applies for the users who already have an adapter and a GSM-EVAL-KIT. For other users they have to purchase one.

### 6.1 Minimum set-up connection

This section and subsections below describe the minimum hardware connection of C55/C55i module to get started.

As a minimum, to set-up a connection between your PC and the C55, it is necessary to connect the following interfaces to operate the C55/C55i module properly. Please, follow step-by-step the instructions below. The figure below shows in a visual form the connection of the C55/C55i hardware interfaces.



#### 6.1.1 Mounting the C55/C55i

The C55/C55i contains four holes for mounting screws. The module can be assembled to various applications without using the screws.

#### 6.1.2 Antenna interface

The antenna must be located on the places where the signal strength is sufficient. Maybe a mobile phone is required to be used to verify the best location for the C55/C55i connected antenna.

Electronic devices can cause interference, which affects the performance of the C55/C55i. Do not locate the antenna nearby electric devices or other antennas.

The C55/C55i uses a MC card-male antenna connector supplied from Radiall. The GSM RF connector has impedance 50  $\Omega$ . A dual- or tri band GSM antenna can be directly connected to this connector. Mating plugs and cables can also be chosen from FALCOM GmbH. In addition to the GSM antenna, FALCOM GmbH provides antenna cable sets which connects a MC card connector to the FME connector (if you are using a GSM antenna with FME connector only) through 20 cm RG.174 antenna cable. The ordering number of this antenna adapter is KA05.

### **6.1.3 SIM interface**

The integrated SIM interface in the C55/C55i module controls a 3 V SIM card. This interface is fully compliant with GSM 11.11 recommendations concerning SIM functions.

The C55/C55i requires a small SIM card, which is provided by your mobile phone service provider. This contains the telephone number of C55/C55i you will use, as well as other customer information.

If your SIM is larger credit-card size, it may have a snap-out area that allows the small SIM to be removed by gentle twisting. Otherwise apply to your service provider for a small SIM.

The SIM card must be enabled for all services that you want to use – VOICE, DATA, and/or FAX; if in doubt contact your service provider.

Via pushing the eject button on the right side of the card reader, the card holder can be taken off. Put the SIM card into the card holder. The bevelled corner of SIM card has to be on the same side to bevelled corner of card holder and the golden contact area is facing upwards. Make sure that the SIM card is sitting firmly in the SIM card holder slot. Then insert the tray (with SIM card) into the card reader, and push it forwards till it snaps in.

### **6.1.4 Serial communication signals**

The physical interface to the integrated C55/C55i is performed through available lines on the 40-pin board-to-board connector. The C55/C55i supports an unbalanced, asynchronous serial channel conforming to ITU-T V.24 protocol DCE signaling. The electrical characteristics do not comply with ITU-T V.28. The significant levels are 0 V (for low data bit or ON condition) and 2.65 V (for high data bit or OFF condition). This interface is provided with 8-wire supports line and ground. In order to use different voltage levels, an appropriate level shifters has to be connected.

E.g. in order to provide RS232 compatible levels use the 3 V compatible MAX3232 transceiver from Maxim (see figure 21) or others based on the required levels. If a RS232 compatible serial level is obtained, then you can directly communicate with a host device serial port. All supported variable baud rates can be controlled from the appropriate screens in the application software (e.g. HyperTerminal).

Refer also on the section [5.3](#) to determinate the DTE-DCE connection.

### 6.1.4.1 Level Shifter




Figure 18\*: level shifter application diagram for serial link

\*This application note is valid for  $V_{CC} \geq 3.0$  Volt (see MAX3238 specifications). Auto shut down mode is not used in this example.

### 6.1.5 Backup battery

The internal Real Time Clock of the C55/C55i module is supplied from a separate voltage regulator in the power supply ASIC which is also active when the C55/C55i module is in POWER DOWN status. An alarm function is provided that allows to wake up C55/C55i without logging on to the GSM network.

### 6.1.6 Power supply

Five VC5 pins of the board-to-board connector are provided to connect the supply voltage, five GND pins are recommended for grounding.

The power supply for the C55/C55i module has to be a single voltage source of  $V_{VC5+} = 4.75 \dots 5.25$  V. It must be able to provide sufficient current in a transmit burst which typically rises to 1.6 A.

Before you connect the module to the external supply voltage, please, start the application software (HyperTerminal) which is to be found in the following directory:

- ✓ Go to Start > Program > Accessories > Communication and click the HyperTerminal program.
- ✓ On the appeared screen assign the name for the current connection (e.g. "C55") and click OK.

- ✓ Then choose the correct COM Port on which the module is connected as well select the baud rate of (57000 bps, 8 bit, no parity bit, 1 stop bit) and click OK.

Now, connect GND pins to ground, and VC5 lines to the external source voltage (+5 V DC) properly.

Once the module is connected to the supply voltage, a string “STARTING” is responded from the module and it is also displayed on the terminal screen. That signifies the module is operational, and it is waiting for switching on. The serial interface of the module is inaccessible yet.

#### **6.1.7 Turn on the GSM/GPRS engine of C55**

In general, be sure not to turn on GSM/GPRS engine of the C55/C55i module while it is out of the operating range of voltage and temperature stated described in the [Table 7](#) and [Table 4](#). The GSM/GPRS engine of the C55/C55i would immediately switch off after having started and detected these inappropriate conditions.


To switch on the C55/C55i GSM/GPRS engine the SOFT\_ON signal needs to be driven to HIGH level for at least 100 ms and not earlier than 1 second after system is powered on. To make it in a properly manner just use externally a user application switch (see also figure above) and link it to the VC5 and SOFT\_ON lines. Now the module is ready for operation and the serial interface of the module is accessible.

Just type

AT <ENTER>

the module responds OK.

## 7 Housing



**Figure 19:** Housing of C55/C55i



## 8 EMC and ESD requirements

The **ETS 300342-1** standard applies to the C55/C55i with regard to EMC and ESD requirements.

Additional requirements in relation to EMC/ESD:

If the C55/C55i is being used in cars, the requirements regarding power supply as defined in section 9.6 of the ETS 300342-1 (6/97) standard must be fulfilled.

The connecting cable between the chip card reader and the socket on the C55/C55i must be shielded in compliance with EMC requirements.

When using the C55/C55i cellular engine with individual handsfree equipment, noise interference may occur.

The C55/C55i cellular engine must be connected directly to the ground of the base device.

**Note:**

The device should only be handled in compliance with ESD regulations (grounded, ESD chain, trained personnel).

## 9 GSM Evaluation Kit (GSM EVAL-KIT)

The quickest way to get first results with the embedded GSM module is the activation by the GSM-EVAL-KIT by means of a terminal program.

The FALCOM GSM-EVAL-KIT provides design engineers with all necessary hard- and software information for the creation of embedded applications based on FALCOM GSM/DCS embedded modules. It saves design, time and reduces “Time-to-Market” period.

### **The GSM EVAL-KIT set contains:**

- EVAL-Board
- Adapter PCB for A2D/F35/C2D/C55 (I56) modules called FALCOM adapter
- Adapter PCB for C55 module called CM adapter
- Wall mount power adapter
- 9-pin serial cable (pin to pin direct connection, male to female connectors)
- GSM antenna (900/1800/1900) and cable (30 cm) with coaxial plug
- Coaxial adapter MC card
- Headset with RJ45 plug
- Set of connectors:
  - 2 pieces 40-pin stacking connector (plug and socket)
  - 2 pieces coaxial antenna plug (plug and socket)
  - 2 pieces 15-pin cable connector (plug and socket)
  - 2 pieces external SIM card reader
  - 3 pieces short circuit bridges
  - 4 pieces mounting clamps
  - 4 pieces dowel
- CD
  - “A2D-Testsoftware”
  - Layout data (PROTEL/GERBER format) of module
  - Evaluation board user manual
  - C55 AT command set
  - C55/C55i hardware manual
  - C55/C55i GPRS start up guide
  - C55i TCP command set

Schematics of the evaluation platform and adapter PCB's (power supply, external SIM card, serial interface).