

AVR Fuse Calculator ... Version 0.3.5

Part name: ATmega64

	Low	High	Ext'd	
Default:	0xc1	0x99	0xFF	Apply default values
Current:	0xC1	0xBF	0xFF	Apply user values

Quick Configuration

Int. RC Osc. 1 MHz; Start-up time: 6 CK + 0 ms; [CKSEL=0001 SUT=00]

(unprogrammed)

Brown-out detection level at VCC=2.7 V; [BODLEVEL=1]

(unprogrammed)

Boot Flash section size=512 words Boot start address=\$7E00; [BOOTSZ=11]

(unprogrammed)

(unprogrammed)

(unprogrammed)

JTAG Interface Enabled; [JTAGEN=0]

(unprogrammed)

(unprogrammed)

(unprogrammed)

	Low	High	Ext'd
<input type="checkbox"/> BODLEVEL	<input type="checkbox"/> OC DEN		
<input type="checkbox"/> BODEN	<input checked="" type="checkbox"/> JTAGEN		
<input checked="" type="checkbox"/> SUT1	<input type="checkbox"/> SPIEN		
<input checked="" type="checkbox"/> SUT0	<input type="checkbox"/> CKOPT		
<input checked="" type="checkbox"/> CKSEL3	<input type="checkbox"/> EESAVE		
<input checked="" type="checkbox"/> CKSEL2	<input type="checkbox"/> BOOTSZ1		
<input checked="" type="checkbox"/> CKSEL1	<input type="checkbox"/> BOOTSZ0	<input type="checkbox"/> CompMode	
<input type="checkbox"/> CKSEL0	<input type="checkbox"/> BOOTRST	<input type="checkbox"/> WDTON	
Apply fuse bits			

☐ = Unprogrammed (1)  
☒ = Programmed (0)

All information based upon database ATmega64.xml build 190.  
Unreviewed original XML backend database from Atmel. Possibly buggy!  
No responsibility is taken for the correctness of the presented information!  
For help, just hover the pointer over the corresponding element.  
Copyright © 2006 Mark Hämmerling.