

AT Command Set For L55 Siemens Mobile Phones And Modems

Copyright

This publication is protected by copyright and distributed under licenses restricting its use, copying and distribution. No part of this publication may be reproduced in any form by any means without prior written authorization of Siemens AG.

Offenders will be liable for damages. All rights are reserved in the event of the granting of a patent or the registration of a utility model.

The products and technologies described herein may be protected by one or more patents or patents pending in the United States or other countries.

Trademarks

Siemens AG is a registered trademark.

Hyperlinks

This publication may contain hyperlinks to the Web pages of third parties. Siemens accepts no liability or responsibility for the contents of such Web pages and Siemens does not take over such Web pages as its own. The use of such pages shall be at the sole risk of the User.

Disclaimer

This publication is provided "AS IS", without a warranty of any kind. All express or implied representations and warranties, including any implied warranty of merchantability, fitness for a particular purpose or non-infringement, are hereby excluded.

Siemens AG may make any improvements or changes in the product(s) or the program(s) described in this publication at any time.

This document is subject to change without notice.

Table of Contents

Table of Contents	ii
1 General information	3
1.3 Abbreviations and glossary.....	3
1.4 Notational Conventions.....	3
1.5 Other conventions	3
1.6 Related documentation.....	3
1.6.1 Related Siemens-internal documentation	3
1.6.2 Related Standardisation documentation	4
2 Software interface.....	5
2.1 Overview of the supported AT command set.....	5
2.2 The AT command set.....	10
2.2.1 Hayes Standard commands	10
2.2.2 Command combinations to be avoided.....	13
2.3 AT commands and responses according to GSM 07.07 and GSM 07.05.....	13
2.3.1 General commands according to GSM 07.07	14
2.3.2 Call control commands.....	16
2.3.3 Network service related commands.....	18
2.3.4 Commands related to mobile equipment control and status	33
2.3.5 Extensions of Hayes Standard commands for GPRS.....	48
2.3.6 Commands for GPRS.....	49
2.3.7 Commands related to mobile equipment errors.....	58
2.3.8 TIA IS-101 commands ("Voice control interim standard for asynchronous DCE").....	59
2.3.9 AT Cellular commands according to GSM 07.05 for SMS	60
2.3.10 Modem commands.....	69
2.3.11 Fax commands.....	71
2.3.12 Bluetooth related commands.....	86
2.4 General commands according to ITU-T Recommendation V.25 ter.....	88
2.4.2 User-defined commands for controlling the GSM mobile phone	89
2.4.3 Summary of all unsolicited messages.....	108
2.5 Appendix A.....	110
2.5.1 Factory settings made by AT&F	110
2.5.2 Features of the Telephone book memory	111
2.5.3 Writing to the FDN Phonebook / FDN Replacement.....	112
2.5.4 Using special characters in certain commands (e. g., +CPBR/+CPBW).....	113
2.6 S Registers.....	114
2.7 Circuit assignments	114
2.8 Appendix B.....	115
2.8.1 Example for creating / retrieving an organizer entry	115
2.8.2 Examples and hints for using GPRS commands	117
2.8.3 The GPRS dial command ATD.....	119
2.8.4 The AT^SVMC command	119
3 Errors and Messages.....	122
3.1 Summary of CME ERRORS (+CME ERROR) related to GSM 07.07	122
3.2 Summary of CMS ERRORS (+CMS ERROR) related to GSM 07.05	123
3.3 GPRS return values issued by AT+CEER	122
3.3.1 GMM-GSM return values issued by AT+CEER (GMM_LOC_GSM).....	125
3.3.2 SM-GSM return values issued by AT+CEER (SM_LOC_GSM).....	126
3.3.3 SM_OWN return values issued by AT+CEER (SM_LOC_OWN).....	126
3.3.4 GAPI return values issued by AT+CEER (GAPI_LOC_OWN)	127
3.3.5 LMAN return values issued by AT+CEER (LMAN_LOC_OWN)	127
3.3.6 ENIP return values issued by AT+CEER (ENIP_LOC_OWN)	127
3.4 List of keys implemented for AT+CKPD.....	128
3.5 List of Commands related to CSCS / UCS2.....	129
3.6 Result codes.....	129
3.7 List of *# codes.....	130

List of Tables

Table 2-1: Supported GSM 07.07 commands	5
Table 2-2: Supported GSM 07.05 commands	7
Table 2-3: Supported commands according to ITU-T Recommendation V.25 ter	7
Table 2-4: Supported commands according to ITU-T Recommendation V.25 ter	8
Table 2-5: Supported Bluetooth-related commands	8
Table 2-6: Supported Siemens-specific commands	9
Table 2-7: Commands supported according to Hayes standard	10
Table 2-8: Conventions applying to the presentation of AT commands	13
Table 2-9: List of dummy FAX commands	71
Table 2-10: List of unexpected messages	108
Table 2-11: Features of the telephone book memory	111
Table 2-12: Using escape characters in commands	113
Table 2-13: Using escape characters in GSM commands	113
Table 2-14: S-Registers	114
Table 3-1: CME ERRORS related to GSM 07.07	122
Table 3-2: CMS ERRORS related to GSM 07.05	123
Table 3-3: GPRS return values	125
Table 3-4: GMM return values issued by AT+CEER	125
Table 3-5: GMM return values issued by AT+CEER	126
Table 3-6: GAPI return values issued by AT+CEER	126
Table 3-7: GAPI return values issued by AT+CEER	129
Table 3-8: LMAN return values issued by AT+CEER	127
Table 3-9: ENIP return values issued by AT+CEER	127
Table 3-10: Result codes	129
Table 3-11: List of *# codes	130

1 General information

This document constitutes the manual reference to the AT command set supported by S45 Siemens mobile phones.

1.3 Abbreviations and glossary

The following abbreviations and terms are used throughout this specification:

Abbreviation / Term	Meaning
FDN	Fixed dialling numbers
IMEI	International Mobile Station Equipment Identity
PDU	Packet Data Unit
PIN	Acronym for "Personal Identification Number"
PUK	Acronym for "PIN Unblocking Key "
SIM	
UDI	

1.4 Notational Conventions

The following notational conventions apply throughout this manual:

- Letters and digits in Courier New indicate parameter names and values
- Underlined digits indicate the default value of the parameter at hand
- Double quotes (") are used to indicate text strings
- Symbols (e. g. @) inside quotes are interpreted as text strings
- Strings which are not included in double quotes must be separated by comma
- Spaces inside strings are ignored unless they are included in double quotes

Further conventions applying to the presentation of AT commands are outlined in section 2.2.

1.5 Other conventions

The following other conventions apply throughout this manual:

- Leading zeroes in strings can be omitted
- If an optional parameter ([<value>]) is omitted in V.25ter commands, the value 0 is assumed
- Although the names of commands are not case-sensitive, cases should not be mixed. Either "AT" or "at" should be specified, but neither "aT" nor "At".

1.6 Related documentation

All documents listed in this section are related to the current document.

1.6.1 Related Siemens-internal documentation

No Siemens-internal documents are related to the current document.

1.6.2 Related Standardisation documentation

The following standardisation documents are related to the current document:

- [1] Digital cellular telecommunications system (Phase 2+); Technical realization of the Short Message Service (SMS) Point-to-Point (PP)(3GPP TS 03.40 version 7.5.0 Release 1998)
- [2] Digital cellular telecommunications system (Phase 2+); Point-to-Point (PP) Short Message Service (SMS) Support on Mobile Radio Interface (3GPP TS 04.11 version 7.1.0 Release 1998)
- [3] Digital cellular telecommunications system (Phase 2+); AT command set for GSM Mobile Equipment (ME)(3GPP TS 07.07 version 7.7.0 Release 1998)
- [4] Digital cellular telecommunications system (Phase 2+) (GSM); Use of Data Terminal Equipment - Data Circuit terminating; Equipment (DTE - DCE) interface for Short Message Service (SMS) and Cell Broadcast Service (CBS)(GSM 07.05 version 7.0.1 Release 1998)
- [5] ITU-T Draft new Recommendation V.25ter "Serial asynchronous automatic dialling and control"
- [6] Digital cellular telecommunications system (Phase 2+) (GSM); Personalisation of GSM Mobile Equipment (ME); Mobile functionality specification (GSM 02.22 version 7.0.0 Release 1998)
- [7] Digital cellular telecommunications system (Phase 2+); Specification of the Subscriber Identity Module - Mobile Equipment (SIM-ME) Interface (3GPP TS 11.11 version 8.8.0 Release 1999)
- [8] Facsimile Digital Interfaces – Asynchronous Facsimile DCE Control Standard, Service Class 1(TIA/EIA-578-A), May 1995
- [9] Standards Proposal No. 2388, Proposed New Standard "Asynchronous Facsimile DCE Control Standard" (if approved, to be published as EIA/TIA-592), October 1990
- [10] Hands-free Profile (0.96 voting draft, 2001-10-22, by Jesus A. G. Pulido; Doc no. CAR_x_SPEC/0.96 B1)

2 Software interface

2.1 Overview of the supported AT command set

This section provides overviews of the supported sets of AT commands, separate for each type of command set.

Table 2-1 lists all the supported GSM 07.07 AT commands in alphabetical order, and indicates the type of command as defined in the ETSI GSM 07.07 standard:

07.07 command	Function	Type of command	Page
AT+CACM	Accumulated call meter	Mobile equipment control	33
AT+CALM	Alert sound mode	Mobile equipment control	33
AT+CAMM	Accumulated call meter maximum	Mobile equipment control	34
AT+CAOC	Advice of charge	Network service	18
AT+CBC	Battery charge	Mobile equipment control	34
AT+CBST	Select bearer service type	Modem command	69
AT+CCFC	Call forwarding	Network service	19
AT+CCLK	Clock	Mobile equipment control	34
AT+CCWA	Call waiting	Network service	20
AT+CEER	Query the reason for disconnection of last call	Call control	16
AT+CGACT	PDP context activate or deactivate	GPRS	49
AT+CGANS	Manual response to a network request for PDP context activation	GPRS	49
AT+CGATT	GPRS attach or detach	GPRS	50
AT+CGAUTO	Auto response to a network request for PDP context activation	GPRS	50
AT+CGCLASS	GPRS mobile station class	GPRS	51
AT+CGDATA	Enter data state	GPRS	51
AT+CGDCONT	Define PDP Context	GPRS	52
AT+CGEREP	GPRS event reporting	GPRS	53
AT+CGMI	Issue manufacturer ID code	General	14
AT+CGMM	Issue model ID code	General	14
AT+CGMR	Output the GSM telephone version	General	14
AT+CGPADDR	Show PDP address	GPRS	56
AT+CGQMIN	Quality of Service Profile (Minimum acceptable)	GPRS	54
AT+CGQREQ	Quality of Service Profile (Requested)	GPRS	55
AT+CGREG	GPRS network registration status	GPRS	57
AT+CGSMS	Select service for MO SMS messages	GPRS	58
AT+CGSN	Output the serial number (IMEI)	General	14
AT+CHLD	Call hold and multiparty	Network service	21
AT+CHUP	Terminate call	Call control	16
AT+CIMI	Output of IMSI	General	15
AT+CIND	Indicator Control	Mobile equipment control	35
AT+CKPD	Keypad control	General	15
AT+CLCC	List Current Calls	Network service	22
AT+CLCK	Switch locking on and off	Network service	23
AT+CLIP	Display telephone number of calling party	Network service	25
AT+CLIR	Select Incognito Mode (Call Line Identification Restriction)	Call control	26

AT+CLVL	Loudspeaker volume level	Mobile equipment control	36
AT+CMEC	Mobile Termination control mode	Mobile equipment control	36
AT+CMEE	Expanded error messages according to GSM 07.07	Mobile equipment error	58
AT+CMER	Mobile Termination control mode	Mobile equipment control	37
AT+CMUT	Mute control	Mobile equipment control	38
AT+COLP	Connected Line Identification Presentation	Call control	27
AT+COPN	Read operator names	Network service	28
AT+COPS	Commands concerning selection of network operator	Network service	28
AT+CPAS	Query the telephone status	Mobile equipment control	38
AT+CPBR	Read a telephone-book entry	Mobile equipment control	39
AT+CPBS	Select a telephone book	Mobile equipment control	40
AT+CPBW	Write a telephone-book entry	Mobile equipment control	41
AT+CPIN	Enter PIN and query lock	Mobile equipment control	42
AT+CPOL	Preferred operator list	Network service	29
AT+CPUC	Price per unit and currency table	Mobile equipment control	43
AT+CPWD	Change password to a lock	Network service	30
AT+CR	Service reporting control	General	17
AT+CRC	Cellular result codes	General	17
AT+CREG	Network registration	Network service	31
AT+CRLP	Select radio link protocol parameter for originating non-transparent data call	Modem command	70
AT+CRMP	Ring Melody Playback	Mobile equipment control	44
AT+CRSL	Ringer sound level	Mobile equipment control	43
AT+CRSM	Restricted SIM access	Mobile equipment control	45
AT+CSCS	Select TE character set	General	15
AT+CSQ	Output signal quality	Mobile equipment control	46
AT+CSSN	Supplementary service notifications	Network service	32
AT+CVIB	Vibrator mode	Mobile equipment control	47
AT+GSN	Output the serial number (IMEI)	General	16
AT+VTS	Send a DTMF tone	TIA IS101	59
AT+VTD	Set duration of a DTMF tone	TIA IS101	59
AT+WS46	Select wireless network	General	16

Table 2-1: Supported GSM 07.07 commands

Table 2-2 lists all the supported GSM 07.05 AT commands in alphabetical order, and indicates the type of command as defined in the ETSI GSM 07.05 standard:

07.05 commands	Function	Type of command	Page
AT+CMGC	Send an SMS command	Message sending and writing	60
AT+CMGD	Delete an SMS in the SMS memory	Message sending and writing	60
AT+CMGF	SMS format	General configuration	60
AT+CMGL	List SMS	Message receiving and reading	61
AT+CMGR	Read in an SMS	Message receiving and reading	61
AT+CMGS	Send an SMS	Message sending and writing	62
AT+CMGW	Write an SMS to the SMS memory	Message sending and writing	62
AT+CMSS	Send an SMS from the SMS memory	Message sending and writing	63
AT+CNMA	Acknowledgment of a short message directly output	Message receiving and reading	63
AT+CNMI	Display new incoming SMS	Message receiving and reading	64
AT+CPMS	Preferred SMS message storage	General configuration	66
AT+CSCA	Address of the SMS service center	Message configuration	67
AT+CSCB	Select cell broadcast messages	Message configuration	67
AT+CSMS	Selection of message service	General configuration	68

Table 2-2: Supported GSM 07.05 commands

Table 2-3 lists all the supported Siemens-specific AT commands in alphabetical order:

Command	Function	Page
AT+GCAP	Request Capabilities List	88
AT+IPR	Fixed DTE rate	88

Table 2-3: Supported commands according to ITU-T Recommendation V.25 ter

Table 2-4 lists all the supported AT commands for FAX services in alphabetical order:

Command	Function	Page
AT+ FBADLIN	Define or read number of bad lines	72
AT+ FBADMUL	Define, read or test number of bad lines	73
AT+ FBOR	Query the bit order for receive mode	73
AT+FCIG	Query or set the Local polling id	74
AT+FCLASS	Select, read or test FAX service class	75
AT+FCQ	Control Copy Quality	74
AT+ FCR	Capability to receive	75
AT+FDCC	Select service for MO SMS messages	76
AT+FDFFC	Data Compression Format Conversion	77
AT+FDIS	Query or set session parameters	78
AT+FDR	Begin or continue phase C data reception	79
AT+FDT	Data Transmission	80
AT+FET	End a page or document	80
AT+FK	Kill operation, orderly FAX abort	81
AT+FLID	Query or set session parameters	81
AT+FMDL	Identify Product Model	81
AT+FMFR	Request Manufacturer Identification	82
AT+FOPT	Set bit order independently	82
AT+FPHCTO	DTE Phase C Response Timeout	82
AT+FREV	Identify Product Revision	83
AT+FRH	Receive Data Using HDLC Framing	83
AT+FRM	Receive Data	83
AT+FRS	Receive Silence	84
AT+FTH	Transmit Data Using HDLC Framing	84
AT+FTM	Transmit Data	84
AT+FTS	Stop Transmission and Wait	85
AT+FVRFC	Vertical resolution format conversion	85

Table 2-4: Supported commands according to ITU-T Recommendation V.25 ter

Table 2-5 lists all the supported Bluetooth-related AT commands in alphabetical order:

Command	Function	Page
AT+BINP	Phone number corresponding to the last voice tag recorded in the HF	86
AT+BLDN	Redial Last Number	86
AT+BVRA	Voice Recognition Activation	87
AT+NREC	Noise Reduction and Echo Canceling	87
AT+VGS	Gain of the Speaker Volume	86

Table 2-5: Supported Bluetooth-related commands

Table 2-6 lists all the supported Siemens-specific AT commands in alphabetical order:

Command	Function	Page
AT^SACM	Output ACM (accumulated call meter) and ACMmax	89
AT^SBNR	Binary Read	90
AT^SBNW	Binary Write	91
AT^SCID	Output card ID	92
AT^SCKS	Output SIM card status	92
AT^SCNI	Output call number information	92
AT^SDBR	Database Read	93
AT^SDLD	Delete the "last number redial" memory	93
AT^SGAUTH	Select Type of Authentication for PPP connection	94
AT^SICO	Icon control	94
AT^SLCK	Switch locks (including user-defined locks) on and off	95
AT^SLNG	Language settings	96
AT^SMGO	SMS overflow indicator	97
AT^SMGL	List SMS (without status change from <i>unread</i> to <i>read</i>)	96
AT^SMGR	Read SMS (without status change from <i>unread</i> to <i>read</i>)	97
AT^SMSO	Switch device off	98
AT^SNFS	Select NF hardware	100
AT^SNFV	Set the volume	100
AT^SPBC	Seek the first entry in the sorted telephone book which begins with the selected (or next available) letter	101
AT^SPBG	Read entry from the sorted telephone book via the sorted index	101
AT^SPBS	Select a telephone book (including Siemens-specific books)	102
AT^SPIC	Output PIN counter	102
AT^SPLM	Read the PLMN	103
AT^SPLR	Read an entry from the preferred-operator	103
AT^SPLW	Write an entry to the preferred-operator	103
AT^SPST	Play Signal Tone	104
AT^SPWD	Change password to a lock (including user-defined locks)	104
AT^SSET	Profile Settings Control (SET Melody and Picture settings in Mobile)	105
AT^SSOC	Sound Control (PLAY/STOP SOUND)	106
AT^SSTK	SIM Toolkit	107

Table 2-6: Supported Siemens-specific commands

2.2 The AT command set

GSM mobile telephones and modems can be operated via Remote Control using a serial interface (data cable or infrared connection). Remote control is implemented by means of AT+C commands according to the ETSI GSM 07.07 [1] and GSM 07.05 [4] specifications, as well as several manufacturer-specific AT commands. These commands are described in more detail in section 2.2.2.

A command entered at the user port generally begins with an 'AT' command prefix. The remainder of the line is interpreted as a sequence of the commands described below. The commands are not case-sensitive. More than one command may be given on a single line, with the semicolon serving as the delimiter between commands.

The "ITU-T Draft new Recommendation V.25ter" specification [5] applies to the sequence of the interface commands. According to this guideline, commands should begin with the character string "AT" and end with "<CR>" (= 0x0D). The input of a command is acknowledged by the display of "OK" or "ERROR".

A command currently in process is interrupted by each additional character entered. This means that you should not enter the next command until you have received the acknowledgment; otherwise the current command is interrupted.

The commands supported are listed in the tables provided in sections 2.2.1, and 2.3.1 through 2.3.9.15.

2.2.1 Hayes Standard commands

The Hayes standard commands correspond to the commands of AT Hayes compatible modems.

All commands in Table 2-7 expect a numeric argument; if this argument is omitted, the default of 0 is assumed.

The ATD command is a special command in that all characters specified in the same line (or up to a semicolon) are considered part of the number to dial.

Command	Function																
AT...	Prefix for all commands																
ATA	Accept call (V.25ter, according to [5])																
ATB[n]	This modem command is used to set the bearer service for data connections (cf. AT+CBST). <n> can take one of the following values: <table border="0"> <tr> <td>7</td> <td>2400bps, asynchronous, V.22bis</td> </tr> <tr> <td>11</td> <td>4800bps, asynchronous, V.32</td> </tr> <tr> <td>13</td> <td>9600bps, asynchronous, 32</td> </tr> <tr> <td>15</td> <td>14400bps, asynchronous, V.34</td> </tr> <tr> <td>25</td> <td>2400bps, asynchronous, V.110 ISDN</td> </tr> <tr> <td>27</td> <td>4800bps, asynchronous, V.110 ISDN</td> </tr> <tr> <td>29</td> <td>9600bps, asynchronous, V.110 ISDN</td> </tr> <tr> <td>31</td> <td>14400bps, asynchronous, V.110 ISDN</td> </tr> </table>	7	2400bps, asynchronous, V.22bis	11	4800bps, asynchronous, V.32	13	9600bps, asynchronous, 32	15	14400bps, asynchronous, V.34	25	2400bps, asynchronous, V.110 ISDN	27	4800bps, asynchronous, V.110 ISDN	29	9600bps, asynchronous, V.110 ISDN	31	14400bps, asynchronous, V.110 ISDN
7	2400bps, asynchronous, V.22bis																
11	4800bps, asynchronous, V.32																
13	9600bps, asynchronous, 32																
15	14400bps, asynchronous, V.34																
25	2400bps, asynchronous, V.110 ISDN																
27	4800bps, asynchronous, V.110 ISDN																
29	9600bps, asynchronous, V.110 ISDN																
31	14400bps, asynchronous, V.110 ISDN																

ATD<str>;	Dial the dialing string <str> with the voice utility Valid dial modifiers: I restrict AT+CLIR i suppress AT+CLIR) for next call T tone dialing P pulse dialing is ignored The finishing character ";" indicates to the phone that the call is to be set up with the voice utility. Otherwise, an attempt is made to set up a data call, which the phone immediately acknowledges with "ERROR". The dial command returns OK to the user immediately after starting a voice call. Other behavior like *# sequences in the dial command, and also data calls remain unchanged. See also section 2.8.3
ATD><n>;	Dial the telephone number from the current telephone book location number <n> The telephone book is selected using the AT+CPBS (or AT^SPBS) command.
ATD><mem><n>;	Dial the telephone number from the telephone book <mem> location number <n>
ATDx[;]	Dial phone number x I ISDN The phone call will be made as a UDI call. An ISDN connection to a V.110 terminal adapter will be established. The data transmission speed is the same as for an "analog" call (2400 / 4800 / 9600 / 14400 bps). PP Plus: same as + character
ATDL	Dial last telephone number
ATE0	Deactivate command echo
ATE1	Activate command echo
ATH[0]	Release existing connection
ATI[n]	Modem command according to [5]: Display product code: 0 042 1 042 2 OK, (check firmware checksum) 8 Display supported operation modes (see ATB) 9 identification of modem and mobile phone
ATL[n]	Monitor speaker loudness (modem command according to [5])
ATM[n]	Monitor speaker mode (modem command according to [5])
ATO[n]	Switch back to transparent mode after +++ interruption (modem command according to [5])
ATQ0	Display acknowledgments (responses or messages)
ATQ1	Suppress acknowledgments (responses or messages)
ATSn=x	Write value x to S register n (modem command according to [5])
ATSn?	Display value of S register n (modem command according to [5]) Note: This type of mobile phone does not allow the values of all S registers to be displayed with a single command
ATV0	Display acknowledgments as numbers
ATV1	Display acknowledgments as text

ATX<n>	<p>Report link with CONNECT only ignore busy signal</p> <p><n> can take one of the following values:</p> <ul style="list-style-type: none"> 1 Report link with CONNECT plus baud rate, ignore busy signal 2 same as ATX1 3 same as ATX, but report BUSY 4 same as ATX, t report BUSY
ATZ	Set to default configuration
AT&C<n>	<p>Circuit 109 (Received line signal detector / DCD) behavior</p> <p><n> can take one of the following values:</p> <ul style="list-style-type: none"> 0 DCD always ON 1 DCD ON if carrier detected
AT&D[n]	<p>Circuit 108 (Data terminal ready / DTR) behavior</p> <p>Note: The AT&D<n> commands described below take no effect since circuit 108 is not supported in this type of mobile phone. See section 2.7 for more information on which circuit assignments are supported.</p> <p><n> can take one of the following values:</p> <ul style="list-style-type: none"> 0 DTR ignored 1 On DTR ON to OFF: go to online command mode, don't disconnect 2 On DTR ON to OFF: disconnect go to command mode. Automatic answer is disabled while DTR OFF.
AT&F[0]	<p>Resets all current parameters of the following AT commands to their factory profile:</p> <p>ATE, ATQ, ATV, ATX AT+CBST, AT+CRLP, AT+CRC, AT+CR, AT+CNMI, AT+CMEE, AT+CSMS, AT^SCKS, AT^SACM, AT+CREG, AT+CLIP</p> <ul style="list-style-type: none"> • S parameters • AT&D; AT&C; AT&S <p>Any existing connections will be terminated. No other commands are accepted on the same command line.</p>
\N	<p>No action (\N2 - \N6)</p> <p>\N2</p> <p>\N3</p> <p>\N4</p> <p>\N5</p> <p>\N6</p>

\Q<n	Local flow control selection (DTE ↔ DCE); can be customized <n> can take one of the following values: 0 Disable flow control 1 XON-XOFF software flow control 2 CTS only flow control 3 RTS/CTS flow control
\V[n]	Modem command 0 No /REL or /RLP appendix with the CONNECT message 1 /REL or /RLP appendix with the CONNECT message

Table 2-7: Commands supported according to Hayes standard

2.2.2 Command combinations to be avoided

It is possible to specify more than a single command in the command line at any one time; however, not all command combinations will have the expected result. To ensure that responses to commands will be displayed in the order expected, the following command combinations should be avoided:

- V25ter commands combined with FAX commands
- GSM 7.07 commands combined with Siemens-specific commands
- GSM 7.05 commands (SMS) specified stand-alone

2.3 AT commands and responses according to GSM 07.07 and GSM 07.05

According to GSM, it is possible to execute an AT command in various forms, as follows:

Test command	AT+CXXX=?	The mobile phone or modem responds by sending the list of parameters and value ranges; these can be set using the corresponding Write command or by means of internal processes
Read command	AT+CXXX?	This command displays the current value setting of the parameter(s).
Write command	AT+CXXX=<...>	This command is used to set parameters that can be set.
Execute command	AT+CXXX	This command reads non-settable parameters which are influenced by internal processes in the mobile phone or modem

Table 2-8: Conventions applying to the presentation of AT commands

2.3.1 General commands according to GSM 07.07

This section provides the descriptions of general GSM 07.07 commands.

2.3.1.1 ATO

ATO	Return to online data state
Execute command ATO	Response CONNECT/ NO CARRIER/ERROR

2.3.1.2 AT+CGMI

AT+CGMI	Issue manufacturer ID code
Test command AT+CGMI=?	Response OK
Execute command AT+CGMI	Response <manufacturer> Parameter <manufacturer> Name of manufacturer (SIEMENS)

2.3.1.3 AT+CGMM

AT+CGMM	Issue model ID code
Test command AT+CGMM=?	Response OK
Execute command AT+CGMM	Response <model> Parameter <model> Name of telephone (MOBILE)

2.3.1.4 AT+CGMR

AT+CGMR	Output the GSM telephone version
Test command AT+CGMR=?	Response OK
Execute command AT+CGMR	Response <revision> Parameter <revision> Version of the telephone software

2.3.1.5 AT+CGSN

AT+CGSN	Output the serial number (IMEI)
Test command AT+CGSN=?	Response OK
Execute command AT+CGSN	Response <sn> Parameter <sn> IMEI of the telephone

2.3.1.6 AT+CIMI

AT+CIMI	Output of IMSI
Test command AT+CIMI=?	Response OK
Execute command AT+CIMI	Response <imsi> Parameter <imsi> International Mobile Subscriber Identity (IMSI)

2.3.1.7 AT+CKPD

AT+CKPD	Keypad control
Test command AT+CKPD=?	Response OK/ERROR/+CME ERROR
Write command AT+CKPD=<keys>[,<time>[,<pause>]]	
Parameter <keys>	string of characters representing keys (see section 3.4 for a list of implemented keys)
<time>	0...255 time in tenths of seconds (0.1 seconds) that each key must be pressed
	3 Default: = 0.3 sec
<pause>	0...255 length of pause in tenths of seconds (*0.1 seconds) that may elapse between two key presses
Response	OK/ERROR/+CME ERROR

2.3.1.8 AT+CSCS

AT+CSCS	Select TE character set
Test command AT+CSCS=?	Response +CSCS: (list of supported <chset>s) OK
Read command AT+CSCS?	Response +CSCS: <chset> OK/ERROR/+CME ERROR Parameter <chset> String; determines which TE character set is used ("GSM"/"UCS2")
Write command AT+CSCS=[<chset>]	Response OK/ERROR/+CME ERROR

2.3.1.9 AT+GSN

AT+GSN	Output the serial number (IMEI)
Test command AT+GSN=?	Response OK
Execute command AT+GSN	Response +GSN: <sn> Parameter <sn> IMEI of the telephone

2.3.1.10 AT+WS46

AT+WS46	Select wireless network
Test command AT+WS46=?	Response (list of supported <n>s) OK
Read command AT+WS46?	Response <n> OK/ERROR/+CME ERROR Parameter <n> Integer; WDS side stack 12 GSM digital cellular
Write command AT+WS46=[<n>]	Response OK/ERROR/+CME ERROR

2.3.2 Call control commands

This section provides the descriptions of commands related to call control.

2.3.2.1 AT+CEER

AT+CEER	Query the reason for disconnection of last call
Test command AT+CEER=?	Response OK
Execute command AT+CEER	Response +CEER: <report> Parameter Reason for disconnection, reported as numbers. For detailed <report> information on GPRS values see section 3.3.

2.3.2.2 AT+CHUP

AT+CHUP	Terminate call
Test command AT+CHUP=?	This command terminates all active calls and all calls on hold. Response OK
Execute command AT+CHUP	Response OK/ERROR

2.3.2.3 AT+CR

AT+CR	Service reporting control
Test command AT+CR=?	Response +CR: (list of supported <mode>s) OK/ERROR/+CME ERROR Parameter 0 disables reporting <mode> 1 enables reportingOK/ERROR/+CME ERROR
Read command AT+CR?	Response +CR: <mode> OK/ERROR/+CME ERROR Parameter <mode> See Test command
Write command AT+CR=<mode>	Parameter <mode> See Test command Response OK/ERROR/+CME ERROR

2.3.2.4 AT+CRC

AT+CRC	Cellular result codes
Test command AT+CRC=?	Response +CRC: (list of supported <mode>s) OK/ERROR/+CME ERROR Parameter 0 disables reporting <mode> 1 enables reportingOK/ERROR/+CME ERROR
Read command AT+CRC?	Response +CRC: <mode> OK/ERROR/+CME ERROR Parameter <mode> See Test command
Write command AT+CRC=<mode>	Parameter <mode> See Test command Response OK/ERROR/+CME ERROR

2.3.3 Network service related commands

This section provides the descriptions of commands related to network service.

2.3.3.1 AT+CAOC

AT+CAOC	Advice of charge
Test command AT+CAOC=?	Response +CAOC: (list of supported <mode>s) Parameter <mode> 0 query CCM value
Read command AT+CAOC?	Response +CAOC: <mode> Parameter <mode> See Test command
Write command AT+CAOC=<mode>	Response OK Parameter <mode> 0 See Test command Parameter <mode> See Test command
Execute command AT+CAOC	Response +CAOC: <ccm> OK/ERROR/+CME ERROR Parameter Updated hexadecimal call meter, measured in home units; coding <ccm> in analogy to ACMmax on the SIM

2.3.3.2 AT+CCFC

AT+CCFC	Call forwarding
Test command AT+CCFC=?	Response +CCFC: (list of supported <reas>s) OK/ERROR/+CME ERROR Parameter <reas> 0 Always 1 If busy 2 If no answer 3 If not available 4 All reasons (0-3) 5 All conditional reasons (1-3)
Write command AT+CCFC=<reas>, <mode>[, <num>[,<type>[,<class>[,,,<time>]]]]	Parameter <reas> See Test command <mode> 1 Deactivate 2 Activate 3 Query 4 Install 5 Delete <num> Telephone number <type> Type of telephone number <class> 1 Voice 2 Data 4 Fax 7 Voice, Data and FAX (default) 8 SMS 16 data circuit sync 32 data circuit async 64 dedicated packet access 128 dedicated PAD access X combination of some of the above classes, e.g. 255 regroupes all classes and 5 regroupes Voice and FAX <time> 1-30 Time, rounded to a multiple of five seconds Response If <mode>=2 and command is successful +CCFC:<status>,<class1>[,<num>,<type>[,,,<time>]]][<CR><LF> +CCFC:....] OK/ERROR/+CME ERROR Parameter <status> 0 Inactive 1 Active

2.3.3.4 AT+CHLD

AT+CHLD	Call hold and multiparty														
Test command AT+CHLD=?	Response +CHLD: (list of supported <n>s) OK/ERROR/+CME ERROR														
Write command AT+CHLD=[<n>]	Parameter <n> <table border="1" data-bbox="659 453 1365 772"> <tr> <td data-bbox="659 453 732 485">0</td> <td data-bbox="740 453 1365 506">Terminates all held calls or sets UDUB (User Determined User Busy) for a waiting call</td> </tr> <tr> <td data-bbox="659 512 732 543">1</td> <td data-bbox="740 512 1365 564">Terminates all active calls (if there are any) and accepts the other call (waiting call or held call)</td> </tr> <tr> <td data-bbox="659 571 732 602">1<x></td> <td data-bbox="740 571 1365 602">Terminates call number <x> (x= 1-7)</td> </tr> <tr> <td data-bbox="659 609 732 640">2</td> <td data-bbox="740 609 1365 661">Puts all active calls on hold (if there are any) and accepts the other call (waiting call or held call) as active</td> </tr> <tr> <td data-bbox="659 667 732 699">2<x></td> <td data-bbox="740 667 1365 720">Puts all active calls except call X (X= 1-7) on hold (split</td> </tr> <tr> <td data-bbox="659 726 732 758">3</td> <td data-bbox="740 726 1365 758">Connects the call put on hold to the active call</td> </tr> <tr> <td data-bbox="659 764 732 795">4</td> <td data-bbox="740 764 1365 795">Call transfer</td> </tr> </table> <p data-bbox="464 806 1365 890">In conflict situations, the action is always applied to the waiting call. For terminating: Use the "AT+CHUP" command to terminate all calls except waiting calls</p> <p data-bbox="464 896 1365 949">Note: The scope of this command depends on the SIM clearing and/or on the network support</p> <p data-bbox="464 955 1365 991">Response OK/ERROR/+CME ERROR</p>	0	Terminates all held calls or sets UDUB (U ser D etermined U ser B usy) for a waiting call	1	Terminates all active calls (if there are any) and accepts the other call (waiting call or held call)	1<x>	Terminates call number <x> (x= 1-7)	2	Puts all active calls on hold (if there are any) and accepts the other call (waiting call or held call) as active	2<x>	Puts all active calls except call X (X= 1-7) on hold (split	3	Connects the call put on hold to the active call	4	Call transfer
0	Terminates all held calls or sets UDUB (U ser D etermined U ser B usy) for a waiting call														
1	Terminates all active calls (if there are any) and accepts the other call (waiting call or held call)														
1<x>	Terminates call number <x> (x= 1-7)														
2	Puts all active calls on hold (if there are any) and accepts the other call (waiting call or held call) as active														
2<x>	Puts all active calls except call X (X= 1-7) on hold (split														
3	Connects the call put on hold to the active call														
4	Call transfer														

2.3.3.6 AT+CLCK

AT+CLCK	Switch locking on and off Revision to GSM 07.07 according to CR TDOC ETSI/SMG4 187/96																																													
<p>Test command AT+CLCK=?</p>	<p>Response +CLCK: (list of supported <fac>s) OK/ERROR/+CME ERROR</p> <p>Parameter <fac></p> <table border="1"> <tr><td>CS</td><td>Keyboard lock</td></tr> <tr><td>PS</td><td>Phone locked to SIM (device code)</td></tr> <tr><td>SC</td><td>SIM card (PIN)</td></tr> <tr><td>FD</td><td>FDN lock</td></tr> <tr><td>AO</td><td>BAOC (bar all outgoing calls)</td></tr> <tr><td>OI</td><td>BOIC (bar outgoing international calls)</td></tr> <tr><td>OX</td><td>BOIC-exHC (bar outgoing international calls except to home country)</td></tr> <tr><td>AI</td><td>BAIC (bar all incoming calls)</td></tr> <tr><td>IR</td><td>BIC-Roam (bar incoming calls when roaming outside the home country)</td></tr> <tr><td>AB</td><td>All Barring services</td></tr> <tr><td>AG</td><td>All outgoing barring services</td></tr> <tr><td>AC</td><td>All incoming barring services</td></tr> </table>	CS	Keyboard lock	PS	Phone locked to SIM (device code)	SC	SIM card (PIN)	FD	FDN lock	AO	BAOC (bar all outgoing calls)	OI	BOIC (bar outgoing international calls)	OX	BOIC-exHC (bar outgoing international calls except to home country)	AI	BAIC (bar all incoming calls)	IR	BIC-Roam (bar incoming calls when roaming outside the home country)	AB	All Barring services	AG	All outgoing barring services	AC	All incoming barring services																					
CS	Keyboard lock																																													
PS	Phone locked to SIM (device code)																																													
SC	SIM card (PIN)																																													
FD	FDN lock																																													
AO	BAOC (bar all outgoing calls)																																													
OI	BOIC (bar outgoing international calls)																																													
OX	BOIC-exHC (bar outgoing international calls except to home country)																																													
AI	BAIC (bar all incoming calls)																																													
IR	BIC-Roam (bar incoming calls when roaming outside the home country)																																													
AB	All Barring services																																													
AG	All outgoing barring services																																													
AC	All incoming barring services																																													
<p>Write command AT+CLCK=<fac>, <mode>[, <passwd>[,<class>]]</p> <p>(Continued next page)</p>	<p>Parameter</p> <table border="1"> <tr><td><fac></td><td></td><td>See Test command</td></tr> <tr><td><mode></td><td>0</td><td>Cancels lock</td></tr> <tr><td></td><td>1</td><td>Activates lock</td></tr> <tr><td></td><td>2</td><td>Queries lock status</td></tr> <tr><td><passwd></td><td></td><td>Password</td></tr> <tr><td><class></td><td>1</td><td>Voice</td></tr> <tr><td></td><td>2</td><td>Data</td></tr> <tr><td></td><td>4</td><td>Fax</td></tr> <tr><td></td><td>7</td><td>Voice, Data and FAX (default)</td></tr> <tr><td></td><td>8</td><td>SMS</td></tr> <tr><td></td><td>16</td><td>data circuit sync</td></tr> <tr><td></td><td>32</td><td>data circuit async</td></tr> <tr><td></td><td>64</td><td>dedicated packet access</td></tr> <tr><td></td><td>128</td><td>dedicated PAD access</td></tr> <tr><td></td><td>X</td><td>combination of some of the above classes, e.g. 255 regroups all classes and 5 regroups Voice and FAX</td></tr> </table>	<fac>		See Test command	<mode>	0	Cancels lock		1	Activates lock		2	Queries lock status	<passwd>		Password	<class>	1	Voice		2	Data		4	Fax		7	Voice, Data and FAX (default)		8	SMS		16	data circuit sync		32	data circuit async		64	dedicated packet access		128	dedicated PAD access		X	combination of some of the above classes, e.g. 255 regroups all classes and 5 regroups Voice and FAX
<fac>		See Test command																																												
<mode>	0	Cancels lock																																												
	1	Activates lock																																												
	2	Queries lock status																																												
<passwd>		Password																																												
<class>	1	Voice																																												
	2	Data																																												
	4	Fax																																												
	7	Voice, Data and FAX (default)																																												
	8	SMS																																												
	16	data circuit sync																																												
	32	data circuit async																																												
	64	dedicated packet access																																												
	128	dedicated PAD access																																												
	X	combination of some of the above classes, e.g. 255 regroups all classes and 5 regroups Voice and FAX																																												

<p>Cont.</p>	<p>Response If <mode>=2 and command is successful +CLCK: <status>[,<class1>[<CR><LF> +CLCK: <status>, class2....]] OK/ERROR/+CME ERROR Parameter <status> 0 Off 1 On</p>
	<p>Note: If no device code ("PS") has previously been entered, at+clck=ps,2 will return an error. It is possible to set a new device code or to delete it using the AT+CPWD command.</p>

2.3.3.8 AT+CLIR

AT+CLIR		Select Incognito Mode (Call Line Identification Restriction)
Test command AT+CLIR=?	Response +CLIR: (list of supported <n>s) OK/ERROR/+CME ERROR	Parameter <n>
		0 Presentation indicator is used according to network
		1 CLIR invocation (incognito)
		2 CLIR suppression (not incognito)
Read command AT+CLIR?	Response +CLIR: <n>, <m> OK/ERROR/+CME ERROR	Parameter <n>
		See Test command
		<m>
		0 CLIR not provisioned (not incognito)
		1 CLIR provisioned in permanent mode (incognito)
		2 Unknown
		3 CLIR temporarily mode presentation restricted (next call incognito)
		4 CLIR temporarily mode presentation allowed (next call not incognito)
Write command AT+CLIR=[<n>]	Parameter <n> Response OK/ERROR/+CME ERROR	See Read command

2.3.3.11 AT+COPN

AT+COPN	Read operator names
Test command AT+COPN=?	Response OK
Execute command AT+COPN	Response +COPN:numeric <oper>,long alphanumeric <oper><CR><LF> +COPN:..... OK/ERROR/+CME ERROR
	Parameter <oper> Network operator in numeric and alphanumeric notation see AT^SPLM

2.3.3.12 AT+COPS

AT+COPS	Commands concerning selection of network operator
Test command AT+COPS=?	Response +COPS: [list of supported (<stat>,long alphanumeric <oper>,,numeric <oper>)s][,.(list of supported <mode>s),(list of supported <format>s)] OK/ERROR/+CME ERROR
	Parameter <stat> 0 Unknown 1 Useful network operator 2 Used network operator 3 Prohibited network operator
	<oper> Operator in the format according to <mode>
	<mode> 0 Automatic mode 1 Manual selection of network operator 3 Setting of format 4 Automatic, manual selected
	<format> 0 Long alphanumeric 2 Numeric <oper>
Read command AT+COPS?	Response +COPS: <mode>[,<format>,<oper>] OK/ERROR/+CME ERROR
	Parameter <mode> See Test command
	<format> See Test command
	<oper> Network operator
Write command AT+COPS=<mode>[,<format>[,<oper>]]	Parameter <mode> See Test command
	<format> See Test command
	If <mode> = 1, <format> can only = 2
	<oper> In numeric form only
	Response OK/ERROR/+CME ERROR

2.3.3.13 AT+CPOL

AT+CPOL	Preferred operator list
Test command AT+CPOL=?	Response +CPOL: (list of supported <index>s),(list of supported <format>s)
	Parameter <index> the order number of operator in the SIM preferred operator list <format> 2 numeric
Read command AT+CPOL?	Response +CPOL: <index>, <format>,<operator><CR><LF> +CPOL:..... OK/ERROR/+CME ERROR Parameter <index> See Test command <format> See Test command
Write command AT+CPOL=[<index>][, <format>[,<oper>]]	Parameter <index> See Test command <format> See Test command <oper> operator Response OK/ERROR/+CME ERROR

2.3.3.14 AT+CPWD

AT+CPWD	Change password to a lock																								
Test command AT+CPWD=?	<p>Response +CPWD: list of supported (<fac>, <pwdlength>)s OK/ERROR/+CME ERROR</p> <p>Parameter <fac></p> <table> <tr><td>CS</td><td>Keyboard lock</td></tr> <tr><td>PS</td><td>Phone locked to SIM (device code)</td></tr> <tr><td>SC</td><td>SIM card (PIN)</td></tr> <tr><td>P2</td><td>PIN2</td></tr> <tr><td>AO</td><td>BAOC (bar all outgoing calls)</td></tr> <tr><td>OI</td><td>BOIC (bar outgoing international calls)</td></tr> <tr><td>OX</td><td>BOIC-exHC (bar outgoing international calls except to home country)</td></tr> <tr><td>AI</td><td>BAIC (bar all incoming calls)</td></tr> <tr><td>IR</td><td>BIC-Roam (bar incoming calls when roaming outside the home country)</td></tr> <tr><td>AB</td><td>All Barring services</td></tr> <tr><td>AG</td><td>All outgoing barring services</td></tr> <tr><td>AC</td><td>All incoming barring services</td></tr> </table> <p><pwdlength> Password length</p>	CS	Keyboard lock	PS	Phone locked to SIM (device code)	SC	SIM card (PIN)	P2	PIN2	AO	BAOC (bar all outgoing calls)	OI	BOIC (bar outgoing international calls)	OX	BOIC-exHC (bar outgoing international calls except to home country)	AI	BAIC (bar all incoming calls)	IR	BIC-Roam (bar incoming calls when roaming outside the home country)	AB	All Barring services	AG	All outgoing barring services	AC	All incoming barring services
CS	Keyboard lock																								
PS	Phone locked to SIM (device code)																								
SC	SIM card (PIN)																								
P2	PIN2																								
AO	BAOC (bar all outgoing calls)																								
OI	BOIC (bar outgoing international calls)																								
OX	BOIC-exHC (bar outgoing international calls except to home country)																								
AI	BAIC (bar all incoming calls)																								
IR	BIC-Roam (bar incoming calls when roaming outside the home country)																								
AB	All Barring services																								
AG	All outgoing barring services																								
AC	All incoming barring services																								
Write command AT+CPWD=<fac>,<oldpwd>,<newpwd>	<p>Parameter <fac> See Test command</p> <p><oldpwd> Existing password</p> <p><newpwd> New password</p> <p>Note</p> <table> <tr> <td>PS</td> <td>Phone Code (device code)</td> </tr> <tr> <td>AT+CPWD="PS",,<newpwd></td> <td>if no password has yet been entered</td> </tr> <tr> <td>AT+CPWD="PS",<oldpwd></td> <td>to delete password</td> </tr> </table> <p>Response OK/ERROR/+CME ERROR</p>	PS	Phone Code (device code)	AT+CPWD="PS",,<newpwd>	if no password has yet been entered	AT+CPWD="PS",<oldpwd>	to delete password																		
PS	Phone Code (device code)																								
AT+CPWD="PS",,<newpwd>	if no password has yet been entered																								
AT+CPWD="PS",<oldpwd>	to delete password																								

2.3.3.15 AT+CREG

AT+CREG	Network registration
Test command AT+CREG=?	Response +CREG: (list of supported <n>s) OK/ERROR/+CME ERROR Parameter <n> 0 Suppresses the unexpected network status messages 1 Displays the unexpected network status messages 2 Enables unexpected network registration and location information messages OK/ERROR/+CME ERROR
Read command AT+CREG?	Response +CREG: <n>,<stat>[,<lac>,<ci>] OK/ERROR/+CME ERROR Parameter <n> See Test command <stat> 0 Not checked in, not seeking 1 Checked in 2 Not checked in, but seeking a network 3 Check-in denied by network 4 Unknown 5 Registered, roaming _____ <lac> Hexadecimal 2-byte string type of location area code _____ <ci> Hexadecimal 2-byte string type of cell ID
Write command AT+CREG=<n>	Response OK/ERROR/+CME ERROR Parameter <n> See Test command _____ Unsolicited message +CREG: <stat>

2.3.3.16 AT+CSSN

AT+CSSN	Supplementary service notifications Revision according to GSM 07.07 Version 5.0.0												
Test command AT+CSSN=?	<p>Response +CSSN: (list of supported <n>s), (list of supported <m>s)</p> <p>Parameter</p> <table border="0"> <tr> <td><n></td> <td>0</td> <td>Suppresses the +CSSI messages</td> </tr> <tr> <td></td> <td>1</td> <td>Activates the +CSSI messages</td> </tr> <tr> <td><m></td> <td>0</td> <td>Suppresses the +CSSU messages</td> </tr> <tr> <td></td> <td>1</td> <td>Activates the +CSSU messages</td> </tr> </table> <p>For +CSSI/+CSSU messages supported, see section 2.4.3 below.</p>	<n>	0	Suppresses the +CSSI messages		1	Activates the +CSSI messages	<m>	0	Suppresses the +CSSU messages		1	Activates the +CSSU messages
<n>	0	Suppresses the +CSSI messages											
	1	Activates the +CSSI messages											
<m>	0	Suppresses the +CSSU messages											
	1	Activates the +CSSU messages											
Read command AT+CSSN?	<p>Response +CSSN: <n>,<m></p> <p>Parameter</p> <table border="0"> <tr> <td><n></td> <td>See Test command</td> </tr> <tr> <td><m></td> <td>See Test command</td> </tr> </table>	<n>	See Test command	<m>	See Test command								
<n>	See Test command												
<m>	See Test command												
Write command AT+CSSN=<n>[,<m>]	<p>Parameter</p> <table border="0"> <tr> <td><n></td> <td>See Test command</td> </tr> <tr> <td><m></td> <td>See Test command</td> </tr> </table> <p>Unsolicited message +CSSI: <code1> +CSSU: <code2></p> <p>Parameter</p> <table border="0"> <tr> <td><code1></td> <td>3</td> <td>Intermediate result code Waiting call is pending</td> </tr> <tr> <td><code2></td> <td>5</td> <td>Unsolicited result code Held call was terminated</td> </tr> </table>	<n>	See Test command	<m>	See Test command	<code1>	3	Intermediate result code Waiting call is pending	<code2>	5	Unsolicited result code Held call was terminated		
<n>	See Test command												
<m>	See Test command												
<code1>	3	Intermediate result code Waiting call is pending											
<code2>	5	Unsolicited result code Held call was terminated											

2.3.4 Commands related to mobile equipment control and status

This section provides the descriptions of commands related to network service.

2.3.4.1 AT+CACM

AT+CACM	Accumulated call meter
Test command AT+CACM=?	Response OK
Read command AT+CACM?	Response +CACM: <acm> OK/ERROR/+CME ERROR Parameter <acm> Accumulated call meter in hexadecimal format, measured in home units; coding analogous to ACMmax on the SIM
Write command AT+CACM=[<passwd>]	Response OK/ERROR/+CME ERROR Parameter <passwd> String type; usually PIN2

2.3.4.2 AT+CALM

AT+CALM	Alert sound mode
Test command AT+CALM=?	Response +CALM: (list of supported <mode>s) OK
Read command AT+CALM?	Response +CALM: <mode> OK/ERROR/+CME ERROR
Write command AT+CALM=<mode>	Response OK/ERROR/+CME ERROR Parameter <mode> 0 normal mode 1 silent mode (all sounds are prevented) 2 beep (only a short beep indicates an incoming call)

2.3.4.3 AT+CAMM

AT+CAMM		Accumulated call meter maximum
Test command AT+CAMM=?	Response OK	
Read command AT+CAMM?	Response +CAMM: <acmmax> OK/ERROR/+CME ERROR Parameter Accumulated call meter maximum in hexadecimal format, measured <acmmax> in home units; coding analogously to ACMmax on the SIM	
Write command AT+CAMM=[<acmmax>[,<passwd>]]		
	Response OK/ERROR/+CME ERROR	
	Parameter <acmmax>	see Read command
	<passwd>	String type; usually PIN2

2.3.4.4 AT+CBC

AT+CBC		Battery charge
Test command AT+CBC=?	Response +CBC: (list of supported <bcs>s),(list of supported <bcl>s) OK/ERROR/+CME ERROR Parameter	
	<bcs>	0 ME is supplied from battery 1 ME has battery but is not supplied from there 2 ME has no battery connected 3 Error
	<bcl>	0 Battery is flat, no more actions are possible 1-100 charge in per cent
Execute command AT+CBC	Response +CBC: <bcs>,<bcl>	

2.3.4.5 AT+CCLK

AT+CCLK		Clock
Test command AT+CCLK=?	Response OK	
Read command AT+CCLK?	Response +CCLK: <time> OK/ERROR/+CME ERROR Parameter: string type value; format is "yy/MM/dd,hh:mm:ss", where characters indicate the year (last two digits), month, day, hour, minutes; e.g. 6th of May 1994, 22:10:00 hours is expressed as "94/05/06,22:10:00"	
Write command AT+CCLK=<time>	Response OK/ERROR/+CME ERROR Parameter: <time> see Test command	

2.3.4.6 AT+CIND

AT+CIND	Indicator Control																																				
Test command AT+CIND=?	<p>Response</p> <p>+CIND: ("battchg",(0-5)), ("signal",(0-5)), ("service",(0,1)), ("message",(0,1)), ("call",(0,1)), ("roam",(0,1)), ("smsfull",(0,1))</p> <p>OK/ERROR/+CME ERROR</p> <p>Parameter</p> <table border="1"> <tr> <td><battchg></td> <td>0 .. 5</td> <td>battery charge level (0 = empty, 5 = full)</td> </tr> <tr> <td><signal></td> <td>0 .. 5</td> <td>quality of signal (0 = not detectable , 5 = good)</td> </tr> <tr> <td><service></td> <td>0</td> <td>Service not available</td> </tr> <tr> <td></td> <td>1</td> <td>Service available</td> </tr> <tr> <td><message></td> <td>0</td> <td>No unread message in memory storage</td> </tr> <tr> <td></td> <td>1</td> <td>At least one unread message INFOBRIEF storage</td> </tr> <tr> <td><call></td> <td>0</td> <td>No call in progress or established</td> </tr> <tr> <td></td> <td>1</td> <td>call in progress or established</td> </tr> <tr> <td><roam></td> <td>0</td> <td>Home network, no roaming</td> </tr> <tr> <td></td> <td>1</td> <td>roaming</td> </tr> <tr> <td><smsfull></td> <td>0</td> <td>memory locations are available</td> </tr> <tr> <td></td> <td>1</td> <td>a short message memory storage in the MT has become full</td> </tr> </table> <p>Remark: The test option returns the supported values which are issued as unsolicited result code of each indicator. It does NOT return the supported values to set an indicator. Each indicator can be switched on (1) or off (0).</p>	<battchg>	0 .. 5	battery charge level (0 = empty, 5 = full)	<signal>	0 .. 5	quality of signal (0 = not detectable , 5 = good)	<service>	0	Service not available		1	Service available	<message>	0	No unread message in memory storage		1	At least one unread message INFOBRIEF storage	<call>	0	No call in progress or established		1	call in progress or established	<roam>	0	Home network, no roaming		1	roaming	<smsfull>	0	memory locations are available		1	a short message memory storage in the MT has become full
<battchg>	0 .. 5	battery charge level (0 = empty, 5 = full)																																			
<signal>	0 .. 5	quality of signal (0 = not detectable , 5 = good)																																			
<service>	0	Service not available																																			
	1	Service available																																			
<message>	0	No unread message in memory storage																																			
	1	At least one unread message INFOBRIEF storage																																			
<call>	0	No call in progress or established																																			
	1	call in progress or established																																			
<roam>	0	Home network, no roaming																																			
	1	roaming																																			
<smsfull>	0	memory locations are available																																			
	1	a short message memory storage in the MT has become full																																			
Read command AT+ CIND?	<p>Response</p> <p>+CIND: <ind1>,<stat1>,... <ind7>,<stat7></p> <p>OK/ERROR/+CME ERROR</p> <p>Parameter</p> <table border="1"> <tr> <td><ind=1></td> <td>battery charge</td> </tr> <tr> <td><ind=2></td> <td>signal quality</td> </tr> <tr> <td><ind=3></td> <td>service</td> </tr> <tr> <td><ind=4></td> <td>message</td> </tr> <tr> <td><ind=5></td> <td>call</td> </tr> <tr> <td><ind=6></td> <td>roam</td> </tr> <tr> <td><ind=7></td> <td>smsfull</td> </tr> <tr> <td><stat></td> <td>The current value of the indicator as described for Test command</td> </tr> </table> <p>Remark: The read option does NOT return the current setting of the indicator. It issues the current value of the indicator, e.g. 1,10 if the battery is full.</p>	<ind=1>	battery charge	<ind=2>	signal quality	<ind=3>	service	<ind=4>	message	<ind=5>	call	<ind=6>	roam	<ind=7>	smsfull	<stat>	The current value of the indicator as described for Test command																				
<ind=1>	battery charge																																				
<ind=2>	signal quality																																				
<ind=3>	service																																				
<ind=4>	message																																				
<ind=5>	call																																				
<ind=6>	roam																																				
<ind=7>	smsfull																																				
<stat>	The current value of the indicator as described for Test command																																				
Write command AT+CIND= [<ind>],[<ind>],[...],	<p>Parameter</p> <table border="1"> <tr> <td><ind></td> <td>0</td> <td>the indicator is switched off</td> </tr> <tr> <td></td> <td>1</td> <td>the indicator is switched on</td> </tr> </table> <p>Response</p> <p>OK/ERROR/+CME ERROR</p>	<ind>	0	the indicator is switched off		1	the indicator is switched on																														
<ind>	0	the indicator is switched off																																			
	1	the indicator is switched on																																			

2.3.4.9 AT+CMER

AT+CMER	Mobile Termination control mode
Test command AT+CMER=?	Response +CMER: (list of supported <mode>s),(list of supported <keyp>s),(list of supported <disp>s),(list of supported <ind>s),(list of supported <bfr>s)
	OK/ERROR/+CME ERROR
Parameter	
<mode>	0 buffer unsolicited result codes in the TA; if TA result code buffer is full, codes the oldest ones are discarded
	1 discard unsolicited result codes when TA-TE link is reserved (e.g. in on-line data mode); otherwise forward them directly to the TE
	2 buffer unsolicited result codes in the TA when TA-TE link is reserved (e.g. in on-line data mode) and flush them to the TE after reservation; otherwise forward them directly to the TE
	3 same as "2". This input for the bluetooth carkit is acceptable but the behaviour is same as mode=2
<keyp>	0 no keypad event reporting
	1 keypad event reporting using result code +CKEV: <key>,<press>, where <key> indicates the key (refer values defined in table for AT+CKPD) and <press> whether the key is pressed (1) or released (0). Only key pressings that are not caused by AT+CKPD are indicated by the TA to the TE
	2 keypad event reporting using result code +CKEV: <key>,<press>. All key pressings shall be directed from TA to TE
<disp>	0 no display event reporting
<ind>	0 no indicator event reporting
	1 indicator event reporting using result code +CIEV: <ind>, <value>. <ind> indicates the indicator order number (as specified for AT+CIND) and <value> is the new value of indicator. Only those indicator events, which are not caused by AT+CIND shall be indicated by the TA to the TE
	2 indicator event reporting using result code +CIEV: <ind>, <value>. All indicator events shall be directed from TA to TE
<bfr>	0 TA buffer of unsolicited result codes defined within this command is cleared when <mode> 1...3 is entered
Continued next page	1 TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1...3 is entered (OK response shall be given before flushing the codes)

Read command AT+ CMER?	Response +CMER: <mode>,<keyp>,0,<ind>,<bfr> OK/ERROR/+CME ERROR
	Parameter <keyp> See Test command
Write command AT+CMER==[<mode>],[<keyp>],[<disp>], [<ind>],[<bfr>]	Parameter <keyp> See Test command
	Response OK/ERROR/+CME ERROR
	Unexpected message +CIEV: <ind>, <value> +CKEV: <key>,<press>

2.3.4.10 AT+CMUT

AT+CMUT	Mute control
Test command AT+CMUT=?	Response +CMUT: (list of supported <n>s) OK
Read command AT+CMUT?	Response +CMUT: <n> OK/ERROR/+CME ERROR
Write command AT+CMUT=<n>	Response OK/ERROR/+CME ERROR Parameter <n> 0 mute off 1 mute on

2.3.4.11 AT+CPAS

AT+CPAS	Query the telephone status
Test command AT+CPAS=?	Response +CPAS: (list of supported <pas>s) OK/ERROR/+CME ERROR Parameter <pas> 0 Ready 3 Incoming call (phone is ringing) 4 Call is active
Execute command AT+CPAS	Response +CPAS: <pas> OK/ERROR/+CME ERROR Parameter <pas> see Test command

2.3.4.12 AT+CPBR

AT+CPBR		Read a telephone-book entry
Test command AT+CPBR=?	Response +CPBR: (list of supported <index>s), <nlength>, <tlength> OK/ERROR/+CME ERROR	Parameter <index> Location number <nlength> Max. length of telephone number <tlength> Max. length of text corresponding to the number
Write command AT+CPBR=<index1>[,<index2>]	Response +CPBR: <index1>, <number>, <typ>, <text>[<CR><LF> +CPBR: +CPBR: <index2>, <number>, <typ>, <text>] OK/ERROR/+CME ERROR	Parameter <index1> <u>Location number where the read of the entry starts</u> <index2> <u>Location number where the read of the entry ends</u> <number> <u>Telephone number</u> <typ> <u>Type of number</u> <text> Text corresponding to the telephone number <text> depends on AT+CSCS.
	Note: In the <text> field, special characters like the following may appear `" (0x22), `@` (0x00), `ò` (0x08), `Ö` (0x5c). See also section AT+CPBW and Appendix A: "Using special characters in certain commands (e. g., +CPBR/+CPBW)". Empty entries do not produce any output.	

2.3.4.13 AT+CPBS

AT+CPBS	Select a telephone book														
<p>Test command AT+CPBS=?</p>	<p>Response +CPBS: (list of supported <sto>s) OK/ERROR/+CME ERROR</p> <p>Parameter <sto></p> <table border="0"> <tr> <td>FD</td> <td>SIM fix-dialing phonebook</td> </tr> <tr> <td>SM</td> <td>SIM phonebook</td> </tr> <tr> <td>DC</td> <td>ME Dialed Calls List</td> </tr> <tr> <td>ON</td> <td>SIM (or ME) own numbers (MSISDNs) list</td> </tr> <tr> <td>LD</td> <td>SIM last-dialling phonebook</td> </tr> <tr> <td>MC</td> <td>ME missed (unanswered received) calls list</td> </tr> <tr> <td>RC</td> <td>ME received calls list</td> </tr> </table> <p>For a description of telephone-book features, see section 2.5.2. Note: DC and LD are mutually exclusive.</p>	FD	SIM fix-dialing phonebook	SM	SIM phonebook	DC	ME Dialed Calls List	ON	SIM (or ME) own numbers (MSISDNs) list	LD	SIM last-dialling phonebook	MC	ME missed (unanswered received) calls list	RC	ME received calls list
FD	SIM fix-dialing phonebook														
SM	SIM phonebook														
DC	ME Dialed Calls List														
ON	SIM (or ME) own numbers (MSISDNs) list														
LD	SIM last-dialling phonebook														
MC	ME missed (unanswered received) calls list														
RC	ME received calls list														
<p>Read command AT+CPBS?</p>	<p>Response +CPBS: <sto> OK/ERROR/+CME ERROR</p> <p>Parameter <sto> See Test command <used> integer type value indicating the number of used locations in selected memory <total> integer type value indicating the total number of locations in selected memory</p>														
<p>Write command AT+CPBS=<sto></p>	<p>Parameter <sto> See Test command</p> <p>Response OK/ERROR/+CME ERROR</p>														

2.3.4.14 AT+CPBW

AT+CPBW		Write a telephone-book entry	
Test command AT+CPBW=?	Response +CPBW: (list of supported <index>s), <nlength>,(list of supported <type>s), <tlength> OK/ERROR/+CME ERROR	Parameter <index>	Location number
		<nlength>	Max. length of telephone number
		<tlength>	Max. length of text corresponding to the number
Write command AT+CPBW=[<index>][,<nummer>[,<typ>[,<text>]]]			
	Parameter <index>		Location number at which the entry is written
		<nummer>	Telephone number
		<typ>	Type of number
		<text>	Text corresponding to the telephone number
			The following characters in <text> must be entered via the Siemens-specific escape sequence (see also Appendix A: "Using special characters in certain commands (e. g., +CPBR/+CPBW")
			<text> depends on AT+CSCS.
		GSM Char	Hex char
		ASCII	3 byte Esc Seq (hex)
		Note	
		Ö	x5C \ x5C x35 x43 Backslash
		"	x22 " x5C x32 x32 String delim
		ò	x08 BSP x5C x30 x38 Backspace
		@	x00 NULL x5C x30 x30 GSM Null
			GSM=0x00 may cause problems on application level when using the function strlen() and should thus be represented by an escape sequence
	Response OK/ERROR/+CME ERROR		

2.3.4.15 AT+CPIN

AT+CPIN	Enter PIN and query lock																																		
Test command AT+CPIN=?	Response OK																																		
Read command AT+CPIN?	<p>Response +CPIN: <code> OK/ERROR/+CME ERROR</p> <p>Parameter <code></p> <table> <tr> <td>READY</td> <td>No further input necessary</td> </tr> <tr> <td>SIM PIN</td> <td>SIM PIN input necessary</td> </tr> <tr> <td>SIM PUK</td> <td>SIM PUK input necessary</td> </tr> <tr> <td>PH-SIM PIN</td> <td>Device code (theft protection) input necessary</td> </tr> <tr> <td>PH-SIM PUK</td> <td>Device code PUK (theft protection) input necessary</td> </tr> <tr> <td>SIM PIN2</td> <td>PIN2, e.g. for editing the FDN book; only possible if previous command was acknowledged with +CME ERROR:17</td> </tr> <tr> <td>SIM PUK2</td> <td>Only possible if previous command was acknowledged with error +CME ERROR:18</td> </tr> </table> <p><u>device specific codes (SIM LOCK):</u></p> <table> <tr> <td>PH-FSIM PIN</td> <td>There is no current PIN</td> </tr> <tr> <td>PH-FSIM PUK</td> <td>Phone locked to very first inserted SIM</td> </tr> <tr> <td>PH-NET PIN</td> <td>There is no current PIN</td> </tr> <tr> <td>PH-NET PUK</td> <td>Network Personalization is actually a PUK</td> </tr> <tr> <td>PH-NETSUB PIN</td> <td>There is no current PIN</td> </tr> <tr> <td>PH-NETSUB PUK</td> <td>Network Subset Personalization is actually a PUK</td> </tr> <tr> <td>PH-SP PIN</td> <td>There is no current PIN</td> </tr> <tr> <td>PH-SP PUK</td> <td>Network Personalization is actually a PUK</td> </tr> <tr> <td>PH-CORP PIN</td> <td>There is no current PIN</td> </tr> <tr> <td>PH-CORP PUK</td> <td>Network Personalization is actually a PUK The required error message can (must) be provoked by an attempted Write command</td> </tr> </table>	READY	No further input necessary	SIM PIN	SIM PIN input necessary	SIM PUK	SIM PUK input necessary	PH-SIM PIN	Device code (theft protection) input necessary	PH-SIM PUK	Device code PUK (theft protection) input necessary	SIM PIN2	PIN2, e.g. for editing the FDN book; only possible if previous command was acknowledged with +CME ERROR:17	SIM PUK2	Only possible if previous command was acknowledged with error +CME ERROR:18	PH-FSIM PIN	There is no current PIN	PH-FSIM PUK	Phone locked to very first inserted SIM	PH-NET PIN	There is no current PIN	PH-NET PUK	Network Personalization is actually a PUK	PH-NETSUB PIN	There is no current PIN	PH-NETSUB PUK	Network Subset Personalization is actually a PUK	PH-SP PIN	There is no current PIN	PH-SP PUK	Network Personalization is actually a PUK	PH-CORP PIN	There is no current PIN	PH-CORP PUK	Network Personalization is actually a PUK The required error message can (must) be provoked by an attempted Write command
READY	No further input necessary																																		
SIM PIN	SIM PIN input necessary																																		
SIM PUK	SIM PUK input necessary																																		
PH-SIM PIN	Device code (theft protection) input necessary																																		
PH-SIM PUK	Device code PUK (theft protection) input necessary																																		
SIM PIN2	PIN2, e.g. for editing the FDN book; only possible if previous command was acknowledged with +CME ERROR:17																																		
SIM PUK2	Only possible if previous command was acknowledged with error +CME ERROR:18																																		
PH-FSIM PIN	There is no current PIN																																		
PH-FSIM PUK	Phone locked to very first inserted SIM																																		
PH-NET PIN	There is no current PIN																																		
PH-NET PUK	Network Personalization is actually a PUK																																		
PH-NETSUB PIN	There is no current PIN																																		
PH-NETSUB PUK	Network Subset Personalization is actually a PUK																																		
PH-SP PIN	There is no current PIN																																		
PH-SP PUK	Network Personalization is actually a PUK																																		
PH-CORP PIN	There is no current PIN																																		
PH-CORP PUK	Network Personalization is actually a PUK The required error message can (must) be provoked by an attempted Write command																																		
Write command AT+CPIN=<pin>[,<new pin>]	<p>Parameter <pin> <new pin></p> <p>Response OK/ERROR/+CME ERROR</p> <p>Password for appropriate lock; if the lock is a PUK, then a <new pin> is necessary. New password for the lock</p>																																		

2.3.4.16 AT+CPUC

AT+CPUC	Price per unit and currency table
Test command AT+CPUC=?	Response OK
Read command AT+CPUC?	Response +CPUC: <currency>,<ppu> OK/ERROR/+CME ERROR Parameter <currency> three-character currency code (e.g. "DEM") see AT+CSCS command <ppu> price per unit; dot is used as a decimal separator (e.g. "1.33")
Write command AT+CPUC=<currency>,<ppu>[,<passwd>]	Response OK/ERROR/+CME ERROR Parameter <passwd> String type; usually PIN2

2.3.4.17 AT+CRSL

AT+CRSL	Ringer sound level
Test command AT+CRSL=?	Response +CRSL: (list of supported <level>s) OK
Read command AT+CRSL?	Response +CRSL: <level> OK/ERROR/+CME ERROR
Write command AT+CRSL=<level>	Response OK/ERROR/+CME ERROR Parameter <level> Ringer Sound Level

2.3.4.18 AT+CRMP

AT+CRMP	Ring Melody Playback
Test command AT+CRMP=?	Response +CRMP: (list of supported <call type>s),(list of supported <volume>s) OK
Write command +CRMP=<call type>[,<volume>]	Response OK/ERROR/+CME ERROR Parameter <call type> integer type parameter corresponding to different ring melodies in mobile such as line1, line2, groups, Alarm, SMS, CBS and others <volume> integer type parameter with manufacturer specific range
Execute command AT+CRMP	Response OK/ERROR/+CME ERROR Note: If an MTC arrives while the test ring is active, the latter is switched off and the "normal" ring is switched on.

2.3.4.19 AT+CRSM

AT+CRSM	Restricted SIM access	
Test command AT+CRSM=?	Response OK	
Write command +CRSM=<command>[,<file id>[,<P1>,<P2>,<P3>[,<data>]]]	Response +CRSM: <sw1>,<sw2>[,<response>] OK/ERROR/+CME ERROR	
Parameter <command>	176 178 192 214 220 242	READ BINARY READ RECORD GET RESPONSE UPDATE BINARY UPDATE RECORD STATUS
<file id>	<integer>	identifier of the data file on the SIM, mandatory for every command except STATUS (see [6])
<P1>, <P2>, <P3>	<integer>	transferral parameter from ME to SIM, mandatory for every command except GET RESPONSE,STATUS (see [6])
<data>	<hexadecimal string>	information to be written to the SIM
<sw1>, <sw2>	<integer>	information from the SIM as to whether the command was executed at all, and if so, how
<response>	<hexadecimal string>	Indicates that the command was processed successfully
Note	The write access to CK boxes receives only limited support and differs from device to device.	

2.3.4.20 AT+CSQ

AT+CSQ	Output signal quality																		
Test command AT+CSQ=?	Response +CSQ: (list of supported <rssi>s), list of supported <ber> OK/ERROR/+CME ERROR Parameter <rssi> <table border="0" style="margin-left: 20px;"> <tr> <td style="padding-right: 20px;">0</td> <td>Reception level</td> </tr> <tr> <td>1</td> <td>-113 dBm or less</td> </tr> <tr> <td>2 - 30</td> <td>111 dBm</td> </tr> <tr> <td>31</td> <td>-109 to -53 dBm</td> </tr> <tr> <td>99</td> <td>-51 dBm or more</td> </tr> <tr> <td></td> <td>Unknown</td> </tr> </table> <hr/> <ber> <table border="0" style="margin-left: 20px;"> <tr> <td style="padding-right: 20px;">0-7</td> <td>Bit error rate</td> </tr> <tr> <td></td> <td>Like RXQUAL values from Table GSM 05.08 in Section 8.2.4</td> </tr> <tr> <td>99</td> <td>Unknown</td> </tr> </table>	0	Reception level	1	-113 dBm or less	2 - 30	111 dBm	31	-109 to -53 dBm	99	-51 dBm or more		Unknown	0-7	Bit error rate		Like RXQUAL values from Table GSM 05.08 in Section 8.2.4	99	Unknown
0	Reception level																		
1	-113 dBm or less																		
2 - 30	111 dBm																		
31	-109 to -53 dBm																		
99	-51 dBm or more																		
	Unknown																		
0-7	Bit error rate																		
	Like RXQUAL values from Table GSM 05.08 in Section 8.2.4																		
99	Unknown																		
Execute command AT+CSQ	Response +CSQ: <rssi>, <ber> OK/ERROR/+CME ERROR Parameter <rssi> See Test command <ber> See Test command																		

2.3.4.21 AT+CVIB

AT+CVIB	Vibrator mode
Test command AT+CVIB=?	Response +CVIB: (list of supported <mode>s) OK
Execute command AT+CVIB	Response +CVIB: <mode> OK/ERROR/+CME ERROR
Write command AT+CVIB=<mode>	Response OK/ERROR/+CME ERROR Parameter <mode> Vibrator mode 0 disable 1 enable 16 vibrate then ring (not available in every model)

2.3.5 Extensions of Hayes Standard commands for GPRS

This chapter describes all the extensions of the Hayes Standard commands for GPRS.

Command	Function
ATD*<GPRS_SC>[*[<called_address>] [*[<L2P>][*[<cid>]]]]#	<p>Request GPRS service</p> <p><GPRS_SC> GPRS Service Code a digit string (value 99)</p> <p><called_address> a string that identifies the called party in the address space</p> <p><L2P> a string which indicates the layer 2 protocol</p> <p><cid> a digit string which specifies a particular PDP context definition. The cid has to be defined by using the AT+CGDCONT command</p> <p>The dial command responds with CONNECT or ERROR</p>
ATD*<GPRS_SC_IP>[*<cid>]#	<p>Request GPRS IP service</p> <p><GPRS_S GPRS Service Code a digit string (value 98)</p> <p>C></p> <p><cid> a digit string which specifies a particular PDP context definition. The cid has to be defined by using the AT+CGDCONT command</p> <p>The dial command responds with CONNECT or ERROR</p>
AT0	Return to on-line data state
ATS0	Automatic answer. The command may be used to turn off (n=0) and on (n>0) the automatic response to a network request for a PDP context activation.
ATS3	Termination character
ATS4	Response formatting character
ATS5	Command line editing character

2.3.6 Commands for GPRS

This section provides the descriptions of commands related to GPRS.

2.3.6.1 AT+CGACT

AT+CGACT	PDP context activate or deactivate
Test command AT+CGACT=?	Response +CGACT: (list of supported <state>s) OK/ERROR/+CME ERROR Parameter <state> indicates the state of PDP context activation 0 deactivated 1 activated
Read command AT+CGACT?	Response +CGACT:<cid>,<state>[<CR><LF>+CGACT:<cid>,<state>...] OK/ERROR/+CME ERROR Parameter <cid> numeric PDP Context Identifier <state> See Test command
Write command AT+CGACT=[<state>,<cid>,<cid>,...]]]	Parameter <cid> See Read command <state> See Test command Response OK/ERROR/+CME ERROR

2.3.6.2 AT+CGANS

AT+CGANS	Manual response to a network request for PDP context activation
Test command AT+CGANS=?	Response +CGANS(list of supported <response>s), (list of supported <L2P>s) OK/ERROR/+CME ERROR Parameter <response> 0 the request is rejected 1 the request is answered <L2P> layer 2 protocol to be used between the TE and MT PPP
Write command AT+CGANS=[<response> ,<L2P> ,<cid>]]]	Parameter <response> See Test command <state> See Test command <cid> numeric PDP Context Identifier Response CONNECT/ERROR/+CME ERROR

2.3.6.7 AT+CGDCONT

AT+CGDCONT	Define PDP Context																
<p>Test command AT+CGDCONT=?</p>	<p>Response +CGDCONT: (range of supported <cid>s), <PDP_type>,,,(list of supported <d_comp>s), (list of supported <h_comp>s) [<CR><LF>+CGDCONT: (range of supported <cid>s), <PDP_type>,,,(list of supported <d_comp>s),(list of supported <h_comp>s)[...] OK/ERROR/+CME ERROR</p> <p>Parameter</p> <table border="0"> <tr> <td><cid></td> <td>numeric PDP Context Identifier</td> </tr> <tr> <td><PDP_type></td> <td>string parameter of Packet Data Protocol type</td> </tr> <tr> <td></td> <td>PPP Type PPT</td> </tr> <tr> <td></td> <td>IP Type IP</td> </tr> <tr> <td><d_comp></td> <td>numeric parameter that controls PDP data compression</td> </tr> <tr> <td></td> <td>0 off</td> </tr> <tr> <td><h_comp></td> <td>numeric parameter that controls PDP header compression</td> </tr> <tr> <td></td> <td>0 off</td> </tr> </table>	<cid>	numeric PDP Context Identifier	<PDP_type>	string parameter of Packet Data Protocol type		PPP Type PPT		IP Type IP	<d_comp>	numeric parameter that controls PDP data compression		0 off	<h_comp>	numeric parameter that controls PDP header compression		0 off
<cid>	numeric PDP Context Identifier																
<PDP_type>	string parameter of Packet Data Protocol type																
	PPP Type PPT																
	IP Type IP																
<d_comp>	numeric parameter that controls PDP data compression																
	0 off																
<h_comp>	numeric parameter that controls PDP header compression																
	0 off																
<p>Read command AT+CGDCONT?</p>	<p>Response +CGDCONT: <cid>, <PDP_type>, <APN>,<PDP_addr>, <data_comp>, <head_comp> [<CR><LF>+CGDCONT: <cid>, <PDP_type>, <APN>,<PDP_addr>, <data_comp>, <head_comp>[...]] OK/ERROR/+CME ERROR</p> <p>Parameter</p> <table border="0"> <tr> <td><cid></td> <td>See Test command</td> </tr> <tr> <td><PDP_type></td> <td>See Test command</td> </tr> <tr> <td><APN></td> <td>string parameter for Access Point Name</td> </tr> <tr> <td><PDP_addr></td> <td>string parameter in IP V4 address notification</td> </tr> <tr> <td><d_comp></td> <td>See Test command</td> </tr> <tr> <td><h_comp></td> <td>See Test command</td> </tr> </table>	<cid>	See Test command	<PDP_type>	See Test command	<APN>	string parameter for Access Point Name	<PDP_addr>	string parameter in IP V4 address notification	<d_comp>	See Test command	<h_comp>	See Test command				
<cid>	See Test command																
<PDP_type>	See Test command																
<APN>	string parameter for Access Point Name																
<PDP_addr>	string parameter in IP V4 address notification																
<d_comp>	See Test command																
<h_comp>	See Test command																
<p>Write command AT+CGDCONT=[<cid> [,<PDP_type> [,<APN> [,<PDP_addr>]]]]</p>	<p>Parameter</p> <table border="0"> <tr> <td><cid></td> <td>See Test command</td> </tr> <tr> <td><PDP_type></td> <td>See Test command</td> </tr> <tr> <td><APN></td> <td>See Read command</td> </tr> <tr> <td><PDP_addr></td> <td>See Read command</td> </tr> </table> <p>Response OK/ERROR/+CME ERROR</p>	<cid>	See Test command	<PDP_type>	See Test command	<APN>	See Read command	<PDP_addr>	See Read command								
<cid>	See Test command																
<PDP_type>	See Test command																
<APN>	See Read command																
<PDP_addr>	See Read command																

2.3.6.8 AT+CGEREP

AT+CGEREP	GPRS event reporting										
<p>Test command AT+CGEREP=?</p>	<p>Response +CGEREP: (list of supported <mode>s),(list of supported <bfr>s) OK/ERROR/+CME ERROR</p> <p>Parameter <mode></p> <table border="0"> <tr> <td style="text-align: right;">0</td> <td>buffer unsolicited result codes in the MT; if MT result code buffer is full, the oldest ones can be discarded. No codes are forwarded to the TE</td> </tr> <tr> <td style="text-align: right;">1</td> <td>discard unsolicited result codes when MT-TE link is reserved (e.g. in on-line data mode); otherwise forward them directly to the TE</td> </tr> <tr> <td style="text-align: right;">2</td> <td>buffer unsolicited result codes in the MT when MT-TE link is reserved (e.g. in on-line data mode) and flush them to the TE when MT-TE link becomes available; otherwise forward them directly to the TE</td> </tr> </table> <p><bfr></p> <table border="0"> <tr> <td style="text-align: right;">0</td> <td>MT buffer of unsolicited result codes defined within this command is cleared when 1 or 2 is entered for <mode></td> </tr> <tr> <td style="text-align: right;">1</td> <td>MT buffer of unsolicited result codes defined within this command is flushed to the TE when 1 or 2 is entered for <mode></td> </tr> </table>	0	buffer unsolicited result codes in the MT; if MT result code buffer is full, the oldest ones can be discarded. No codes are forwarded to the TE	1	discard unsolicited result codes when MT-TE link is reserved (e.g. in on-line data mode); otherwise forward them directly to the TE	2	buffer unsolicited result codes in the MT when MT-TE link is reserved (e.g. in on-line data mode) and flush them to the TE when MT-TE link becomes available; otherwise forward them directly to the TE	0	MT buffer of unsolicited result codes defined within this command is cleared when 1 or 2 is entered for <mode>	1	MT buffer of unsolicited result codes defined within this command is flushed to the TE when 1 or 2 is entered for <mode>
0	buffer unsolicited result codes in the MT; if MT result code buffer is full, the oldest ones can be discarded. No codes are forwarded to the TE										
1	discard unsolicited result codes when MT-TE link is reserved (e.g. in on-line data mode); otherwise forward them directly to the TE										
2	buffer unsolicited result codes in the MT when MT-TE link is reserved (e.g. in on-line data mode) and flush them to the TE when MT-TE link becomes available; otherwise forward them directly to the TE										
0	MT buffer of unsolicited result codes defined within this command is cleared when 1 or 2 is entered for <mode>										
1	MT buffer of unsolicited result codes defined within this command is flushed to the TE when 1 or 2 is entered for <mode>										
<p>Read command AT+CGEREP?</p>	<p>Response +CGEREP: <mode>,<bfr> OK/ERROR/+CME ERROR</p> <p>Parameter <mode> See Test command <bfr> See Test command</p>										
<p>Write command AT+CGEREP=[<mode>[,<bfr>]]</p>	<p>Response OK/ERROR/+CME ERROR</p> <p>Parameter <mode> See Test command <bfr> See Test command</p> <p>Unsolicited message: +CGEV: REJECT <PDP_type>, <PDP_addr> +CGEV: NW REACT <PDP_type>, <PDP_addr> +CGEV: NW DEACT <PDP_type>, <PDP_addr> +CGEV: ME DEACT <PDP_type>, <PDP_addr> +CGEV: NW DETACH +CGEV: ME DETACH +CGEV: NW CLASS <class> +CGEV: ME CLASS <class></p>										

2.3.6.9 AT+CGQMIN

AT+CGQMIN	Quality of Service Profile (Minimum acceptable)																																				
<p>Test command AT+CGQMIN=?</p>	<p>Response +CGQMIN: <PDP_type>, (list of supported <precedence>s), (list of supported <delay>s), (list of supported <reliability>s) , (list of supported <peak>s), (list of supported <mean>s) [<CR><LF>+CGQMIN: <PDP_type>, (list of supported <precedence>s), (list of supported <delay>s), (list of supported <reliability>s) , (list of supported <peak>s), (list of supported <mean>s)[...]] OK/ERROR/+CME ERROR</p> <p>Parameter</p> <table border="0"> <tr> <td><PDP_type></td> <td>string parameter of Packet Data Protocol type</td> </tr> <tr> <td>PPP</td> <td>Type PPP</td> </tr> <tr> <td>IP</td> <td>Type IP</td> </tr> <tr> <td><precedence></td> <td>numeric parameter for the precedence class</td> </tr> <tr> <td>0</td> <td>network subscribed value</td> </tr> <tr> <td>1..3</td> <td></td> </tr> <tr> <td><delay></td> <td>numeric parameter for the delay class</td> </tr> <tr> <td>0</td> <td>network subscribed value</td> </tr> <tr> <td>1..4</td> <td></td> </tr> <tr> <td><reliability></td> <td>numeric parameter for the reliability class</td> </tr> <tr> <td>0</td> <td>network subscribed value</td> </tr> <tr> <td>1..5</td> <td></td> </tr> <tr> <td><peak></td> <td>numeric parameter for the peak throughput class</td> </tr> <tr> <td>0</td> <td>network subscribed value</td> </tr> <tr> <td>1..7</td> <td></td> </tr> <tr> <td><mean></td> <td>numeric parameter for the mean throughput class</td> </tr> <tr> <td>0</td> <td>network subscribed value</td> </tr> <tr> <td>1..12</td> <td></td> </tr> </table>	<PDP_type>	string parameter of Packet Data Protocol type	PPP	Type PPP	IP	Type IP	<precedence>	numeric parameter for the precedence class	0	network subscribed value	1..3		<delay>	numeric parameter for the delay class	0	network subscribed value	1..4		<reliability>	numeric parameter for the reliability class	0	network subscribed value	1..5		<peak>	numeric parameter for the peak throughput class	0	network subscribed value	1..7		<mean>	numeric parameter for the mean throughput class	0	network subscribed value	1..12	
<PDP_type>	string parameter of Packet Data Protocol type																																				
PPP	Type PPP																																				
IP	Type IP																																				
<precedence>	numeric parameter for the precedence class																																				
0	network subscribed value																																				
1..3																																					
<delay>	numeric parameter for the delay class																																				
0	network subscribed value																																				
1..4																																					
<reliability>	numeric parameter for the reliability class																																				
0	network subscribed value																																				
1..5																																					
<peak>	numeric parameter for the peak throughput class																																				
0	network subscribed value																																				
1..7																																					
<mean>	numeric parameter for the mean throughput class																																				
0	network subscribed value																																				
1..12																																					
<p>Read command AT+CGQMIN?</p>	<p>Response +CGQMIN:<cid>,<precedence>,<delay>,<reliability>,<peak>,<mean>[<CR><LF>+CGQMIN:<cid>,<precedence>,<delay>,<reliability>,<peak>,<mean>[...]] OK/ERROR/+CME ERROR</p> <p>Parameter</p> <table border="0"> <tr> <td><cid></td> <td>numeric PDP Context Identifier</td> </tr> <tr> <td><PDP_type></td> <td>See Test command</td> </tr> <tr> <td><precedence></td> <td>See Test command</td> </tr> <tr> <td><delay></td> <td>See Test command</td> </tr> <tr> <td><reliability></td> <td>See Test command</td> </tr> <tr> <td><peak></td> <td>See Test command</td> </tr> <tr> <td><mean></td> <td>See Test command</td> </tr> </table>	<cid>	numeric PDP Context Identifier	<PDP_type>	See Test command	<precedence>	See Test command	<delay>	See Test command	<reliability>	See Test command	<peak>	See Test command	<mean>	See Test command																						
<cid>	numeric PDP Context Identifier																																				
<PDP_type>	See Test command																																				
<precedence>	See Test command																																				
<delay>	See Test command																																				
<reliability>	See Test command																																				
<peak>	See Test command																																				
<mean>	See Test command																																				
<p>Write command AT+CGQMIN=[<cid>[,<precedence>[,<delay>[,<reliability>[,<peak>[,<mean>]]]]]]</p>	<p>Parameter</p> <table border="0"> <tr> <td><cid></td> <td>See Read command</td> </tr> <tr> <td><PDP_type></td> <td>See Test command</td> </tr> <tr> <td><precedence></td> <td>See Test command</td> </tr> <tr> <td><delay></td> <td>See Test command</td> </tr> <tr> <td><reliability></td> <td>See Test command</td> </tr> <tr> <td><peak></td> <td>See Test command</td> </tr> <tr> <td><mean></td> <td>See Test command</td> </tr> </table> <p>Response OK/ERROR/+CME ERROR</p>	<cid>	See Read command	<PDP_type>	See Test command	<precedence>	See Test command	<delay>	See Test command	<reliability>	See Test command	<peak>	See Test command	<mean>	See Test command																						
<cid>	See Read command																																				
<PDP_type>	See Test command																																				
<precedence>	See Test command																																				
<delay>	See Test command																																				
<reliability>	See Test command																																				
<peak>	See Test command																																				
<mean>	See Test command																																				

2.3.6.10 AT+CGQREQ

AT+CGQREQ	Quality of Service Profile (Requested)																																	
<p>Test command AT+CGQREQ=?</p>	<p>Response +CGQREQ: <PDP_type>, (list of supported <precedence>s), (list of supported <delay>s), (list of supported <reliability>s) , (list of supported <peak>s), (list of supported <mean>s) [<CR><LF>>+CGQREQ: <PDP_type>, <precedence >, <delay>, <reliability>, <peak>, <mean>[...]]</p> <p>OK/ERROR/+CME ERROR</p> <p>Parameter</p> <table border="0"> <tr> <td data-bbox="553 590 699 615"><PDP_type></td> <td data-bbox="760 646 818 705">PPP IP</td> <td data-bbox="889 590 1344 705">string parameter of Packet Data Protocol type Type PPP Type IP</td> </tr> <tr> <td data-bbox="553 709 711 735"><precedence></td> <td data-bbox="760 766 781 791">0</td> <td data-bbox="889 709 1317 766">numeric parameter for the precedence class</td> </tr> <tr> <td></td> <td data-bbox="760 791 808 816">1..3</td> <td data-bbox="889 766 1170 791">network subscribed value</td> </tr> <tr> <td data-bbox="553 825 643 850"><delay></td> <td data-bbox="760 856 781 882">0</td> <td data-bbox="889 825 1308 882">numeric parameter for the delay class</td> </tr> <tr> <td></td> <td data-bbox="760 882 808 907">1..4</td> <td data-bbox="889 856 1170 882">network subscribed value</td> </tr> <tr> <td data-bbox="553 915 678 940"><reliability></td> <td data-bbox="760 947 781 972">0</td> <td data-bbox="889 915 1344 972">numeric parameter for the reliability class</td> </tr> <tr> <td></td> <td data-bbox="760 972 808 997">1..5</td> <td data-bbox="889 947 1170 972">network subscribed value</td> </tr> <tr> <td data-bbox="553 1005 638 1031"><peak></td> <td data-bbox="760 1058 781 1083">0</td> <td data-bbox="889 1005 1365 1062">numeric parameter for the peak throughput class</td> </tr> <tr> <td></td> <td data-bbox="760 1083 808 1108">1..7</td> <td data-bbox="889 1058 1170 1083">network subscribed value</td> </tr> <tr> <td data-bbox="553 1117 643 1142"><mean></td> <td data-bbox="760 1169 781 1194">0</td> <td data-bbox="889 1117 1247 1173">numeric parameter for the mean throughput class</td> </tr> <tr> <td></td> <td data-bbox="760 1194 818 1220">1..12</td> <td data-bbox="889 1169 1170 1194">network subscribed value</td> </tr> </table>	<PDP_type>	PPP IP	string parameter of Packet Data Protocol type Type PPP Type IP	<precedence>	0	numeric parameter for the precedence class		1..3	network subscribed value	<delay>	0	numeric parameter for the delay class		1..4	network subscribed value	<reliability>	0	numeric parameter for the reliability class		1..5	network subscribed value	<peak>	0	numeric parameter for the peak throughput class		1..7	network subscribed value	<mean>	0	numeric parameter for the mean throughput class		1..12	network subscribed value
<PDP_type>	PPP IP	string parameter of Packet Data Protocol type Type PPP Type IP																																
<precedence>	0	numeric parameter for the precedence class																																
	1..3	network subscribed value																																
<delay>	0	numeric parameter for the delay class																																
	1..4	network subscribed value																																
<reliability>	0	numeric parameter for the reliability class																																
	1..5	network subscribed value																																
<peak>	0	numeric parameter for the peak throughput class																																
	1..7	network subscribed value																																
<mean>	0	numeric parameter for the mean throughput class																																
	1..12	network subscribed value																																
<p>Read command AT+CGQREQ?</p> <p>(Continued next page)</p>	<p>Response +CGQREQ: <cid>, <precedence >, <delay>, <reliability>, <peak>, <mean>[<CR><LF>>+CGQREQ: <cid>, <precedence >, <delay>, <reliability.>, <peak>, <mean>[...]]</p> <p>OK/ERROR/+CME ERROR</p> <p>Parameter</p> <table border="0"> <tr> <td data-bbox="553 1373 613 1398"><cid></td> <td data-bbox="870 1373 1214 1398">numeric PDP Context Identifier</td> </tr> <tr> <td data-bbox="553 1423 695 1449"><PDP_type></td> <td data-bbox="870 1423 1089 1449">See Test command</td> </tr> <tr> <td data-bbox="553 1457 711 1482"><precedence></td> <td data-bbox="870 1457 1089 1482">See Test command</td> </tr> <tr> <td data-bbox="553 1491 643 1516"><delay></td> <td data-bbox="870 1491 1089 1516">See Test command</td> </tr> <tr> <td data-bbox="553 1524 678 1549"><reliability></td> <td data-bbox="870 1524 1089 1549">See Test command</td> </tr> <tr> <td data-bbox="553 1558 638 1583"><peak></td> <td data-bbox="870 1558 1089 1583">See Test command</td> </tr> <tr> <td data-bbox="553 1591 643 1617"><mean></td> <td data-bbox="870 1591 1089 1617">See Test command</td> </tr> </table>	<cid>	numeric PDP Context Identifier	<PDP_type>	See Test command	<precedence>	See Test command	<delay>	See Test command	<reliability>	See Test command	<peak>	See Test command	<mean>	See Test command																			
<cid>	numeric PDP Context Identifier																																	
<PDP_type>	See Test command																																	
<precedence>	See Test command																																	
<delay>	See Test command																																	
<reliability>	See Test command																																	
<peak>	See Test command																																	
<mean>	See Test command																																	

Write command (cont.)	
AT+CGQREQ=[<cid>[,<precedence>[,<delay>[,<reliability>[,<peak>[,<mean>]]]]]]]	
Parameter	
<cid>	See Read command
<PDP_type>	See Test command
<precedence>	See Test command
<delay>	See Test command
<reliability>	See Test command
<peak>	See Test command
<mean>	See Test command
Response	
OK/ERROR/+CME ERROR	

2.3.6.11 AT+CGPADDR

AT+CGPADDR	Show PDP address
Test command AT+CGPADDR=?	Response +CGPADDR: (list of defined <cid>s) OK/ERROR/+CME ERROR Parameter <cid> numeric PDP Context Identifier
Write command AT+CGPADDR=[<L2P> , [<cid> [, <cid> [, ...]]]]	Parameter <L2P> layer 2 protocol to be used between the TE and MT PPP Type PPP <cid> numeric PDP Context Identifier Response +CGPADDR:: <cid>,<PDP_addr>[<CR><LF>+CGPADDR:<cid>,<PDP_addr>[. ..]] OK/ERROR/+CME ERROR

2.3.6.12 AT+CGREG

AT+CGREG	GPRS network registration status
Test command AT+CGREG=?	Response +CGREG: (list of supported <n>s) OK/ERROR/+CME ERROR Parameter 0 Suppresses the unexpected network-status messages <n> Displays the unexpected network-status messages:OK/ERROR/+CME ERROR
Read command AT+CGREG?	Response +CGREG: <n>,<stat>[,<lac>,<ci>] OK/ERROR/+CME ERROR Parameter <n> See Test command <stat> Status 0 Not registered, not currently searching 1 registered, home network 2 Not registered, but currently searching 3 registration denied by network 4 Unknown 5 Registered, roaming <lac> Hexadecimal 2-byte string type of location area code <ci> Hexadecimal 2-byte string type of cell ID
Write command AT+CGREG=[<n>]	Parameter <n> See Test command Response OK/ERROR/+CME ERROR Unsolicited message +CGREG: <stat>

2.3.6.13 AT+CGSMS

AT+CGSMS	Select service for MO SMS messages
Test command AT+CGSMS=?	Response +CGSMS: (list of currently available <service>s) OK/ERROR/+CME ERROR Parameter <service> numeric parameter for service or service preference 0 GPRS 1 circuit switched 2 GPRS preferred (use circuit switched if GPRS not available) 3 circuit switched preferred (use GPRS if circuit switched not available)
Read command AT+CGSMS?	Response +CGSMS: <service> OK/ERROR/+CME ERROR Parameter <service> See Test command
Write command AT+CGSMS=[< service >]	Parameter <service> See Test command Response OK/ERROR/+CME ERROR

2.3.7 Commands related to mobile equipment errors

2.3.7.1 AT+CMEE

AT+CMEE	Expanded error messages according to GSM 07.07
Test command AT+CMEE=?	Response +CMEE: (list of supported <n>s) Parameter <n> 0 Suppresses the expanded error format 1 Expanded error messages as number 2 Expanded error messages as text
Read command AT+CMEE?	Response +CMEE: <n> Parameter <n> See Read command
Write command AT+CMEE=<n>	Parameter <n> See Read command Response OK/ERROR/+CME ERROR Description: For detailed information on the values possible for +CME ERROR see section 3.1. +CMS errors have been defined for SMS; for detailed information on the values possible for +CME ERROR see section 3.2.

2.3.9 AT Cellular commands according to GSM 07.05 for SMS

GSM 07.05 commands are used for operating the SMS functions of the GSM mobile phone. The GSM module mobile supports the SMS PDU mode.

2.3.9.1 AT+CMGC

AT+CMGC		Send an SMS command
Test command AT+CMGC=?	Response OK	
Write command If PDU mode (+CMGF=0) AT+CMGS=<length><CR> PDU is given: <ctrl-Z/ESC>		
	Parameter <length> <pdu> <mr>	Length of PDU See AT+CMGL command Message reference
	Response If sending is successful: +CMGC: <mr> If sending is not successful: +CMS ERROR	

2.3.9.2 AT+CMGD

AT+CMGD		Delete an SMS in the SMS memory
Test command At+CMGD=?	Response OK	
Write command AT+CMGD=<index>		
	Parameter <index>	Index of message in the selected memory <mem1>
	Response OK/ERROR/+CMS ERROR	

2.3.9.3 AT+CMGF

AT+CMGF		SMS format	
Test command AT+CMGF=?	Response +CMGF: (list of supported <mode>s)	Parameter <mode>	0 PDU mode
Read command AT+CMGF?	Response +CMGF: <mode>	Parameter <mode>	0 PDU mode
Write command AT+CMGF=[<mode>]	Parameter <mode>	0	PDU mode
	Response OK/ERROR		

2.3.9.6 AT+CMGS

AT+CMGS	Send an SMS
Test command AT+CMGS=?	Response OK
Write command If PDU mode (+CMGF=0) AT+CMGS=<length><CR> PDU is given: <ctrl-Z/ESC>	
	Parameter <length> Length of PDU <pdu> See AT+CMGL command <mr> Message reference
	Response If sending is successful: +CMGS: <mr> If sending is not successful: +CMS ERROR

2.3.9.7 AT+CMGW

AT+CMGW	Write an SMS to the SMS memory
Test command AT+CMGW=?	Response OK
Write command If PDU mode (+CMGF=0) AT+CMGW=<length>[,<stat>]<CR> PDU is given: <ctrl-Z/ESC>	
	Parameter <length> Length of PDU <stat> See AT+CMGL command <pdu> See AT+CMGL command <index> Index of message in selected memory <mem1>
	Response +CMGW: <index> +CMS ERROR

2.3.9.8 AT+CMMS

AT+CMMS	More (Short) Message to Send
Test command AT+CMMS=?	Response +CMGF: (list of supported <mode>s)
	Parameter <mode>
	0 Disable
	1 Keep link enabled until time between last send messages command response and next send command exceeds 5 seconds then ME closesTA switches <n> to 0
	2 keep link enabled until time between last send messages command response and next send command exceeds 5 seconds then ME closes link TA does NOT switch <n> to 0
Read command AT+CMMS?	Response +CMMS: <mode> Parameter <mode> See Test Command
Write command AT+CMMS=[<mode>]	Parameter <mode> Response OK/ERROR

2.3.9.9 AT+CMSS

AT+CMSS	Send an SMS from the SMS memory
Test command AT+CMSS=?	Response OK
Write command AT+CMSS=<index>[,<da>[,<toda>]]	Parameter <index> Index of message in selected memory <mem1> <da> Destination address in string format <toda> Format of destination address <mr> Message reference Response If sending is successful: +CMSS: <mr> If sending is not successful: +CMS ERROR

2.3.9.10 AT+CNMA

AT+CNMA	Acknowledgment of a short message directly output (without storing on the chip card) <i>(NOTE: This command is only available if Phase 2+ compatibility has been activated by means of AT+CSMS=1)</i>
Test command AT+CNMA=?	Response +CNMA: (list of supported <n>s) Parameter <n> 0 Mode of functioning analogously to GSM 07.05 text mode
Write command AT+CNMA=[<n>]	Parameter <n> See Test command Response OK/ERROR/+CMS ERROR

	<p><bm> Rules for storing received CBMs depend on the relevant data coding method (refer to GSM 03.38), the setting of Select CBM Types AT+CSCB) and these values:</p> <p>0 No CBM indications are routed to the TE.</p> <p>2 New CBMs are routed directly to the TE using unsolicited result code: +CBM: <length><CR><LF><pdu> (PDU mode enabled)</p> <p>3 Class 3 CBMs are routed directly to TE using unsolicited result codes as defined in <bm>=2</p> <p><ds> 0 No SMS-STATUS-REPORTs are routed to the TE</p> <p>1 SMS-STATUS-REPORTs are routed to the TE using unsolicited result code: +CDS: <length><CR><LF><pdu> (PDU mode enabled)</p> <p>2 If SMS-STATUS-REPORT is routed into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CDSI: <mem>,<index></p> <p><bfr> 1 TA buffer of unsolicited result codes defined within this command is cleared when <mode> 1...3 is entered.</p> <p><mem> See AT+CPMS command</p> <p><index> Index of the record on the chip card</p> <p><length> Length of <pdu></p> <p><pdu> See AT+CMGL command</p>
Read command AT+CNMI?	<p>Response +CNMI: <mode>,<mt>,<bm>,<ds>,<bfr></p> <p>Parameter</p> <p><mode> See Test command</p> <p><mt> See Test command</p> <p><bm> See Test command</p> <p><ds> See Test command</p> <p><bfr> See Test command</p>
Write command AT+CNMI=[<mode>,<mt>,<bm>,<ds>,<bfr>]]]]	<p>Parameter</p> <p><mode> See Test command</p> <p><mt> See Test command</p> <p><bm> See Test command</p> <p><ds> See Test command</p> <p><bfr> See Test command</p> <p>Response OK/ERROR/+CMS ERROR</p>
	<p>Unsolicited message</p> <p>+CMTI: <mem>,<index></p> <p>+CMT: <length><CR><LF><pdu></p> <p>+CDS: <length><CR><LF><pdu></p> <p>+CDSI: <mem>,<index></p>

2.3.9.12 AT+CPMS

AT+CPMS		Preferred SMS message storage Revision according to GSM 07.05 Version 4.7.0
Test command AT+CPMS=?	Response +CPMS: (list of supported <mem1>s),(list of supported <mem2>s) ,(list of supported <mem3>s) Parameter <mem1> Memory from which messages are read and deleted SM SIM message storage ME Mobile Equipment message storage MT combination of "ME" and "SM" storages ----- <mem2> Messages will be written and sent to this memory storage: SM SIM message storage ME Mobile Equipment message storage MT combination of "ME" and "SM" storages ----- <mem3> Memory in which received messages are preferred to be stored, if routing to TE is not set (see AT+CNMI command with parameter <mt>=2) SM SIM message storage ME Mobile Equipment message storage MT combination of "ME" and "SM" storages	
Read command AT+CPMS?	Response +CPMS: <mem1>,<used1>,<total1>,<mem2>,<used2>,<total2>,<mem3>,<used3>,<total3> > Parameter <memx> Memory from which messages are read and deleted ----- <usedx> Number of messages currently in <memx> ----- <totalx> Total number of messages that can be stored in <memx>	
Write command AT+CPMS= <mem1>[,<mem2>[,<mem3>]]	Parameter <mem1> See Test command ----- <mem2> See Test command ----- <mem3> See Test command ----- +CPMS: <used1>,<total1>,<used2>,<total2>,<used3>,<total3> OK/ERROR/+CMS ERROR	
Notes	<ol style="list-style-type: none"> 1) The Mobil Equipment storage "ME" has capacity for 25 short messages 2) The storage "MT" is a combination of "ME" and "SM" storage. If "MT" is chosen indices < 26 refer to ME" storage while indices 26 or higher are associated with the "SM" storage 3) Incoming short messages with message class 2 (see GSM 03.38) will be stored in the "SM" storage only. Therefore, the AT^SMGO:2 indication (see AT^SMGO command) can occur without a preceding AT^SMGO:1 indication. 	

2.3.9.15 AT+CSMS

AT+CSMS	Selection of message service Revision according to GSM 07.05 Version 5.0.0	
Test command AT+CSMS=?	Response +CSMS: (list of supported <service>s) Parameter <service>	
	0	GSM 3.40 and 3.41
	1	GSM 3.40 and 3.41 and compatibility of the AT command syntax for phase 2+
	NOTE	Deactivating phase 2+ compatibility is only possible if the direct output of short messages AT+CNMI=1,2 or AT+CNMI=1,3 is not activated. If necessary, the latter should be deactivated first
Read command AT+CSMS?	Response +CSMS: <service>, <mt>, <mo>, <bm> Parameter <service>	0 GSM 3.40 and 3.41
	<mt>	Mobile terminated messages
	1	Type supported
	<mo>	Mobile originated messages
	1	Type supported
	<bm>	Broadcast type messages
	1	Type not supported
Write command AT+CSMS= <service>	Parameter <service>	0 GSM 3.40 and 3.41
	Response +CSMS: <mt>, <mo>, <bm> OK/ERROR/+CME ERROR	

2.3.10 Modem commands

This section provides the descriptions of modem commands.

2.3.10.1 AT+CBST

AT+CBST	Select bearer service type																		
Test command AT+ CBST =?	Selects the bearer service <name> with data rate <speed> and the connection element <ce> to be used when data calls are originated. Response +CBST: (list of supported <speed>s), (list of supported <name>s), (list of supported <ce>s) OK Parameter <speed> <table border="0" style="margin-left: 40px;"> <tr><td>0</td><td>auto bauding</td></tr> <tr><td>4</td><td>2400 bps (V.22bis)</td></tr> <tr><td>6</td><td>4800 bps (V.32)</td></tr> <tr><td><u>7</u></td><td>9600 bps (V.32)</td></tr> <tr><td>14</td><td>14400 bps (V.34)</td></tr> <tr><td>68</td><td>2400 bps (V.110)</td></tr> <tr><td>70</td><td>4800 bps (V.110)</td></tr> <tr><td>71</td><td>9600 bps (V.110)</td></tr> <tr><td>75</td><td>14400 bps (V.110)</td></tr> </table> <hr/> <name> <u>0</u> asynchronous modem <ce> 1 non-transparent	0	auto bauding	4	2400 bps (V.22bis)	6	4800 bps (V.32)	<u>7</u>	9600 bps (V.32)	14	14400 bps (V.34)	68	2400 bps (V.110)	70	4800 bps (V.110)	71	9600 bps (V.110)	75	14400 bps (V.110)
0	auto bauding																		
4	2400 bps (V.22bis)																		
6	4800 bps (V.32)																		
<u>7</u>	9600 bps (V.32)																		
14	14400 bps (V.34)																		
68	2400 bps (V.110)																		
70	4800 bps (V.110)																		
71	9600 bps (V.110)																		
75	14400 bps (V.110)																		
Read command AT+ CBST?	Response +CBST: <speed>,<name>,<ce> OK																		
Write command AT+ CBST=<speed>[,0,1]																			
	Parameter <speed> See Test command Response OK																		

2.3.11 Fax commands

The following commands can be used for FAX transmission. If the ME is acting as a FAX modem to a PC-based application, it is necessary to select the appropriate service class (FAX class) provided by the ME. The ME reports its FAX service class capabilities, both the current setting and the range of services available, via the AT+FCLASS command.

Note: According to EIA/TIA-592-A, the Error Correcting Mode (ECM) should not be used when sending FAXes over GSM.

+FCLASS parameter	Service Class	Reference, Standard
0		e.g. TIA/EIA-602 or ITU V.25ter
1	Service Class 1	EIA/TIA-578-A
2	Vendor-specific	this document and EIA PN-2388 (draft)

The following FAX commands are dummy commands. Invoking these commands will not cause ERROR result codes, but these commands have no functionality either:

Command	Meaning
AT+FAA	Auto Answer mode
AT+FECM	Error Correction Mode control
AT+FLNFC	Page Length format conversion
AT+FLPL	Indicate document available for polling
AT+FMINSPL	Minimum Phase C speed
AT+FRBC	Phase C data receive byte count
AT+FREL	Phase C received EOL alignment
AT+FSPL	Enable polling
AT+FTBC	Phase C data transmit byte count
AT+FWDFC	Page width format conversion

Table 2-9: List of dummy FAX commands

2.3.11.1 AT+FBADLIN

AT+ FBADLIN	Define or read number of bad lines		
	<p>Used for FAX class 2 only This command defines the "Copy Quality OK" threshold. If pixel count errors were detected in normal resolution (98 dpi) mode in as many consecutive lines as defined in <badlin>, the copy quality is unacceptable.</p> <p>If pixel count errors were detected in fine resolution (196 dpi) mode in twice as many consecutive lines as defined in <badlin>, the copy quality is unacceptable.</p> <p>"Copy Quality Not OK" occurs if either the error percentage is too high or if too many consecutive lines contain errors</p>		
Read command AT+ FBADLIN?	Response <badlin> OK Parameter <badlin>	See Write command	
Write command AT+FBADLIN=<badlin>	Parameter <badlin>	0...255	0 indicates that error checking is present or disabled (Default value: 10)

2.3.11.2 AT+FBADMUL

AT+ FBADMUL	Define, read or test number of bad lines
	Used for FAX class 2 only This command defines the "Copy-Quality-OK" multiplier. The number of lines received with a bad pixel count is multiplied by this number. If the result exceeds the total number of lines on the page the error rate is considered too high. A threshold multiplier value of 20 corresponds to a 5% error rate.
Read command AT+ FBADMUL?	Response Parameter <n> OK
Write command AT+ FBADMUL =<n>	Parameter 0...255 <n> 0 indicates that error checking is present or disabled (Default value: 20)

2.3.11.3 AT+FBOR

AT+ FBOR	Query the bit order for receive mode
	Used for FAX class 2 only Query the bit order for receive-mode. The mode is set by the ME dependent on the selected Service Class.
Test command AT+FBOR=?	Response +FBOR: (list of supported bit order modes <bor>s) OK Parameter <bor> 0 direct bit order for both Phase C and Phase B/D data 1 Reversed bit order for Phase C data, direct bit order for Phase B/D data
Read command AT+FBOR?	Response Parameter <bor> OK
Write command AT+FBOR=<bor>	Response OK / ERROR
	Parameter <bor> OK

2.3.11.4 AT+FCIG

AT+FCIG	Query or set the Local polling id
Test command AT+FCIG=?	<p>Used for FAX class 2 only</p> <p>Response +FCIG: (max. length of Local Polling ID string) (range of supported ASCII character values) OK Parameter <id> Local Polling ID string, max. length and possible content as reported by test command. Default value is empty string ("").</p> <p>See also "AT+FLID" command</p>
Read command AT+FCIG?	<p>Response <id> OK Parameter <id> See Test command</p>
Write command AT+FCIG=<id>	<p>Parameter <id> See Test command</p>

2.3.11.5 AT+FCQ

AT+FCQ	Control Copy Quality				
Test command AT+FCQ=?	<p>This command controls Copy Quality checking when receiving a fax</p> <p>Used for FAX class 2 only</p> <p>Response +FCQ: (list of supported copy quality checking <cq>s) OK Parameter <cq></p> <table border="0"> <tr> <td style="padding-right: 20px;">0</td> <td>No checking of copy quality performed. The ME will generate Copy Quality OK (MCF) responses to complete pages</td> </tr> <tr> <td>1</td> <td>ME can check 1-D phase data. The connected application must check copy quality for 2-D phase C data</td> </tr> </table>	0	No checking of copy quality performed. The ME will generate Copy Quality OK (MCF) responses to complete pages	1	ME can check 1-D phase data. The connected application must check copy quality for 2-D phase C data
0	No checking of copy quality performed. The ME will generate Copy Quality OK (MCF) responses to complete pages				
1	ME can check 1-D phase data. The connected application must check copy quality for 2-D phase C data				
Read command AT+FCQ?	<p>Response <cq> OK Parameter <cq> See Test command</p>				
Write command AT+FCQ=<id>	<p>Parameter <cq> See Test command</p>				

2.3.11.6 AT+FCLASS

AT+FCLASS	Select, read or test FAX service class
Test command AT+FCLASS=?	Response +FCLASS: (list of supported <n>s) OK Parameter <n> 0 data (e.g. EIA/TIA-602 or ITU V.25ter) 1 Fax class 1 (EIA/TIA-578-A, Service Class 1) 2 Vendor-specific (Fax class 2 (EIA/TIA SP-2388, an early draft version of EIA/TIA-592-A – Service class 2.1))
Read command AT+FCLASS?	Response <n> OK Parameter <n> See Test command
Write command AT+FCLASS=<n>	Parameter <n> See Test command

2.3.11.7 AT+FCR

AT+ FCR	Capability to receive
Write command AT+FCR=<cr>	Response OK Parameter <cr> 0 ME cannot receive message data. This value can be used when the application has insufficient storage. The ME can send and can be polled for a file.
	1 ME can receive message data. Used for FAX class 2 only

2.3.11.8 AT+FDCC

AT+FDCC	Select service for MO SMS messages																
<p>Test command AT+FDCC=?</p>	<p>This command allows the connected application to sense and constrain the capabilities of the facsimile DCE (=ME), from the choices defined in ITU T.30 Table 2.</p> <p>Used for Faxclass 2 only</p> <p>Response +FDCC: (list of <VR>s), (list of
s), (list of <WD>s), (list of <LN>s), (list of <DF>s), (list of <EC>s), (list of <BF>s), (list of <ST>s)</p> <p>Parameter</p> <table border="0"> <tr> <td>VR</td> <td>Vertical Resolution</td> </tr> <tr> <td>BR</td> <td>Bit rate</td> </tr> <tr> <td>WD</td> <td>Page Width</td> </tr> <tr> <td>LN</td> <td>Page length</td> </tr> <tr> <td>DF</td> <td>Data compression Format</td> </tr> <tr> <td>EC</td> <td>Error Correction mode</td> </tr> <tr> <td>BF</td> <td>Binary File transfer mode</td> </tr> <tr> <td>ST</td> <td>Scan Time / line</td> </tr> </table> <p>Note: For further information see AT+FDIS</p>	VR	Vertical Resolution	BR	Bit rate	WD	Page Width	LN	Page length	DF	Data compression Format	EC	Error Correction mode	BF	Binary File transfer mode	ST	Scan Time / line
VR	Vertical Resolution																
BR	Bit rate																
WD	Page Width																
LN	Page length																
DF	Data compression Format																
EC	Error Correction mode																
BF	Binary File transfer mode																
ST	Scan Time / line																
<p>Read command AT+FDCC?</p>	<p>Response <dcc> OK</p> <p>Parameter</p> <table border="0"> <tr> <td>VR</td> <td>See Test command</td> </tr> <tr> <td>BR</td> <td>See Test command</td> </tr> <tr> <td>WD</td> <td>See Test command</td> </tr> <tr> <td>LN</td> <td>See Test command</td> </tr> <tr> <td>DF</td> <td>See Test command</td> </tr> <tr> <td>EC</td> <td>See Test command</td> </tr> <tr> <td>BF</td> <td>See Test command</td> </tr> <tr> <td>ST</td> <td>See Test command</td> </tr> </table>	VR	See Test command	BR	See Test command	WD	See Test command	LN	See Test command	DF	See Test command	EC	See Test command	BF	See Test command	ST	See Test command
VR	See Test command																
BR	See Test command																
WD	See Test command																
LN	See Test command																
DF	See Test command																
EC	See Test command																
BF	See Test command																
ST	See Test command																
<p>Write command AT+FDCC=<VR>,
,<WD>,<LN>,<DF>,<EC>,<BF>,<ST></p>	<p>Response +FDCC: (list of <VR>s), (list of
s), (list of <WD>s), (list of <LN>s), (list of <DF>s), (list of <EC>s), (list of <BF>s), (list of <ST>s)</p> <p>Parameter</p> <table border="0"> <tr> <td>VR</td> <td>See Test command</td> </tr> <tr> <td>BR</td> <td>See Test command</td> </tr> <tr> <td>WD</td> <td>See Test command</td> </tr> <tr> <td>LN</td> <td>See Test command</td> </tr> <tr> <td>DF</td> <td>See Test command</td> </tr> <tr> <td>EC</td> <td>See Test command</td> </tr> <tr> <td>BF</td> <td>See Test command</td> </tr> <tr> <td>ST</td> <td>See Test command</td> </tr> </table>	VR	See Test command	BR	See Test command	WD	See Test command	LN	See Test command	DF	See Test command	EC	See Test command	BF	See Test command	ST	See Test command
VR	See Test command																
BR	See Test command																
WD	See Test command																
LN	See Test command																
DF	See Test command																
EC	See Test command																
BF	See Test command																
ST	See Test command																

2.3.11.10 AT+FDIS

AT+FDIS	Query or set session parameters																																																																												
	<p>Used for FAX class 2 only</p> <p>This command allows the controlling application to set and constrain the capabilities used for the current session. +FDIS is used to generate DIS or DTC messages directly. +FDIS (and received DIS messages) is also used to generate DCS messages.</p>																																																																												
<p>Test command AT+FDIS=?</p>	<p>Response +FDIS: (list of <VR>s), (list of
s), (list of <WD>s), (list of <LN>s), (list of <DF>s), (list of <EC>s), (list of <BF>s), (list of <ST>s)</p> <p>Parameter</p> <table border="1"> <tr> <td>VR</td> <td>Vertical Resolution</td> </tr> <tr> <td>0</td> <td>normal, 98 lpi</td> </tr> <tr> <td>1</td> <td>fine, 196 lpi</td> </tr> <tr> <td>BR</td> <td>Bit rate</td> </tr> <tr> <td>0</td> <td>2400 bit/s, V.27ter</td> </tr> <tr> <td>1</td> <td>4800 bit/s, V.27ter</td> </tr> <tr> <td>2</td> <td>7200 bit/s, V.29</td> </tr> <tr> <td>3</td> <td>9600 bit/s, V.29</td> </tr> <tr> <td>WD</td> <td>Page Width</td> </tr> <tr> <td>0[*])</td> <td>1728 pixels in 215mm</td> </tr> <tr> <td>1</td> <td>2048 pixels in 255 mm</td> </tr> <tr> <td>2</td> <td>2432 pixels in 303 mm</td> </tr> <tr> <td>3</td> <td>1216 pixels in 151 mm</td> </tr> <tr> <td>4</td> <td>864 pixels in 107 mm</td> </tr> <tr> <td>LN</td> <td>Page length</td> </tr> <tr> <td>0</td> <td>A4, 297mm</td> </tr> <tr> <td>1</td> <td>B4, 364mm</td> </tr> <tr> <td>2</td> <td>unlimited length</td> </tr> <tr> <td>DF</td> <td>Data compression Format</td> </tr> <tr> <td>0[*])</td> <td>1-D modified Huffman</td> </tr> <tr> <td>1</td> <td>2-D modified read</td> </tr> <tr> <td>2</td> <td>2-D uncompressed mode</td> </tr> <tr> <td>EC</td> <td>Error Correction mode</td> </tr> <tr> <td>0[*])</td> <td>disable ECM</td> </tr> <tr> <td>1</td> <td>enable ECM, 64 bytes/frame</td> </tr> <tr> <td>2</td> <td>enable ECM, 256 bytes/frame</td> </tr> <tr> <td>BF</td> <td>Binary Fole transfer mode</td> </tr> <tr> <td>0[*])</td> <td>disable BFT</td> </tr> <tr> <td>1</td> <td>enable BFT</td> </tr> <tr> <td>ST</td> <td>Scan Time / line</td> </tr> <tr> <td>0[*])</td> <td>0 ms (at VR= normal)</td> </tr> <tr> <td>1</td> <td>5 ms</td> </tr> <tr> <td>2</td> <td>10 ms</td> </tr> <tr> <td>3</td> <td>10 ms</td> </tr> <tr> <td>4</td> <td>20 ms</td> </tr> <tr> <td>5</td> <td>20 ms</td> </tr> <tr> <td>6</td> <td>40 ms</td> </tr> <tr> <td>7</td> <td>40 ms</td> </tr> </table>	VR	Vertical Resolution	0	normal, 98 lpi	1	fine, 196 lpi	BR	Bit rate	0	2400 bit/s, V.27ter	1	4800 bit/s, V.27ter	2	7200 bit/s, V.29	3	9600 bit/s, V.29	WD	Page Width	0 [*])	1728 pixels in 215mm	1	2048 pixels in 255 mm	2	2432 pixels in 303 mm	3	1216 pixels in 151 mm	4	864 pixels in 107 mm	LN	Page length	0	A4, 297mm	1	B4, 364mm	2	unlimited length	DF	Data compression Format	0 [*])	1-D modified Huffman	1	2-D modified read	2	2-D uncompressed mode	EC	Error Correction mode	0 [*])	disable ECM	1	enable ECM, 64 bytes/frame	2	enable ECM, 256 bytes/frame	BF	Binary Fole transfer mode	0 [*])	disable BFT	1	enable BFT	ST	Scan Time / line	0 [*])	0 ms (at VR= normal)	1	5 ms	2	10 ms	3	10 ms	4	20 ms	5	20 ms	6	40 ms	7	40 ms
VR	Vertical Resolution																																																																												
0	normal, 98 lpi																																																																												
1	fine, 196 lpi																																																																												
BR	Bit rate																																																																												
0	2400 bit/s, V.27ter																																																																												
1	4800 bit/s, V.27ter																																																																												
2	7200 bit/s, V.29																																																																												
3	9600 bit/s, V.29																																																																												
WD	Page Width																																																																												
0 [*])	1728 pixels in 215mm																																																																												
1	2048 pixels in 255 mm																																																																												
2	2432 pixels in 303 mm																																																																												
3	1216 pixels in 151 mm																																																																												
4	864 pixels in 107 mm																																																																												
LN	Page length																																																																												
0	A4, 297mm																																																																												
1	B4, 364mm																																																																												
2	unlimited length																																																																												
DF	Data compression Format																																																																												
0 [*])	1-D modified Huffman																																																																												
1	2-D modified read																																																																												
2	2-D uncompressed mode																																																																												
EC	Error Correction mode																																																																												
0 [*])	disable ECM																																																																												
1	enable ECM, 64 bytes/frame																																																																												
2	enable ECM, 256 bytes/frame																																																																												
BF	Binary Fole transfer mode																																																																												
0 [*])	disable BFT																																																																												
1	enable BFT																																																																												
ST	Scan Time / line																																																																												
0 [*])	0 ms (at VR= normal)																																																																												
1	5 ms																																																																												
2	10 ms																																																																												
3	10 ms																																																																												
4	20 ms																																																																												
5	20 ms																																																																												
6	40 ms																																																																												
7	40 ms																																																																												
(Continued next page)																																																																													

Cont.	*) Note: Only the default value needs to be implemented. Use test command to check which parameter values are in fact possible!
Read command AT+FDIS?	Response <cdec> OK Parameter VR See Test command BR See Test command WD See Test command LN See Test command DF See Test command EC See Test command BF See Test command ST See Test command
Write command AT+FDIS=<VR>, ,<WD>,<LN>,<DF>,<EC>,<BF>,<ST>	Response +FDIS: (list of <VR>s), (list of s), (list of <WD>s), (list of <LN>s), (list of <DF>s), (list of <EC>s), (list of <BF>s), (list of <ST>s) Parameter VR See Test command BR See Test command WD See Test command LN See Test command DF See Test command EC See Test command BF See Test command ST See Test command

2.3.11.11 AT+FDR

AT+FDR	Begin or continue phase C data reception
Execute command AT+FDR	Used for FAX class 2 only This command initiates transition to Phase C data reception. Response CONNECT/OK/ERROR

2.3.11.12 AT+FDT

AT+FDT	Data Transmission	
	<p>Used for FAX class 2 only</p> <p>This command requests the ME to transmit a Phase C page. When the ME is ready to accept Phase C data, it issues the negotiation responses and the CONNECT result code to the application.</p> <p>In Phase B, this command releases the ME to proceed with negotiation, and releases the DCS message to the remote station.</p> <p>In Phase C, this command resumes transmission after the end of a data stream transmitted before.</p>	
Execute command AT+FDT		
	Parameter	
	<dt>	list of <DF>s, <VR>s, <WD>s, <LN>s
	DF	Data compression Format
	0*)	1-D modified Huffman
	1	2-D modified read
	2	2-D uncompressed mode
	VR	Vertical Resolution
	0	normal, 98 lpi
	1	fine, 196 lpi
	WD	Page Width
	0*)	1728 pixels in 215mm
	1	2048 pixels in 255 mm
	2	2432 pixels in 303 mm
	3	1216 pixels in 151 mm
	4	864 pixels in 107 mm
	LN	Page length
	0	A4, 297mm
	1	B4, 364mm
	2	unlimited length
	Response	CONNECT

2.3.11.13 AT+FET

AT+FET	End a page or document	
	<p>Used for FAX class 2 only</p> <p>This command indicates that the current page or part thereof is complete. An ERROR response code results if this command is issued while the mode is on-hook.</p>	
Write command AT+FET=<ppm>	Parameter: <ppm>	
		Post Page Message Codes
	1	another document next
	2	no more pages or documents
	4	another page, procedure interrupt
	5	another document, procedure interrupt
	Response	OK/ERROR

2.3.11.14 AT+FK

AT+FK	Kill operation, orderly FAX abort
Execute command AT+FK	Used for FAX class 2 only This command causes the TA to terminate the session in an orderly manner. Response OK/ERROR

2.3.11.15 AT+FLID

AT+FLID	Query or set session parameters
	Used for FAX class 2 only
Test command AT+FLID=?	Parameter <lid> Local ID string, max. length and possible content as reported by test command. Default value is empty string (""). See also the "AT+FCIG" command Response +FLID: (max. character length of Local ID string) (range of supported ASCII character values)
Read command AT+FLID?	OK Response <lid> OK Parameter <lid> See Test Command
Write command AT+FLID=<lid>	Parameter <lid> See Test command Response +FLID: (max. character length of Local ID string) (range of supported ASCII character values) OK

2.3.11.16 AT+FMDL

AT+FMDL	Identify Product Model
Read command AT+FMDL?	Used for FAX class 2 only Send the model identification to the TA. Response Gipsy Soft Protocolstack OK

2.3.11.17 AT+FMFR

AT+FMFR	Request Manufacturer Identification
Read command AT+FMFR?	Used for FAX class 2 only Send the model identification to the TA. Response Siemens OK

2.3.11.18 AT+FOPT

AT+FOPT	Set bit order independently
Write command AT+FOPT=<opt>	Used for FAX class 2 only Model-specific command to set bit order independently of the understanding which is "mirrored" and which is direct. Parameter: <opt> 0 non-standard 1 standard Response OK

2.3.11.19 AT+FPHCTO

AT+FPHCTO	DTE Phase C Response Timeout
Read command AT+FPHCTO?	Used for FAX class 2 only Send the model identification to the TA. Response <tout> OK/ERROR
Write command AT+FPHCTO=<tout>	Used for FAX class 2 only Model-specific command to set bit order independently of the understanding which is "mirrored" and which is direct. Parameter: <tout> 0...255 determines how long the DCE will wait for a command after reaching the end of data when transmitting in Phase C. When time-out is reached, the DCE assumes that there are no more pages or documents to send. Time-out value in 100ms units. 30 default Response <tout> OK/ERROR

2.3.11.23 AT+FRS

AT+FRS	Receive Silence
Write command AT+FRS=<time>	<p>Used for FAX class 1 only This command causes the TA to report an OK result code to the TE after <time> 10 millisecond intervals of silence have been detected on the line. This command is aborted if any character is received by the DTE. The modem discards the aborting character and issues an OK result code. An ERROR response code results if this command is issued while the mode is on-hook.</p> <p>Parameter <time> 0 .. 255 number of 10 millisecond intervals</p> <p>Response (List of supported modulation modes <mod>s) OK</p>

2.3.11.24 AT+FTH

AT+FTH	Transmit Data Using HDLC Framing
Write command AT+FTH=<mod>	<p>Used for FAX class 1 only This command causes the TA to transmit data using HDLC protocol and the modulation mode defined below. An ERROR response code results if this command is issued while the modem is on-hook.</p> <p>Parameter 3 V.21 Ch2 300 bps</p> <p><mod></p> <p>Response CONNECT</p>

2.3.11.25 AT+FTM

AT+FTM	Transmit Data
Test command AT+FTM=?	<p>Used for FAX class 1 only This command causes the TA to transmit data using the modulation mode defined below. An ERROR response code results if this command is issued while the modem is on-hook.</p> <p>Parameter modulation mode</p> <p><mod></p> <p> 96 V.29 9600 bps</p> <p> 72 V.29 7200 bps</p> <p> 48 V.27ter 4800 bps</p> <p> 24 V.27ter 2400 bps</p>
Write command AT+FTM=<mod>	<p>Parameter <mod> See Test command</p> <p>Response CONNECT</p>

2.3.11.26 AT+FTS

AT+FTS	Stop Transmission and Wait
Write command AT+FTS=<time>	<p>Used for FAX class 1 only</p> <p>This command causes the TA to terminate a transmission and wait for <time> 10 millisecond intervals before responding with the OK result code to the DTE. An ERROR response code results if this command is issued while the modem is on-hook</p> <p>Parameter <time> 0 .. 85 number of 10 millisecond intervals</p>

2.3.11.27 AT+FVRF

AT+FVRFC	Vertical resolution format conversion
Test command AT+FVRFC=?	<p>Used for FAX class 2 only</p> <p>This command determines the DCE response to a mismatch between the vertical resolution negotiated for the facsimile session and the Phase C data desired by the DTE. An ERROR response code results if this command is issued while the modem is on-hook</p> <p>Response (List of supported mismatch checking modes)</p> <p>OK</p> <p>Parameter 0 disable mismatch checking</p> <p><vrfc> 2 enable mismatch checking, with resolution conversion of 1-D data in the DCE and an implied AT+FK command executed on 2-D mismatch detection</p>
Read command AT+FVRFC?	<p>Response <vrfc></p> <p>OK</p> <p>Parameter <vrfc> See Test command</p>
Write command AT+FVRFC=<vrfc>	<p>Response OK</p> <p>Parameter <vrfc> See Test command</p>

2.3.12 Bluetooth related commands

This section provides descriptions of commands related to Bluetooth application. AT commands defined in this chapter are only to be used over a bluetooth connection between mobile and devices such as Headset or CarKit. This commands are actually specified in the Bluetooth Profile Description and not in an ETSI specification.

2.3.12.1 AT+VGS (Headset and Handsfree (e.g. CarKit) Profile)

AT+VGS	Gain of the Speaker Volume
Test command AT+VGS=?	Response OK
Write command AT+VGS=<vol>	Response OK/ERROR/+CME ERROR Parameter <gain> 0 .. 15 Minimum Gain Maximum Gain Unsolicited message +VGS: <gain>

2.3.12.2 AT+BLDN (Handsfree Profile)

AT+BLDN	Redial Last Number
Execute command AT+BLDN;	Dial Last number! Similar to ATDL command but only for connection over Bluetooth. Response OK/ERROR/+CME ERROR

2.3.12.3 AT+BINP (Handsfree Profile)

AT+BINP	Phone number corresponding to the last voice tag recorded in the HF
Test command AT+BINP=?	Response OK
Write command AT+BINP=1	Response +BINP: <number>, <type> OK/ERROR/+CME ERROR <number> Telephone number <type> Type of number

2.3.12.4 AT+BVRA (Handsfree Profile)

AT+BVRA	Voice Recognition Activation
Test command AT+BVRA=?	Response OK
Write command AT+BVRA=<vrec>	Response OK/ERROR/+CME ERROR Parameter <vrec> 0 Disable Voice Recognition 1 Enable Voice Recognition Unsolicited message +BVRA: <vrec>

2.3.12.5 AT+NREC (Handsfree Profile)

AT+NREC	Noise Reduction and Echo Canceling
Test command AT+NREC=?	Response OK
Write command AT+NREC=<nrec>	Response OK/ERROR/+CME ERROR Parameter <nrec> 0 Disable Noise Reduction and Echo Cancellation 1 Enable Noise Reduction and Echo Cancellation

2.4 General commands according to ITU-T Recommendation V.25ter

This section provides the descriptions of general ITU-T Recommendation V.25ter commands.

2.4.1.1 AT+GCAP

AT+GCAP	Request Capabilities List
Test command AT+GCAP=?	Response OK/ERROR
Read command AT+GCAP?	Response +GCAP: <mode> Parameter <mode> : e.g. +CGSM,+FCLASS

2.4.1.2 AT+IPR

AT+IPR	Fixed DTE rate
Test command AT+IPR=?	Response +IPR:(list of fixed-only <rate> values) OK/ERROR/+CME ERROR
	Parameter: <rate> bits per second at which the DTE-DCE interface should operate
Read command AT+IPR?	Response +IPR: <rate> OK/ERROR/+CME ERROR Parameter <rate> See Test command
Write command AT+IPR=<rate>	Response OK/ERROR/+CME ERROR
Write command AT+IPR=<rate>	Parameter <rate> See Test command

2.4.2 User-defined commands for controlling the GSM mobile phone

Since user-defined commands cannot be implemented according to official syntax, the character string "+C" is replaced by "^S" ("^" = 0x5E). In future, if a user-defined command is accepted in the same syntax in GSM recommendations, the command can be addressed using either command string.

2.4.2.1 AT^SACM

AT^SACM	Output ACM (accumulated call meter) and ACMmax
Test command AT^SACM=?	Response ^SACM: (list of supported <n>s)
Execute command AT^SACM	Response ^SACM: <n>,<acm>,<acm_max> OK/ERROR/+CME ERROR Parameter <n> See Write command <acm> Accumulated call meter <acm_max> Maximum accumulated call meter
Write command AT^SACM=<n>	Parameter <n> 0 Suppresses the unsolicited message 1 Displays the unsolicited message Unsolicited message ^SACM: <m>; Parameter <m> 1 ACM limit almost reached 2 ACM greater than ACMmax 3 ACM range overflow

2.4.2.2 AT^SBNR

AT^SBNR	Binary Read
Test command AT^SBNR=?	Response ^SBNR: (list of supported <types>s, (list of supported <subtype>s)) OK/ERROR/+CME ERROR Parameter: <type> see AT^SBNW command <subtype> see AT^SBNW command
Write command AT^SBNR=<type>,<subtype>	Response ^SBNR: <type>,<subtype>,1,<maxNumber> <CR><LF><data><CR><LF> ^SBNR: <type>,<subtype>,2,<maxNumber> <CR><LF><data><CR><LF>[...] OK/ERROR/+CME ERROR Parameter: <type> see AT^SBNW command <subtype> see AT^SBNW command <data> data in hexadecimal form (PDU) <maxNumber> see AT^SBNW command See "Appendix B" for examples

2.4.2.3 AT^SBNW

AT^SBNW	Binary Write																																				
Test command AT^SBNW=?	Response ^SBNW: (list of supported <types>s, list of supported <subtype>s) OK/ERROR/+CME ERROR:																																				
	Parameter: <table border="0"> <tr> <td style="vertical-align: top;"><type></td> <td style="vertical-align: top;"> <table border="0"> <tr> <td style="vertical-align: top;">bmp</td> <td style="vertical-align: top;"> Bitmap; Windows bitmap format compression; 2/16/256 colours <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">shown permanently when registered in home network</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">shown temporarily, deleted by more important display contents</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">mid</td> <td style="vertical-align: top;"> ring tones in standard MIDI format 0, without polyphony specification: http://www.midi.org <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type mid</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">vcs</td> <td style="vertical-align: top;"> vcal format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcs</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcs</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">vcf</td> <td style="vertical-align: top;"> vcard format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcf</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcf</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">t9d</td> <td style="vertical-align: top;"> Tegic database for t9 text recognition. <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type t9d</td> </tr> </table> </td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;"><actNumber></td> <td style="vertical-align: top;"> <table border="0"> <tr> <td style="vertical-align: top;">0</td> <td style="vertical-align: top;">deletes entry of the current subtype</td> </tr> <tr> <td style="vertical-align: top;">other</td> <td style="vertical-align: top;">current packet number</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;"><maxNumber></td> <td style="vertical-align: top;">maximum number of packets</td> </tr> </table>	<type>	<table border="0"> <tr> <td style="vertical-align: top;">bmp</td> <td style="vertical-align: top;"> Bitmap; Windows bitmap format compression; 2/16/256 colours <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">shown permanently when registered in home network</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">shown temporarily, deleted by more important display contents</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">mid</td> <td style="vertical-align: top;"> ring tones in standard MIDI format 0, without polyphony specification: http://www.midi.org <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type mid</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">vcs</td> <td style="vertical-align: top;"> vcal format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcs</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcs</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">vcf</td> <td style="vertical-align: top;"> vcard format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcf</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcf</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">t9d</td> <td style="vertical-align: top;"> Tegic database for t9 text recognition. <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type t9d</td> </tr> </table> </td> </tr> </table>	bmp	Bitmap; Windows bitmap format compression; 2/16/256 colours <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">shown permanently when registered in home network</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">shown temporarily, deleted by more important display contents</td> </tr> </table>	<subtype> 0	shown permanently when registered in home network	<subtype> 1	shown temporarily, deleted by more important display contents	mid	ring tones in standard MIDI format 0, without polyphony specification: http://www.midi.org <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type mid</td> </tr> </table>	<subtype> 0	first (and only) entry of type mid	vcs	vcal format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcs</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcs</td> </tr> </table>	<subtype> 0	first (and only) entry of type vcs	<subtype> 1	entry of type vcs	vcf	vcard format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcf</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcf</td> </tr> </table>	<subtype> 0	first (and only) entry of type vcf	<subtype> 1	entry of type vcf	t9d	Tegic database for t9 text recognition. <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type t9d</td> </tr> </table>	<subtype> 0	first (and only) entry of type t9d	<actNumber>	<table border="0"> <tr> <td style="vertical-align: top;">0</td> <td style="vertical-align: top;">deletes entry of the current subtype</td> </tr> <tr> <td style="vertical-align: top;">other</td> <td style="vertical-align: top;">current packet number</td> </tr> </table>	0	deletes entry of the current subtype	other	current packet number	<maxNumber>	maximum number of packets
<type>	<table border="0"> <tr> <td style="vertical-align: top;">bmp</td> <td style="vertical-align: top;"> Bitmap; Windows bitmap format compression; 2/16/256 colours <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">shown permanently when registered in home network</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">shown temporarily, deleted by more important display contents</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">mid</td> <td style="vertical-align: top;"> ring tones in standard MIDI format 0, without polyphony specification: http://www.midi.org <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type mid</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">vcs</td> <td style="vertical-align: top;"> vcal format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcs</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcs</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">vcf</td> <td style="vertical-align: top;"> vcard format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcf</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcf</td> </tr> </table> </td> </tr> <tr> <td style="vertical-align: top;">t9d</td> <td style="vertical-align: top;"> Tegic database for t9 text recognition. <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type t9d</td> </tr> </table> </td> </tr> </table>	bmp	Bitmap; Windows bitmap format compression; 2/16/256 colours <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">shown permanently when registered in home network</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">shown temporarily, deleted by more important display contents</td> </tr> </table>	<subtype> 0	shown permanently when registered in home network	<subtype> 1	shown temporarily, deleted by more important display contents	mid	ring tones in standard MIDI format 0, without polyphony specification: http://www.midi.org <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type mid</td> </tr> </table>	<subtype> 0	first (and only) entry of type mid	vcs	vcal format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcs</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcs</td> </tr> </table>	<subtype> 0	first (and only) entry of type vcs	<subtype> 1	entry of type vcs	vcf	vcard format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcf</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcf</td> </tr> </table>	<subtype> 0	first (and only) entry of type vcf	<subtype> 1	entry of type vcf	t9d	Tegic database for t9 text recognition. <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type t9d</td> </tr> </table>	<subtype> 0	first (and only) entry of type t9d										
bmp	Bitmap; Windows bitmap format compression; 2/16/256 colours <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">shown permanently when registered in home network</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">shown temporarily, deleted by more important display contents</td> </tr> </table>	<subtype> 0	shown permanently when registered in home network	<subtype> 1	shown temporarily, deleted by more important display contents																																
<subtype> 0	shown permanently when registered in home network																																				
<subtype> 1	shown temporarily, deleted by more important display contents																																				
mid	ring tones in standard MIDI format 0, without polyphony specification: http://www.midi.org <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type mid</td> </tr> </table>	<subtype> 0	first (and only) entry of type mid																																		
<subtype> 0	first (and only) entry of type mid																																				
vcs	vcal format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcs</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcs</td> </tr> </table>	<subtype> 0	first (and only) entry of type vcs	<subtype> 1	entry of type vcs																																
<subtype> 0	first (and only) entry of type vcs																																				
<subtype> 1	entry of type vcs																																				
vcf	vcard format specification: http://www.imc.org/pdi <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type vcf</td> </tr> <tr> <td style="vertical-align: top;"><subtype> 1</td> <td style="vertical-align: top;">entry of type vcf</td> </tr> </table>	<subtype> 0	first (and only) entry of type vcf	<subtype> 1	entry of type vcf																																
<subtype> 0	first (and only) entry of type vcf																																				
<subtype> 1	entry of type vcf																																				
t9d	Tegic database for t9 text recognition. <table border="0"> <tr> <td style="vertical-align: top;"><subtype> 0</td> <td style="vertical-align: top;">first (and only) entry of type t9d</td> </tr> </table>	<subtype> 0	first (and only) entry of type t9d																																		
<subtype> 0	first (and only) entry of type t9d																																				
<actNumber>	<table border="0"> <tr> <td style="vertical-align: top;">0</td> <td style="vertical-align: top;">deletes entry of the current subtype</td> </tr> <tr> <td style="vertical-align: top;">other</td> <td style="vertical-align: top;">current packet number</td> </tr> </table>	0	deletes entry of the current subtype	other	current packet number																																
0	deletes entry of the current subtype																																				
other	current packet number																																				
<maxNumber>	maximum number of packets																																				
Write command AT^SBNW=<type>,<subtype>, [<actNumber>[, <maxNumber>]]<CR> PDU is given: <ctrl-Z/ESC>	Response OK/ERROR/+CME ERROR Parameter: see Test command <type> <subtype> see Test command <actNumber> see Test command <maxNumber> see Test command																																				
Notes:	<ul style="list-style-type: none"> - It is not possible to upload data when a call is active or in progress. - If a call is active the mobile responds with +CME ERROR: PHONE BUSY, the current upload sequence is aborted and all data packets are discarded. - If uploaded data is not useable (e.g. wrong data format) the mobile responds with +CME ERROR: INV CHAR IN TEXT after the last packet is uploaded. - To get the extended +CME ERROR response, AT+CMEE=2 has to be sent first. Otherwise the mobile only returns an ERROR. (see 1) - If <actNumber> and <maxNumber> are omitted during the upload, the mobile aborts the whole input sequence for the current subtype. - If <actNumber> is 0 during the upload and <maxNumber> is omitted, the mobile deletes the current record with index <subtype> - Packets have to be uploaded in the right order! 																																				
Restriction	The maximum pdu size is 176 bytes (or 352 characters) See "Appendix B" for examples.																																				

2.4.2.4 AT^SCID

AT^SCID	Output card ID
Test command AT^SCID=?	Response OK/ERROR/+CME ERROR
Execute command AT^SCID	Response ^SCID: <cid> OK/ERROR/+CME ERROR Parameter <cid> Number of SIM card

2.4.2.5 AT^SCKS

AT^SCKS	Output SIM card status
Test command AT^SCKS=?	Response ^SCKS: (list of supported <n>s) Parameter 0 Suppresses the unsolicited messages <n> 1 Displays the unsolicited messages
Read command AT^SCKS?	Response ^SCKS: <n>, <m> Parameter <m> 0 No card 1 Card in card reader
Write command AT^SCKS=<n>	Parameter <n> See Test command Response OK/ERROR Unsolicited message ^SCKS: <m>

2.4.2.6 AT^SCNI

AT^SCNI	Output call number information
Test command AT^SCNI=?	Response OK
Execute command AT^SCNI	Response ^SCNI: 1[,<cs>[,<number>,<type>]]<CR><LF> ^SCNI: 2[,<cs>[,<number>,<type>]]<CR><LF> ^SCNI: 3[,<cs>[,<number>,<type>]]<CR><LF> ^SCNI: 4[,<cs>[,<number>,<type>]]<CR><LF> ^SCNI: 5[,<cs>[,<number>,<type>]]<CR><LF> ^SCNI: 6[,<cs>[,<number>,<type>]]<CR><LF> ^SCNI: 7[,<cs>[,<number>,<type>]] OK/ERROR/+CME ERROR Parameter <cs> Call status of affiliated call number (first parameter) 0 Call on hold 1 Active call 2 Waiting call _____ <number> Telephone number <type> Type of number

2.4.2.7 AT^SDBR

AT^SDBR		Database Read	
Test command AT^SDBR=?		Response ^SDBR: (list of supported <index>s) OK/ERROR/+CME ERROR	
Write command AT^SDBR=<index1> [,<number typ>]	Parameter: <index> Parameter <number typ>	Location number stored in the alphabetically-sorted addressbook Response [^SDBR: <number typ>, <number>, <typ>, <text>[[...] <CR><LF>^SDBR: <number typ>, <number>, <typ>, <text>]] OK/ERROR/+CME ERROR	Number type
	<nummer> <typ> <text>	0 phone number 'HOME' 1 phone number 'OFFICE' 2 phone number 'MOBILE' 3 phone number 'FAX'	Telephone number
			Type of number
			Text corresponding to the telephone number <text> depends on AT+CSCS.
	Note:	In the <text> field, special characters like the following may appear: `" (0x22), `@` (0x00), `ò` (0x08), `Ö` (0x5c). (See also AT+CPBW and Appendix A: "Using special characters in certain commands (e. g., +CPBR/+CPBW)")	

2.4.2.8 AT^SDLD

AT^SDLD		Delete the "last number redial" memory	
Test command AT^SDLD=?		Response OK	
Execute command AT^SDLD		Response OK/ERROR/+CME ERROR	

2.4.2.9 AT^SGAUTH

AT^SGAUTH	Select Type of Authentication for PPP connection
Test command AT^SGAUTH=?	Response ^SGAUTH: (list of supported <auth>s) OK/ERROR/+CME ERROR Parameter <auth> indicates typ of supported authentication 0 none 1 PAP 2 CHAP 3 PAP and CHAP
Read command AT^SGAUTH?	Response +CGACT: <auth> OK/ERROR/+CME ERROR Parameter <auth> See Test command
Write command AT^SGAUTH =<auth>	Response OK/ERROR/+CME ERROR Parameter <auth> See Test command

2.4.2.10 AT^SICO

AT^SICO	Icon control
Test command AT^SICO =?	Response ^SICO: (list of supported <n>s),(list of supported <m>s) OK
Write command AT^SICO =<n>,<m>	Response for <m> = 0 and 1 OK/ERROR/+CME ERROR Response for <m> = 2 ^SICO: <s> OK Parameter <n> Type of icon 0 GPS icon 1 hide icon 2 show icon 3 query icon status <s> Status 0 icon hidden 1 icon shown

2.4.2.11 AT^SLCK

AT^SLCK	Switch locks (including user-defined locks) on and off
Test command AT^SLCK=?	Response ^SLCK: (list of supported <fac>s) OK/ERROR/+CME ERROR Parameter <fac> <ul style="list-style-type: none"> PS Phone locked to SIM (device code) SC SIM card (PIN) FD FDN lock AO BAOB (bar all outgoing calls) OI BOIC (bar outgoing international calls) OX BOIC-exHC (bar outgoing international calls except to home country) AI BAIC (bar all incoming calls) IR BIC-Roam (bar incoming calls when roaming outside the home country) AB All barring services AG All outgoing barring services AC All incoming barring services PN Network personalization (GSM 02.22, [6]) PC Corporate personalization (GSM 02.22, [6]) PU Network subset personalization (GSM 02.22, [6]) PP Service provider personalization (GSM 02.22, [6]) PF Phone locked to very first inserted SIM
Write command AT^SLCK = <fac>, <mode> [, <passwd> [, <class>]]	Parameter <fac> See Test command <mode> <ul style="list-style-type: none"> 0 Cancels lock 1 Activates lock 2 Queries lock status <passwd> Password <class> <ul style="list-style-type: none"> 1 Voice 2 Data 4 Fax 7 Voice, Data and FAX (default) 8 SMS 16 data circuit sync 32 data circuit async 64 dedicated packet access 128 dedicated PAD access X combination of some of the above classes, e.g. 255 regroups all classes and 5 regroups Voice and FAX

(Continued next page)

Cont.	<p>Response If <mode>=2 and command is successful ^SLCK: <status>[,<class1>[<CR><LF> ^SLCK: <status>, class2....]] OK/ERROR/+CME ERROR Parameter <status> 0 Off 1 On</p>
-------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

2.4.2.12 AT^SLNG

AT^SLNG	Language settings
Test command AT^SLNG=?	<p>Response ^SLNG: (list of supported languages <lng>s) Parameter: <lng> Integer; language coded according to GSM 03.38 or mobile-specific language (>100)</p>
Read command AT^SLNG?	<p>Response ^SLNG: <lng></p>
Write command AT^SLNG=<lng>	<p>Response OK/ERROR/+CME ERROR</p>

2.4.2.13 AT^SMGL

AT^SMGL	List SMS (without status change from <i>unread</i> to <i>read</i>) Revision according to GSM 07.05 Version 4.7.0															
Test command AT^SMGL=?	<p>Response ^SMGL: (list of supported <stat>s) Parameter <stat></p> <table border="0"> <tr> <td style="padding-right: 20px;">0</td> <td>REC UNREAD</td> <td>received unread messages (default)</td> </tr> <tr> <td>1</td> <td>REC READ</td> <td>received read messages</td> </tr> <tr> <td>2</td> <td>STO UNSENT</td> <td>stored unsend messages</td> </tr> <tr> <td>3</td> <td>STO SENT</td> <td>stored send messages</td> </tr> <tr> <td>4</td> <td>ALL</td> <td>all messages</td> </tr> </table>	0	REC UNREAD	received unread messages (default)	1	REC READ	received read messages	2	STO UNSENT	stored unsend messages	3	STO SENT	stored send messages	4	ALL	all messages
0	REC UNREAD	received unread messages (default)														
1	REC READ	received read messages														
2	STO UNSENT	stored unsend messages														
3	STO SENT	stored send messages														
4	ALL	all messages														
Write command AT^SMGL [=<stat>]	<p>Response If PDU mode (+CMGF=0) and command is successful: ^SMGL: <index>, <stat>,[<alpha>],<length> <CR><LF><pdu> [<CR><LF>^SMGL: <index>, <stat>,[<alpha>],<length> <CR><LF><pdu> [...]] Parameter <stat> See Test command <pdu> The PDU begins with the service-center address (according to GSM 04.11), followed by the TPDU according to GSM 03.40 in hexadecimal format otherwise: +CMS ERROR: <err></p>															

2.4.2.14 AT^SMGO

AT^SMGO	SMS overflow indicator
Test command AT^SMGO=?	Response ^SMGO: (list of supported <n>s) OK/ERROR/+CMS ERROR Parameter <n> 0 Disable 1 Enable
Read command AT^SMGO?	Response ^SMGO: <n>,<mode> OK/ERROR/+CMS ERROR Parameter <n> See Test command <mode> 0 Space still available 1 SMS storage full (The "SM" and "ME" storages are full, that is to say "MT" storage is full. See AT+CPMS command.) 2 A message is waiting into Message Service Centre(MSC) in network for delivery to phone (e.g., a message Class 2 waiting and "SM" storage full or a message waiting and every storage full)
Write command AT^SMGO=<n>	Parameter <n> See Test command <mode> See Test command Response OK/ERROR/+CMS ERROR Unsolicited message ^SMGO: <mode>
Notes	1) Indication during data transfer via break (100ms). 2) Incoming short messages with message class 2 (refer <dcs> GSM 03.38) will be stored in "SM" storage only. Therefore, AT^SMGO: 2 indication can occur without a preceding AT^SMGO: 1 indication.

2.4.2.15 AT^SMGR

AT^SMGR	Read SMS (without status change from <i>unread</i> to <i>read</i>) Syntax identical with AT+CMGR
Test command AT^SMGR=?	Response OK
Write command AT^SMGR=<index>	Response If PDU mode (+CMGF=0) and command are successful: AT^SMGR:<stat>,[<alpha>],<length><CR><LF><pdu> Parameter <pdu> See the AT+CMGL command <stat> See the AT+CMGL command <length> See the AT+CMGL command otherwise: +CMS ERROR: <err> <index> Index of message in selected memory <mem1>

2.4.2.16 AT^SMSO

AT^SMSO	Switch device off	
Test command AT^SMSO=?	Response OK	
Execute command AT^SMSO	Response OK	Device switches off

2.4.2.17 AT^SVMC

AT^SVMC	Voice Memo Contol	
Test command AT^SVMC =?	Response ^SVMC: (list of <actions>s),<number>,<time>,<nlength> +CME ERROR: <err>	
	Parameter:	
<action>	integer type value; the following values are defined:	
0	stop recording and save the Voice Memo, or stop playback of Voice Memo	
1	cancel recording without saving current file	
2	start recording; no index is needed - if an index is specified, an error is issued. If a name is specified, it will be associated with the current Voice Memo; otherwise, the <datetime>oparameter is used as name. <nlength> gives the max. length for the name of a Voice Memo.	
	Examples:	
	AT^SVMC=2	start record, Voice Memo is named with default name "date_time"
	AT^SVMC=2,,"My_Memo"	start record named 'My_Memo'
3	start playback of voice memo selected with <index>, from start of file if no time is given. If a time (<start>) is given then the playback starts a position <start> in seconds from the beginning of the file. This could also be used to have a fast forward or rewind. The parameter <name> is not needed and if it is available an error is issued	
4	query information for voice memo with <index>, if no index is given then an error is issued	
5	delete voice memo with <index>, if no index is given then all voice memos are being deleted	
<number>	integer type value indicating the number of available Voice Memos, if no Voice Memo is available this value is '0'	
<time>	string of format "hh:mm:ss", indicating hour (hh), minutes (mm) and seconds (ss)	
<nlength>	integer type value indicating the maximum length of field <name>	
Write command ^SVMC=<action>[,<index>[,<name>]][,<start>]]	Response ^SVMC: <action>,<index>,<name>,<date_time> +CME ERROR: <err>	
	Parameter:	
<action>	see Test command	
<index>	0 .. 254 integer type value; which represents a certain voice memo sorted in a chronological order (starting with '0', max. '254')	

	<p><name> string representing the name of the file; used character set should be the one selected with Select TE Character Set AT+CSCS</p> <p><start> integer indicating the time in seconds from the beginning of a voice memo (not supported at the moment)</p>																
	<p><date_time> -47...+48</p> <p>string of format yyyy-MM-dd,hh:mm:ss[±zz] indicating year, month, day, hour, minutes, seconds and, optionally, time zone (indicates the difference between the local time and GMT, expressed in quarters of an hour)</p> <p>E.g. 6th of May 1994, 22:10:00 GMT+2 hours stands for "94/05/06,22:10:00+08"</p>																
Read command ^SVMC?	<p>^SVMC: <type>,<time> +CME ERROR: <err></p> <p><type> integer indicating the type of action being performed for a voiced memo; the following values are defined</p> <p>0 Idle 1 recording of voice memo 2 playback of voice memo</p> <p><time> see Test command</p>																
Execute command ^SVMC	<p>^SVMC: <type>,<time> +CME ERROR: <err></p>																
Unsolicited result code:	<table border="1"> <tr> <td><int></td> <td></td> </tr> <tr> <td>0</td> <td>Normal Stop</td> </tr> <tr> <td>1</td> <td>Memory failure (e.g. MMC removed)</td> </tr> <tr> <td>2</td> <td>Memory full</td> </tr> <tr> <td>3</td> <td>Incoming call</td> </tr> <tr> <td>4</td> <td>Warning: 5 seconds remaining for recording</td> </tr> <tr> <td>5 – 254</td> <td>not defined (for later use)</td> </tr> <tr> <td>255</td> <td>Unknown event</td> </tr> </table>	<int>		0	Normal Stop	1	Memory failure (e.g. MMC removed)	2	Memory full	3	Incoming call	4	Warning: 5 seconds remaining for recording	5 – 254	not defined (for later use)	255	Unknown event
<int>																	
0	Normal Stop																
1	Memory failure (e.g. MMC removed)																
2	Memory full																
3	Incoming call																
4	Warning: 5 seconds remaining for recording																
5 – 254	not defined (for later use)																
255	Unknown event																
Description:	<p>The Test command returns a list of possible actions, a list of available indexes of Voice Memos, the remaining recording time and maximum length for the name of a Voice Memo.</p> <p>The Write command is used to control the Voice Memo functionality of the mobile. The action parameter lets you start, stop, pause, or cancel a Voice Memo playback. Also, this command can be used to start, stop, cancel and pause the recording of a Voice Memo.</p> <p>The Read command indicates whether a playback or recording is running (type), the remaining time (recording time or playback time) and the name (if available) of the current Voice Memo.</p> <p>The Execute command controls the pausing of playback and recording. Each time this command is executed there is a change between playback/record and pause.</p>																

2.4.2.18 AT^SNFS

AT^SNFS	Select NF hardware
Test command AT^SNFS=?	Response ^SNFS: (list of supported <dev>s) Parameter <dev> 0 Cell phone mode 1 Handsfree
Read command AT^SNFS?	Response ^SNFS: <dev> Parameter <dev> See Test command Note: Volume should be temporarily set to "0" before NF hardware is changed.
Write command AT^SNFS=<dev>	Parameter <dev> See Test command Response OK/ERROR

2.4.2.19 AT^SNFV

AT^SNFV	Set the volume
Test command AT^SNFV=?	Response ^SNFV: (list of supported <vol>s) Parameter <vol> Value range of volume (0 to 4) 0 Low volume 1 2 3 4 max. volume (approx. 3 dB/level)
Read command AT^SNFV?	Response ^SNFV: <vol> Parameter <vol> See Test command
Write command AT^SNFV=<vol>	Parameter <vol> See Test command Response OK/ERROR

2.4.2.20 AT^SPBC

AT^SPBC	Seek the first entry in the sorted telephone book which begins with the selected (or next available) letter
Test command AT^SPBC=?	Response ^SPBC: (list of sorted telephone books supported <mem>s) See AT+CPBS / AT^SPBS OK/ERROR/+CME ERROR
Write command AT^SPBC=<char>	Parameter <char> First letter of desired entry Value range: letters A to Z (capitals only) (if <char> is not A to Z, the index of the first entry beginning with a special character is displayed) <index> Index in the sorted telephone book (access via AT^SPBG) Response ^SPBC: <index> OK/ERROR/+CME ERROR

2.4.2.21 AT^SPBG

AT^SPBG	Read entry from the sorted telephone book via the sorted index
Test command AT^SPBG=?	Response ^SPBG: (list of supported <index>s), <nlength>, <tlength> OK/ERROR/+CME ERROR: Parameter <index> Location number <nlength> Max. length of telephone number <tlength> Max. length of the text corresponding to the number
Write command AT^SPBG= <index1> [, <index2>]	Response ^SPBG:<index1>,<number>,<type>,<text>[<CR><CL> ^SPBG: ^SPBG:<index2>,<number>,<type>,<text>] OK/ERROR/+CME ERROR Parameter <index1> Location number where the read of the entry starts <index2> Location number where the read of the entry ends <number> Telephone number <type> Type of number <text> Text corresponding to the telephone number

2.4.2.22 AT^SPBS

AT^SPBS	Select a telephone book (including Siemens-specific books)
Test command AT^SPBS=?	Response ^SPBS: (list of supported <sto>s) OK/ERROR/+CME ERROR Parameter <sto> <ul style="list-style-type: none"> FD SIM fix-dialing telephone book SM SIM telephone book ME Telephone book in device DC ME Dialed Calls List ON Own telephone numbers LD SIM last dialing number MC ME Missed Calls List RC ME Received Calls List MD Last number redial memory in telephone device OW Own numbers BD Barred dialing numbers SD Service dialing numbers MS Missed dialing numbers (unanswered calls) CD Callback dialing numbers (answered calls) BL Blacklist dialing numbers (barred numbers from remote) MB Mailbox dialing numbers (network-operator mailbox) CS Common sortable telephone book (sorted combination of "SM", "ME", "FD"; access only via ^SPBC, ^SPBG) RD Red book (all entries in "CS" whose name portions have an exclamation mark (!) as their final character) *For detailed information on the telephone-book features see "Appendix A"
Read command AT^SPBS?	Response ^SPBS: <sto>>[,<used>,<total>] OK/ERROR/+CME ERROR Parameter <sto> See Test command <used> integer type value indicating the number of used locations in selected memory <total> integer type value indicating the total number of locations in selected memory
Write command AT^SPBS=<sto>	Parameter <sto> See Test command Response OK/ERROR/+CME ERROR

2.4.2.23 AT^SPIC

AT^SPIC	Output PIN counter
Test command AT^SPIC=?	Response OK/ERROR/+CME ERROR
Execute command AT^SPIC	Response ^SPIC: <counter> OK/ERROR/+CME ERROR Parameter <counter> Number of attempts still available to enter the <passwd>. Use the AT+CPIN? command to check which password is being required.

2.4.2.24 AT^SPLM

AT^SPLM	Read the PLMN list
Test command AT^SPLM=?	Response OK
Execute command AT^SPLM	Response ^SPLM: numeric <oper>, long alphanumeric <oper><CR><LF> ^SPLM:..... OK/ERROR/+CME ERROR Parameter <oper> Network operator in numeric and alphanumeric notation

2.4.2.25 AT^SPLR

AT^SPLR	Read an entry from the preferred-operator list
Test command AT^SPLR=?	Response ^SPLR: (list of supported <index>s) OK/ERROR/+CME ERROR Parameter <index> Location numbers
Write command AT^SPLR=<index1> [, <index2>]	Response ^SPLR: <index1>, numeric <oper> ^SPLR: ^SPLR: <index2>, numeric <oper> OK/ERROR/+CME ERROR Parameter <index1> Location number where the read of the entry starts <index2> Location number where the read of the entry ends <oper> Network operator in numeric form

2.4.2.26 AT^SPLW

AT^SPLW	Write an entry to the preferred-operator list
Test command AT^SPLW=?	Response ^SPLW: (list of supported <index>s) OK/ERROR/+CME ERROR Parameter <index> Location number Parameter <index> Location number at which the entry is written
Write command AT^SPLW=<index>[, <oper>]	<oper> Network operator in numeric form
	Response OK/ERROR/+CME ERROR

2.4.2.27 AT^SPST

AT^SPST	Play Signal Tone
Test command AT^SPST=?	Response ^SPST: (list of supported <n>s) OK
Write command AT^SPST =<n>,<m>	Response OK/ERROR/+CME ERROR
	Parameter
	<n>
	0 Type of Signal Tone (st = self terminating)
	1 Carkit PTT (st)
	2 Carkit PTT long (st)
	3 Carkit Crash (st)
	4 Carkit Error (st)
	5 Carkit Call Setup (st)
	<m>
	0 Mode
	1 Stop tone (not necessary for self terminating tones)
	2 Play tone

2.4.2.28 AT^SPWD

AT^SPWD	Change password to a lock (including user-defined locks)
Test command AT^SPWD=?	Response ^SPWD: list of supported (<fac>, <pwdlength>)s OK/ERROR/+CME ERROR
	Parameter
	<fac>
	P2 PIN2
	PS Phone locked to SIM (device code)
	SC SIM card (PIN)
	AO BAOC (bar all outgoing calls)
	OI BOIC (bar outgoing international calls)
	OX BOIC-exHC (bar outgoing international calls except to home country)
	AI BAIC (bar all incoming calls)
	IR BIC-Roam (bar incoming calls when roaming outside the home country)
	AB All barring services
	AG All outgoing barring services
	AC All incoming barring services
	PN Network personalization (GSM 02.22, [6])
	PC Corporate personalization (GSM 02.22, [6])
	PU Network subset personalization (GSM 02.22, [6])
	PP Service provider personalization (GSM 02.22, [6])
	PF Phone locked to very first inserted SIM
	<pwdlength> Length of password
Write command AT^SPWD = <fac>,<oldpwd>, <newpwd>	
	Parameter
	<fac> See Test command
	<oldpwd> Old password
	<newpwd> New password
	Response OK/ERROR/+CME ERROR

2.4.2.29 AT^SSET (Profile Settings Control)

AT^SSET Profile Settings Control (SET Melody and Picture settings in Mobile)	
<p>Test command AT^ SSET =?</p>	<p>Response ^SSET:((list of <actions>), <applicationX>,(list of <keys>)),..., ((list of <actions>),<applicationY>,(list of <keys>)) OK</p> <p>Parameter: <action> integer type value; the following values are defined: 0 Delete 1 Set 2 Get</p> <p><application> integer type value; the following values are defined: 1 MMI Settings (Melody and Picture Settings)</p> <p><keys> integer type value indicating the feature related, e.g. incoming sms ringer melody, background picture.</p>
<p>Write command ^SSET=<action>[,<application>[,<key>[,<fullname>]]]</p>	<p>Response to Write and Delete Action OK/ERROR/+CME ERROR: <err></p> <p>Response to Read Action with application and key parameters [^SSET: <applicationX>,<keyY>,<fullname><CR><LF>] OK/ERROR/+CME ERROR: <err></p> <p>Response to Read Action with application parameter but without key parameter [[^SSET: <applicationX>,<key1>,<fullname><CR><LF>][...] [^SSET: <applicationX>,<keyN>,<fullname><CR><LF>]] OK/ERROR/+CME ERROR: <err></p> <p>Response to Read Action without application and key parameters [[^SSET: <applicationX>,<key1>,<fullname><CR><LF>][...] [^SSET: <applicationX>,<keyN>,<fullname><CR><LF>][...] [^SSET: <applicationY>,<key1>,<fullname><CR><LF>][...] [^SSET: <applicationY>,<keyM>,<fullname><CR><LF>]] OK/ERROR/+CME ERROR: <err></p> <p>Parameter: <action> see Test command <application> see Test command <key> see Test command <fullname> String type parameter which contains the name of the file with extension</p>
<p>Description:</p>	<p>The Test command returns a list of possible applications with its available actions and keys.</p> <p>The Write command is used to set, get or delete settings of the mobile. The action parameter lets you set, get or delete settings.</p> <p>Delete Action If no parameters are provided, every setting will be deleted. If no key parameter is entered then all settings of this application are deleted Otherwise just the setting corresponding to the key will be deleted.</p> <p>Set Action All parameters are mandatory.</p> <p>Get Action Optional application and key parameters If no key parameter is entered then all settings of this application are get Otherwise just the setting corresponding to the key will be get.</p>

Example Note:	<p>The <fullname> parameter should be given according to the character setting defined in command AT+CSCS.</p> <p>Example: "A:\Sounds\jump.mid"</p> <p>In GSM character set, this string is different to ANSI character set (standard) and thus the Backslash character must be passed as two characters: the extension table character and a slash. The extension table character has value 1B and the following character "/" has value 2F.</p> <p>In UCS2 character set, there is no problem since "\" is defined as value 005C.</p> <p>Note: String case insensitive (Upper or Lower case)</p>
----------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

2.4.2.30 AT^SSOC

AT^SSOC		Sound Control (PLAY/STOP SOUND)
Test command AT^SSOC=?	Response OK/	
Write command AT^SSOC=<fullname>	Parameter <fullname>	string type parameter which contains the path and the filename with its extension
	Response OK/ERROR/+CME ERROR	
Execute command AT^SSOC	Response Stops the current Melody OK/ERROR/+CME ERROR	
Example Note:	<p>Note: AT+CRMP and AT^SSOC can not be used simultaneously. If an MTC arrives while the test ring is active, the latter is switched off and the "normal" ring is switched on. The <fullname> parameter should be given according to the character setting defined in command AT+CSCS.</p> <p>Example: "A:\Sounds\jump.mid"</p> <p>In GSM character set, this string is different to ANSI character set (standard) and thus the Backslash character must be passed as two characters: the extension table character and a slash. The extension table character has value 1B and the following character "/" has value 2F.</p> <p>In UCS2 character set, there is no problem since "\" is defined as value 005C.</p> <p>Note: String case insensitive (Upper or Lower case)</p>	

2.4.2.31 AT^SSTK

AT^SSTK	SIM Toolkit
Test command AT^SSTK=?	Response ^SSTK: <profile>
	Parameter: <profile> ME profile according to GSM 11.14
Write command AT^SSTK=<length>[,<mode>]<CR> PDU is given: <ctrl-Z/ESC>	Response: OK/ERROR/+CME ERROR Parameter: <length> Length of PDU in bytes <mode> 0 Single command 1 Sequence of commands, SIM Toolkit commands <pdu> see GSM 11.14 Restriction: The maximum PDU length is 176 bytes. Unsolicited message ^SSTK:<data>

2.4.3 Summary of all unsolicited messages

Unsolicited result codes indicate that processing of actions currently running is aborted due to an unforeseen event. Table 2-10 lists all unsolicited messages defined, together with their meaning:

Message	Meaning
+CBM: <length><CR><LF><pdu>	Direct output of the broadcast message. For an explanation of parameters see the AT+CNMI command
+CBMI:<mem>,<index>	Indicates that a new CB message has been received: For an explanation of parameters see AT+CNMI
+CCWA:<num>,<type>,<class>,<cli validity>	Call waiting indication For an explanation of parameters see AT+CCWA
+CDS: <length><CR><LF><pdu>	Direct output of the status report For an explanation of parameters see AT+CNMI
+CDSI: <mem>,<index>	???
+CGEV: ME CLASS <class>	The mobile equipment has forced a change of MS class For an explanation of parameters see AT+CGEREP
+CGEV: ME DEACT <PDP_type>, <PDP_addr>	The mobile equipment has forced a context deactivation For an explanation of parameters see AT+CGEREP
+CGEV: ME DETACH	The mobile equipment has forced a GPRS detach For an explanation of parameters see AT+CGEREP
+CGEV: NW CLASS <class>	The network has forced a change of MS class For an explanation of parameters see AT+CGEREP
+CGEV: NW DEACT <PDP_type>, <PDP_addr>	The network has forced context deactivation For an explanation of parameters see AT+CGEREP
+CGEV: NW DETACH	The network has forced a GPRS detach For an explanation of parameters see AT+CGEREP
+CGEV: NW REACT <PDP_type>, <PDP_addr>	The network has requested a context reactivation For an explanation of parameters see AT+CGEREP
+CGEV: REJECT <PDP_type>, <PDP_addr>	A network request for PDP context activation occurred when the MT was unable to report it and was automatically rejected For an explanation of parameters see AT+CGEREP
+CGREG: <stat>	GPRS Network registration For an explanation of parameters see AT+CGREG
+CIEV: <ind>, <value>	Indicator event reporting

+CKEV: <key>,<press>	
+CLIP: <num>,<type>,,,<CLI validity>	Telephone number of caller For an explanation of parameters see AT+CLIP
+CMT: <length><CR><LF<>pdu>	Direct output of the short message For an explanation of parameters see AT+CNMI
+CMTI: <mem>,<index>	Indication that a new message has arrived For an explanation of parameters see AT+CNMI
+COLP: <num>,<type>	Telephone number of called line For an explanation of parameters see AT+COLP
+CREG: <stat>	Network registration For an explanation of parameters see AT+CREG
+CSSI: <code1> +CSSU: <code2>	Supplementary service intermediate/unsolicited result code For an explanation of parameters see AT+CSSN
^SACM: <m>	Message indicating if ACM has reached the maximum value ACMmax For an explanation of parameters see AT^SACM
^SCKS: <m>	Message indicating whether card has been removed or inserted For an explanation of parameters see AT^SCKS
^SMGO: <mode>	SMS overflow indicator For an explanation of parameters see AT^SMGO
^SSTK:<data>	The user has selected a menu entry from a menu created by means of AT^SSTK
^SVMC:<int>	For an explanation of parameters see AT^SVMC
+VGS: <gain>	Speaker Volume indication used in Headset and Handsfree(Carkit) Bluetooth Profile For an explanation of parameters see AT+VGS

Table 2-10: List of unexpected messages

2.5 Appendix A

2.5.1 Factory settings made by AT&F

ATE1 (only in case of RCCP mode)

ATQ0

ATV1

AT+CCWA=0

AT+CREG=0

AT+CLIP=0

AT+COLP=0

AT+CRC=0

AT+CAOC=0

AT+CMEE=0

AT+CPBS=SM (if available)

AT+COPS=0

AT+VTS=1

AT+CSCS="GSM"

AT+CSSN=0,0

AT^SCKS=0

Reset pending locks (Phone Pin/Puk, Pin2/Puk2 ...)

which are given as answer to AT+CPIN?

AT+CSMS=0

AT+CNMI=0,0,0,0,1

AT^SMGO=0

AT+CSCB=0

2.5.2 Features of the Telephone book memory

Table 2-11 lists the features supported by the telephone book memory.

Name	Description	Category	Access	Write allowed ?	How to delete completely
FD	Fix-dialing number (SIM fix-dialing telephone book)	GSM 07.07	AT+CPBS or AT^SPBS	PIN2 required	
SM	Abbreviate dialing number (SIM telephone book)	GSM 07.07	AT+CPBS or AT^SPBS	device code required if FDN replacement is active	
DC (MD)	Mobile last dialing number (last number redial memory; only if "LD" is not available)	GSM 07.07	AT+CPBS or AT^SPBS	-	AT^SDLD
ON (OW)	Own Numbers (SIM own telephone numbers)	GSM 07.07 (Siemens)	AT+CPBS (historical)	x	
LD	SIM last dialing number (last number redial memory on SIM)	GSM 07.07	AT+CPBS or AT^SPBS	-	AT^SDLD
ME	Mobile-equipment telephone book (ME dialing numbers)	GSM 07.07	AT+CPBS or AT^SPBS	device code required if FDN replacement is active	
BD	Barred dialing numbers (blocked numbers)	Siemens	AT^SPBS	-	
SD	Service dialing numbers (Service numbers)	Siemens	AT^SPBS	-	
MC (MS)	Missed dialing numbers (unanswered calls)	GSM 07.07 (Siemens)	AT+CPBS, AT^SPBS	-	
RC (CD)	Callback dialing numbers (answered calls)	GSM 07.07 (Siemens)	AT+CPBS, AT^SPBS	-	
BL	Blacklist of dialing numbers (numbers that are blocked for a certain time in order to prevent continuous accesses from remote control)	Siemens	AT^SPBS	-	
MB	Mailbox dialing numbers (network-operator mailbox)	Siemens	AT^SPBS	-	
CS	Common sortable numbers (sorted combination of SM, ME, FD)	Siemens	AT^SPBS, AT^SPBC, AT^SPBG	-	
RD	Red book numbers (CS entries with ! at the end of the name portion)	Siemens	AT^SPBS, AT^SPBC, AT^SPBG	-	

Table 2-11: Features of the telephone book memory

2.5.3 Writing to the FDN Phonebook / FDN Replacement

Writing to the fixed-dialing number phonebook is protected by PIN2. A sample Write sequence (to e.g. record 5) is provided below:

AT Command	Comment
AT+CMEE=2 OK	Activate expanded error message
AT+CPBS=? +CPBS: ("FD","SM","LD") OK	Listing of available telephone books
AT+CPBS="FD" OK	Selection of the FDN telephone book
AT+CPBW=5,"1234",,"test" +CME ERROR: SIM PIN2 REQUIRED	A Write to record 5 is attempted PIN2 is required for this purpose
AT+CPIN? +CPIN: SIM PIN2 AT+CPIN="12345678" OK	Query of the PIN status PIN2 is to be entered Input of PIN2
AT+CPBW=5,"1234",,"test" OK	A Write to record 5 is attempted... PIN2 remains active as long as you use the commands AT+CPIN, AT+CPBS, AT+CPBR, AT+CPBW, AT+CACM, AT+CAMM, AT+CPUC or AT^SPIC, AT^SPBS, AT^SPBC, AT^SPBG,;
	If you use other commands or if none of the above commands are executed within five minutes, PIN2 is no longer valid.
AT+CPBW=6,"5678",,"new test" OK	A Write to record 6 is attempted...

In addition, if there is no FDN phonebook available on the SIM, it is possible to activate a feature which activates an FDN-like behavior for the "SM" and "ME" phonebooks (FDN replacement). (Currently this feature can only be activated via the MMI lock/device lock/excluding telephone book.) In this case, the Write to the "SM" and "ME" phonebooks is ensured by the device code (PH-SIM PIN and PH-SIM PUK, respectively). The sequence for entering the device code is analogous to the above example.

2.5.4 Using special characters in certain commands (e. g., +CPBR/+CPBW)

String parameters like <text> in certain commands (like, for instance, AT+CPBW) should be entered using quotation marks "" (Ascii=Windows=GSM=0x22), since the following problems may occur if the quotation marks are left out:

- SPACES (Space, Blank, Ascii=Windows=GSM=0x20) are skipped.
 E.g. at+cpbw=1,"123",,K. H. results in "K.H." ☹
 at+cpbw=1,"123",,K. H. spaces are retained ☺
- Commas (',') (Ascii=Windows=GSM=0x2C) and semicolons (;)(Ascii=Windows=GSM=0x3B) are prohibited and must not be used in <text>, because they are used as separators between parameters and commands.
 E.g. at+cpbw=1,"123",,Kurz,Helmut results in ERROR ☹
 at+cpbw=1,"123",,"Kurz,Helmut" ☺

To be able, however, to enter quotation marks (and some other special characters) in string parameters you will have to use the Escape character (hex value 0x5c). While "0x5c" denotes the backslash (\) in the ASCII character set (Ascii=Windows=0x5C), in the GSM character set "0x5C" denotes the ` character.

The escape sequence thus has the following structure:

- The sequence begins with the escape character 0x5C (ASCII=Windows=`, GSM=`)
- The special character follows and is entered as a 2 Byte representation of the GSM character set value .
 e.g. the 2 Byte representation of the ` (@) (GSM=0x00) is `00`

Table 2-12 lists the special characters that should be entered using the escape sequence:

GSM Char	GSM hex value	ASCII char.	3 byte esc. seq.(hex)	Note
`	0x5C	\	0x5C 0x35 0x43	Backslash
"	0x22	"	0x5C 0x32 0x32	String delimiter
ò	0x08	BSP	0x5C 0x30 0x38	Backspace
@	0x00	NULL	0x5C 0x30 0x30	GSM NULL

Table 2-12: Using escape characters in commands

Examples of using escape characters in GSM commands are listed in Table 2-13:

Desired phonebook entry	<text> in AT+CPBW command (hex)
Ölhändler	0x22 0x5C 0x35 0x43 0x6C 0x68 0x7B 0x6E 0x64 0x6C 0x65 0x72 0x22
"Eddi" Kurz	0x22 0x5C 0x32 0x32 0x45 0x64 0x64 0x69 0x5C 0x32 0x32 0x20 0x4B 0x75 0x72 0x7A 0x22
Oòo	0x22 0x4F 0x5C 0x30 0x38 0x6F 0x22
@Adr.	0x22 0x5C 0x30 0x30 0x41 0x64 0x72 0x2E 0x22 [no problems with strlen()] 22 00 41 64 72 2E 22 (may cause problems with strlen() in application)

Table 2-13: Using escape characters in GSM commands

Note:

When reading phonebook records, there is NO replacement. Every character will appear in normal GSM character set notation (like the left column in the example above).

2.6 S Registers

This section provides the meanings of S registers used in the modem:

S Register	Function (default values in bold type)		
S 0	The number of rings before the call is answered default: 0 (i. e. does not answer)		
S 3	Command termination character and first character of response trailer (CR)		
S 4	Second character of response trailer (LF)		
S 5	Editing character; erases the previous character (BS)		
S 6	Escape character		
S 7	Wait for carrier after dialing (in seconds). default: 60		
S 8 + S 9	No action		
S 10	Delay between Lost Carrier and Hang up in 0.1 sec. (Default 2 = 200ms)		
S 11 .. S17	No action		
S 18	Bit 0	0	No GSM exit cause
		1	With GSM exit cause
	Bit 1	0	No SMS indication "+C"
		1	With incoming SMS indication "+C"
S 19 ... S99	No action		

Table 2-14: S-Registers

Only the following S registers can be modified by means of the corresponding ATSn=x command (where n denotes the number of the register): S0, S3, S5, S6, S7, S8, S10; S18.

All the other S registers are used internally and thus read-only.

The contents of a single S register can be displayed via the ATSn? command (where n denotes the number of the register). It is not possible to have the contents of multiple registers displayed at the same time.

2.7 Circuit assignments

The following circuits are assigned at the mobile connector to support the exchange of data:

Name:	Direction	Function	ITU V24 Circuit
SG		Signal Ground	102
TxD	DTE to DCE	Transmitted Data	103
RxD	DCE to DTE	Received Data	104
CTS	DCE to DTE	Clear To Send	106
DCD	DCE to DTE	Data Carrier Detect	109

2.8 Appendix B

2.8.1 Example for creating / retrieving an organizer entry

-vcs object which has to be uploaded:

```
BEGIN:VCALENDAR
VERSION:1.0
BEGIN:VEVENT
CATEGORIES:ANNIVERSARY
DTSTART:19991213T100000
DESCRIPTION:W. von Siemens
END:VEVENT
END:VCALENDAR
```

-hexadecimal representation of this object:

```
424547494E3A5643414C454E4441520D0A56455253494F4E3A312E300D0A424547494E3A564556
454E540D0A43415445474F524945533A414E4E49564552534152590D0A445453544152543A31393
93931323133543130303030300D0A4445534352495054494F4E3A572E20766F6E205369656D656E
730D0A454E443A564556454E540D0A454E443A5643414C454E4441520D0A
```

-upload of an entry on record 20

```
at^sbnw="vcs",20,1,3<CR>
<CR><LF> > <Space>
424547494E3A5643414C454E4441520D0A56455253494F4E3A312E300D0A424547494E3A564556
454E540D0A43415445474F<Ctrl-Z>
<CR><LF>OK<CR><LF>
```

```
at^sbnw="vcs",20,2,3<CR>
<CR><LF> > <Space>
524945533A414E4E49564552534152590D0A445453544152543A3139393931323133543130303030
300D0A44455343524950<Ctrl-Z>
<CR><LF>OK<CR><LF>
```

```
at^sbnw="vcs",20,3,3<CR>
<CR><LF> > <Space>
54494F4E3A572E20766F6E205369656D656E730D0A454E443A564556454E540D0A454E443A5643
414C454E4441520D0A<Ctrl-Z>
<CR><LF>OK<CR><LF>
```

All characters are answered with an echo. Echoing can be switched off via „ATE0“.
In this example the organizer entry is uploaded in 50 bytes packets (100 input characters in every PDU).

Characters in blue characterize the responses of the mobile.

-interrogation of the current <type>,<subtype>,<actNumber>,<maxNumber>

```
at^sbnw?<CR>
<CR><LF>^SBNW: "vcs",20,2,3<CR><LF>
<CR><LF>OK<CR><LF>
```

description: The current object which is uploaded is an VCS object.
It has to be stored on record 20.
2 of 3 packets have already been uploaded.

-deleting of record 20

```
at^sbnw="vcs",20,0<CR>
<CR><LF>OK<CR><LF>
```

-download entry from record 20

```
at^sbnr="vcs",20<CR>
<CR><LF>^SBNR:<space>"vcs",20,1,1<CR><LF>
424547494E3A5643414C454E4441520D0A56455253494F4E3A312E300D0A424547494E3A564556
454E540D0A43415445474F524945533A414E4E49564552534152590D0A445453544152543A31393
93931323133543130303030300D0A4445534352495054494F4E3A572E20766F6E205369656D656E
730D0A454E443A564556454E540D0A454E443A5643414C454E4441520D0A<CR><LF>
<CR><LF>OK<CR><LF>
```

The mobile divides the record entry into packets of 176 byte (=176*2 characters).

-Download of an empty record 20

```
at^sbnr="vcs",20<CR>
<CR><LF>OK<CR><LF>
```

-Test command of AT^SBNW

```
at^sbnw=?<CR>
<CR><LF>^SBNW:<space>("bmp",(0)),(,"mid",(0)),(,"vcs",(1-30)) <CR><LF>
<CR><LF>OK<CR><LF>
```

description: The mobile supports bitmaps of subtype 0, midi objects of subtype 0 and vcs objects of the subtypes 1 to 30.

2.8.2 Examples and hints for using GPRS commands

2.8.2.1 Defining and using a Context Definition Id (CID):

Every time a CID is used as a parameter for a GPRS command the CID has to be defined first via the AT+CGDCONT command.

To retrieve the parameter of a CID the AT+CGDCONT read option must be used.

If the response of AT+CGDCONT? is OK only, no CID is defined.

```
AT+CGDCONT?  
OK // no CID defined
```

All parameters of the CID are initiated by NULL or non-existing values, and the CID itself is set to undefined. To define a CID use the AT+CGDCONT command with at least one CID parameter. The present version of the mobile software supports CID 1 and CID 2 by using the AT+CGDCONT command.

e.g.

```
AT+CGDCONT=1,IP  
OK // defines CID 1 and sets the PDP type to IP  
// access point name and IP address aren't set
```

```
AT+CGDCONT=2,IP, "internet.t-d1.gprs", 111.222.123.234  
OK // defines CID 2 and sets PDP type, APN and IP addr
```

A subsequent read command will return

```
AT+CGDCONT?  
+CGDCONT:1,IP  
+CGDCONT:2,IP," internet.t-d1.gprs",111.222.123.234  
OK
```

```
AT+CGDCONT=1  
OK // sets the CID 1 to be undefined
```

A subsequent read command will return

```
AT+CGDCONT?  
+CGDCONT:2,IP, "internet.t-d1.gprs",111.222.123.234  
OK
```

2.8.2.2 Defining Quality of service for a CID

Quality of Service (QoS) is a special parameter of a CID which again consists of several parameters. The QoS consists of

- the precedence class
- the delay class
- the reliability class
- the peak throughput class
- the mean throughput class

and is subdivided into "requested QoS" and "minimum acceptable QoS".

All parameters of the QoS are initiated by default to the "network subscribed value (= 0)", but the QoS itself is set to undefined. Use the AT+CGQREQ or AT+CGQMIN command to define a QoS.

e.g.:

```
AT+CGQREQ=1,2
OK           // overwrites the precedence class of QoS of CID 1 and sets
             // the QoS of CID 1 to be present
```

A following read command will response

```
AT+CGQREQ?
+CGQREQ: 1,2,0,0,0,0
OK           // all QoS values of CID 1 are set to network subscribed
             // except precedence class which is set to 2
```

```
AT+CGQREQ=1
OK           // set the QoS of CID 1 to not present
```

After defining a CID it could be activated. To activate a CID use

```
AT+CGACT=1,2
OK           // activate CID 2
```

If the CID is already active, the mobile immediately returns OK.

If no CID is given, all CIDs defined will be activated by means of

```
AT+CGACT= // NO CID and NO STATE given
OK         // all defined CIDs will be activated
```

If no CID is defined the mobile returns ++CME ERROR: invalid index

Remark: If the mobile is NOT attached via AT+CGATT=1 before activating, the attach is automatically done by means of the AT+CGACTcommand.

After a CID has been defined and activated, it can be used using AT commands as in the following example:

```
AT+CGDATA=PPP,1
CONNECT           // the mobile is connected using the parameters of CID 1
```

```
AT+CDATA=
CONNECT           // the mobile is connected using default parameter
```

The mobile supports Layer 2 Protocol (L2P) PPP only.

Remark: If the mobile is NOT attached by means of AT+CGATT=1 and if the CID is NOT activated before connecting, the attach and activate is automatically done by means of the AT+CGDATA command.

2.8.3 The GPRS dial command ATD

As an alternative to using the GPRS-AT commands it is possible to connect to a GPRS network by using the dial command "atD".

There are two GPRS Service Codes for the ATD command. Values 98 and 99.

e. g.:

```
ATD*99#  
CONNECT          // establish a connection via service code 99
```

```
ATD*99*123.124.125.126*PPP*1#  
CONNECT          // establish a connection via service code 99, IP address 123...  
                //and L2P = PPP and using CID 1.  
                // The CID has to be defined by means of AT+CGDCONT
```

```
ATD*99**PPP#  
CONNECT          // establish a connection via service code 99 and L2P = PPP
```

```
ATD*99***1#  
CONNECT          // establish a connection via service code 99 and using CID 1
```

```
ATD*99*PPP*1#  
CONNECT          // establish a connection via service code 99 and L2P = PPP and  
                // using CID 1. The CID has to be defined by means of AT+CGDCONT
```

```
ATD*98#  
CONNECT          // establish an IP connection via service code 98
```

```
ATD*98*1#  
CONNECT          // establish an IP connection via service code 98 using CID 1  
                // The CID has to be defined by means of AT+CGDCONT
```

2.8.4 The AT^SVMC command

In this section examples for the use of the AT^SVMC command are provided:

2.8.4.1 Test command

The Test command returns a list of possible actions, a list of available indexes of Voice Memos, the remaining recording time and maximum length for the name of a Voice Memo.

Sample input plus output:

```
AT^SVMC=?  
^SVMC: (0-5),14,132,"00:04:15"
```

Meaning:

- All actions (0-5) are possible,
- Currently there are 14 voice memos
- The maximum length for a voice memo name in this example is 132 bytes

- The remaining recording time is 4 minutes and 15 seconds

2.8.4.2 Write-command

The Write command is used to control the Voice Memo functionality of the mobile. The action parameter lets you start, stop, pause, or cancel the playback of a voice memo. Also, this command can be used to start, stop, cancel and pause the recording of a voice memo.

Sample input and resulting output:

```
AT^SVMC=0
^SVMC: OK
```

Meaning:

The recording of a voice memo has been stopped, saving the file, or the playing of the voice memo has been stopped. No error occurred.

```
AT^SVMC=2
^SVMC: OK
```

Meaning:

The recording of a voice memo has been started, the time and date of the recording is taken as voice memo name

```
AT^SVMC=2,, "my_memo"
^SVMC: OK
```

Meaning:

The recording of a voice memo has been started, the voice memo name is "my_memo".

```
AT^SVMC=2,14, "my_memo"
^SVMC: ERROR
```

Meaning:

An attempt was made to start recording a voice memo by the name of "my_memo", specifying the index at which the voice memo is to be stored. Since the index of a voice memo cannot be set (only queried or played back), an error is returned.

```
AT^SVMC=3,14, "my_memo"
^SVMC: OK
```

Meaning:

A voice memo by the name of "my_memo", stored with the index 14 is to be played back.

```
AT^SVMC=4,2
^SVMC: 2, "2002-02-22,22:22:22", "00:01:00", ["My_Memo"] OK
```

Meaning:

A query was started for a voice memo defined by index 2, and the query result is returned, including the index specified, the length of the recorded memo (date and time information; 22:22:22 amounts to one minute) and the name by which it is stored.

```
AT^SVMC=5
```

Meaning:

All voice memos stored are to be deleted.

AT^SVMC=5,2

Meaning:

The voice memo stored with the index 2 is to be deleted.

2.8.4.3 Read command

The Read command indicates whether a playback or recording is running (type), the remaining time (recording time or playback time) and the name (if available) of the current Voice Memo.

Sample input and resulting output:

AT^SVMC?

^SVMC: 0

Meaning:

Currently no action is performed for a voice memo, the value of <type> is "Idle".

AT^SVMC?

^SVMC: 1,"00:10:00"

Meaning:

A voice memo is being recorded, with 10 minutes' record time remaining

AT^SVMC?

^SVMC: 2,"00:00:30"

Meaning:

A voice memo is being played back, with 30 seconds remaining

2.8.4.4 Execute command

The Execute command controls the pausing of playback and recording. Each time this command is executed there is a change between playback/record and pause.

Pause a recording or playback depending on the current running action. The following table shows the possible response for the execution command:

State of VM-AL	Command Response	Meaning	Next State
Recording	^SVMC: 0,"00:00:30" OK	30s are recorded	'Pause Recording'
Pause Recording	OK	recording continued	'Recording'
Playing	^SVMC: 1,"00:00:40" OK	40s are played	'Pause Playing'
Pause Playing	OK	playback continued	'Playing'
Other states	ERROR (+CME ERROR: operation temporarily not		

	allowed)		
--	----------	--	--

3 Errors and Messages

This section provides information on the final result code of a command execution (+CMS ERROR: <err>) and indicates an error related to mobile equipment or network.

3.1 Summary of CME ERRORS (+CME ERROR) related to GSM 07.07

Table 3-1 lists the numbers and meaning of CME errors (+CMS ERROR: <err>) related to GSM 07.07.

Note: Values smaller than 256 are reserved.

Code of <err>	Meaning
0	phone failure
1	no connection to phone
2	phone-adapter link reserved
3	Operation not allowed
4	Operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	SIM not inserted
11	SIM PIN required
12	SIM PUK required
13	SIM failure
14	SIM busy
15	SIM wrong
16	Incorrect password
17	SIM PIN2 required
18	SIM PUK2 required
20	Memory full
21	invalid index
22	not found
23	Memory failure
24	text string too long
25	invalid characters in text string
26	dial string too long
27	invalid characters in dial string
30	no network service
31	Network timeout
32	Network not allowed emergency calls only
40	Network personalization PIN required
41	Network personalization PUK required
42	Network subset personalization PIN required
43	Network subset personalization PUK required
44	service provider personalization PIN required
45	service provider personalization PUK required
46	Corporate personalization PIN required
47	Corporate personalization PUK required
100	Unknown
103	Illegal MS (#3) (Values in parentheses are GSM 04.08 cause codes.)
106	Illegal ME (#6)

107	GPRS services not allowed (#7)
111	PLMN not allowed (#11)
112	Location area not allowed (#12)
113	Roaming not allowed in this location area (#13)
132	service option not supported (#32)
133	requested service option not subscribed (#33)
134	service option temporarily out of order (#34)
148	unspecified GPRS error
149	PDP authentication failure
256	Operation temporarily not allowed
257	call barred
258	phone is busy
259	user abort
260	invalid dial string
261	ss not executed
262	SIM blocked

Table 3-1: CME ERRORS related to GSM 07.07

3.2 Summary of CMS ERRORS (+CMS ERROR) related to GSM 07.05

Table 3-2 lists the numbers and meaning of CMS errors related to GSM 07.05:

<err> code	Meaning
1	Unassigned (unallocated) number
8	Operator determined barring
10	Call barred
21	Short message transfer rejected
27	Destination out of service
28	Unidentified subscriber
29	Facility rejected
30	Unknown subscriber
38	Network out of order
41	Temporary failure
42	Congestion
47	Resources unavailable, unspecified
50	Requested facility not subscribed
69	Requested facility not implemented
81	Invalid short message transfer reference value
95	Invalid message, unspecified
96	Invalid mandatory information
97	Message type non-existent or not implemented
98	Message not compatible with short message protocol state
99	Information element non-existent or not implemented
111	Protocol error, unspecified
127	Interworking, unspecified
128	Telematic interworking not supported
129	Short message Type 0 not supported
130	Cannot replace short message
143	Unspecified TP-PID error
144	Data coding scheme (alphabet) not supported
145	Message class not supported
159	Unspecified TP-DCS error
160	Command cannot be executed
161	Command unsupported

175	Unspecified TP-Command error
176	TPDU not supported
192	SC busy
193	No SC subscription
194	SC system failure
195	Invalid SME address
196	Destination SME barred
197	SM Rejected-Duplicate SM
198	TP-VPF not supported
199	TP-VP not supported
208	D0 SIM SMS storage full
209	No SMS storage capability in SIM
210	Error in MS
211	Memory Capacity Exceeded
212	SIM Application Toolkit Busy
213	SIM data download error
255	Unspecified error cause
300	ME failure
301	SMS service of ME reserved
302	Operation not allowed
303	Operation not supported
304	Invalid PDU mode parameter
305	Invalid text mode parameter
310	SIM not inserted
311	SIM PIN required
312	PH-SIM PIN required
313	SIM failure
314	SIM busy
315	SIM wrong
316	SIM PUK required
317	SIM PIN2 required
318	SIM PUK2 required
320	Memory failure
321	Invalid memory index
322	Memory full
330	SMSC address unknown
331	no network service
332	Network timeout
340	NO +CNMA ACK EXPECTED
500	Unknown error
512	User abort

Table 3-2: CMS ERRORS related to GSM 07.05

3.3 GPRS return values issued by AT+CEER

Table 3-3 lists the GPRS return values issued by the AT+CEER command in the form <x>.<y>, where x indicates the type of the value returned and y denotes the reason why the call was terminated.

Table 3-3 provides the values for the applications handled by AT+CEER (x values). For more detailed information on meaning of the y values see tables Table 3-4 through Table 3-9:

Value	Meaning
48	GMM_LOC_GSM (see section 3.3.1)
50	SM_LOC_GSM (see section 3.3.2)
51	SM_LOC_OWN (see section 3.3.3)
241	GAPI_LOC_OWN (see section 3.3.4)
242	LMAN_LOC_OWN (see section 3.3.5)
243	ENIP_LOC_OWN (see section 3.3.6)

Table 3-3 GPRS return values

3.3.1 GMM-GSM return values issued by AT+CEER (GMM_LOC_GSM)

Value	Meaning
2	IMSI is unknown in HLR
3	MS is illegal
6	ME is illegal
7	GPRS services not allowed
8	GPRS services not allowed in combination with non-GPRS services
9	MS cannot be identified
10	Implicit detachment
11	PLMN not allowed
12	Location area not allowed
13	Roaming not allowed in current location area
14	GPRS services not allowed in current PLMN
16	MSC temporarily unreachable
17	Network failure
22	Congestion
48 – 63	Retry upon entry into new cell low – high
95	Message semantically incorrect
96	Mandatory information invalid
97	Message type does not exist or is not implemented
98	Message type incompatible with protocol state
99	Information element does not exist or is not implemented
100	Conditional error
101	Message incompatible with protocol state
111	Unspecified protocol error

Table 3-4: GMM return values issued by AT+CEER

3.3.2 SM-GSM return values issued by AT+CEER (SM_LOC_GSM)

Value	Meaning
25	LLC or SNDCP failure
26	Insufficient resources
27	Missing or unknown APN
28	PDP address or type unknown
29	User authentication failed
30	Activation rejected by GGSN
31	Activation rejected for unspecified reason
32	Service option not supported
33	Requested service option not subscribed
34	Service option temporarily out of order
35	NSAPI already used
36	Regular deactivation
37	QoS not accepted
38	Network failure
39	Reactivation required
81	Invalid transaction identifier value
95	Message semantically incorrect
96	Mandatory information invalid
97	Message type does not exist or is not implemented
98	Message type incompatible with protocol state
99	Information element does not exist or is not implemented
100	Conditional IE error
101	Message incompatible with protocol state
111	Unspecified protocol error

Table 3-5: GMM return values issued by AT+CEER

3.3.3 SM_OWN return values issued by AT+CEER (SM_LOC_OWN)

Value	Meaning
3	T3380 timer expired
4	DeactAct
5	DeactActReject
6	DeactActStaticPDPaddressCollision
7	Unspecified protocol error

Table 3-6: GAPI return values issued by AT+CEER

3.3.4 GAPI return values issued by AT+CEER (GAPI_LOC_OWN)

Value	Meaning
0	Regular deactivation of the call
1	Action temporarily not allowed
2	Wrong connection type
3	Specified data service profile invalid
4	PDP type or address is unknown
255	Undefined

Table 3-7: GAPI return values issued by AT+CEER

3.3.5 LMAN return values issued by AT+CEER (LMAN_LOC_OWN)

Value	Meaning
0	Regular call deactivation
1	Action temporarily not allowed
2	Bearer invalid
3	Specified data service profile invalid
4	GPRS profile invalid
5	CSD profile invalid
17	Modem in use
18	Modem not responding
19	Modem error
20	Timeout while waiting for modem
21	Modem nocarrier
22	Modem no dialtone
23	Modem busy
24	Modem dial timeout
25	Modem call lost
255	Undefined

Table 3-8: LMAN return values issued by AT+CEER

3.3.6 ENIP return values issued by AT+CEER (ENIP_LOC_OWN)

Value	Meaning
0	Regular call deactivation
1	LCP stopped
255	Undefined

Table 3-9: ENIP return values issued by AT+CEER

3.4 List of keys implemented for AT+CKPD

The following keys are implemented for the AT+CKPD command:

Character	IRA (dec)	Comment
#	35	Hash (number sign)
%	37	Percent sign
*	42	asterisk
0..9	48 .. 57	number keys
:	58	Colon; escape character for manufacturer specific keys
<	60	Left arrow
>	62	Right arrow
C/c	67 / 99	clear display (C/CLR)
E/e	69 / 101	connection end (END)
S/s	83 / 115	connection start (SEND)
V/v	86 / 118	Down arrow
W/w	87 / 119	pause character
Y/y	89 / 121	delete last character (C)
[91	soft key 1
]	93	soft key 2
^	94	Up arrow
Siemens specific keys		
+		left side key up
-		left side key down
M		right side key

3.5 List of Commands related to CSCS / UCS2

The following commands relate to the AT+CSCS command and UCS2:

- AT+CNUM
- AT+CPBR
- AT+CPBW
- AT+CPUC
- AT^SDBR
- AT^SSET
- AT^SSOC
- AT^SVMC

3.6 Result codes

Table 3-10 lists the numbers of result codes and provides their meaning:

Indication	Numeric	Meaning
OK	0	Command executed, no errors, Wake up after reset
CONNECT	1	Link established
RING	2	Ring detected
NO CARRIER	3	Link not established or disconnected
ERROR	4	Invalid command or command line too long
NO DIALTONE	6	No dial tone, dialling impossible, wrong mode
BUSY	7	Remote station busy
CONNECT 2400	10	Link with 2400 bps
CONNECT 4800	30	Link with 4800 bps
CONNECT 9600	32	Link with 9600 bps
CONNECT 14400	33	Link with 14400 bps
CONNECT 2400/RLP	47	Link with 2400 bps and Radio Link Protocol
CONNECT 4800/RLP	48	Link with 4800 bps and Radio Link Protocol
CONNECT 9600/RLP	49	Link with 9600 bps and Radio Link Protocol
CONNECT 14400/RLP	50	Link with 14400 bps and Radio Link Protocol

Table 3-10: Result codes

3.7 List of *# codes

The commands listed in Table 3-11 can be used with ATD (only for voice calls):

*# code	Functionality	Possible response(s)
*#06#	Query IMEI:	<IMEI> / OK
**04[2]*oldPin*newPin[2]*newPin[2]#	Change SIM pwd:	+CME ERROR/ OK
**05[2]*unblKey*newPin[2]*newPin[2]#	Change/Unblocking SIM pwd:	OK
[]03[*ZZ]*oldPw*newPw*newPw#	Registration of network password:	
*#30#	Interrogation CLIP	AT+CLIP / OK
*#31#	Interrogation CLIR	AT+CLIR : <n>,<m> OK
*#76#	Interrogation COLP	AT+COLP : 0,<m> OK
*#77#	Interrogation COLR (Connection line interpretation restriction)	+COLR : 0,<m> OK
(choice of *,#,*,#,**,##)21*DN*BS#	Act/deact/int/reg/eras CFU	AT+CCFC
(choice of *,#,*,#,**,##)67*DN*BS#	Act/deact/int/reg/eras CF busy	
(choice of *,#,*,#,**,##)61*DN*BS*T#	Act/deact/int/reg/eras CF no reply	
(choice of *,#,*,#,**,##)62*DN*BS#	Act/deact/int/reg/eras CF no reach	
(choice of *,#,*,#,**,##)002*DN*BS*T#	Act/deact/int/reg/eras CF all	
(choice of *,#,*,#,**,##)004*DN*BS*T#	Act/deact/int/reg/eras CF all cond.	
(choice of *,#,*,#)43*BS#	Activation/deactivation/int WAIT	AT+CCWA
(choice of *,#,*,#)33*Pw*BS#	Act/deact/int BAOC	AT+CLCK
(choice of *,#,*,#)331*Pw*BS#	Act/deact/int BAOIC	
(choice of *,#,*,#)332*Pw*BS#	Act/deact/int BAOIC exc.home	
(choice of *,#,*,#)35*Pw*BS#	Act/deact/int. BAIC	
(choice of *,#,*,#)351*Pw*BS#	Act/deact/int BAIC roaming	
#330*Pw*BS#	Deact. All Barring Services	
#333*Pw*BS#	Deact. All Outg.Barring Services	
#353*Pw*BS#	Deactivation. All Inc.Barring Services	

Table 3-11: List of *# codes

The abbreviations used in Table 3-11 have the following meaning:

ZZ	type of supplementary services	330	Barring services
ZZ		----	All services
DN	dialling number	0-9	string of digits
BS	basic service:Voice	11	Voice
		16	Sms
		13	Fax
		12	Sms+fax
		19	Voice+fax
		10	Voice+sms+fax
		25	Data circuit asynchron
		24	Data circuit synchron
		27	PAD
		26	packet
		21	data circuit async.+PAD
		22	data circuit sync.+packet
		20	data circ.Async+sync.+PAD+ packet
		----	all services
T	time in seconds		
Pw	network password		