TSic™

Precision Temperature Sensor IC

Technical Notes – ZACwire™ Digital Output

IST TSic™ Temperature Sensor IC

Technical Notes – ZACwire™ Digital Output

CONTENTS

TSic™

Precision Temperature Sensor IC

Technical Notes – ZACwire™ Digital Output

1 ZACwire™ Communication Protocol for the TSic™

ZACwire™ is a single wire bi-directional communication protocol. The bit encoding is similar to Manchester in that clocking information is embedded into the signal (falling edges of the signal happen at regular periods). This allows the protocol to be largely insensitive to baud rate differences between the two ICs communicating. In end-user applications, the TSic™ will be transmitting temperature information and another IC in the system (most likely a µController) will be reading the temperature data over the ZACwire™.

1.1 Temperature Transmission Packet from a TSic™

The TSic™ transmits 1-byte packets. These packets consist of a start bit, 8 data bits, and a parity bit. The nominal baud rate is 8kHz (125µsec bit window). The signal is normally high. When a transmission occurs, the start bit occurs first followed by the data bits (MSB first, LSB last). The packet ends with an even parity bit.



Figure 1.1 – ZACwire™ Transmission Packet

The TSic™ provides temperature data with 11-bit resolution,[1] which cannot be conveyed in a single packet. A complete temperature transmission from the TSic™ consists of two packets. The first packet contains the most significant 3 bits of temperature information, and the second packet contains the least significant 8 bits of temperature information. There is a single bit window of high signal (stop bit) between the end of the first transmission and the start of the second transmission.



Figure 1.2 – Full ZACwire™ Temperature Transmission from TSic™ (5 MSBs are Zero-Padded)

[1] Contact ZMD for possible customization for higher temperature resolution.

1.2 Bit Encoding

The bit format is duty cycle encoded:

Start bit => 50% duty cycle used to set up strobe time

Logic 1 => 75% duty cycle

Logic 0 => 25% duty cycle

Stop Bit
For the time of a half a bit width, the signal level is high. There is a half stop bit time between bytes in a packet.



Figure 1.3 – Manchester Duty Cycle

An oscilloscope trace of a ZACwire™ transmission demonstrates the bit encoding. The following shows a single packet of 96Hex being transmitted. Because 96Hex is already even parity, the parity bit is zero.



Figure 1.4 – ZACwire™ Transmission

1.3 How to Read a Packet

When the falling edge of the start bit occurs, measure the time until the rising edge of the start bit. This time (Tstrobe) is the strobe time. When the next falling edge occurs, wait for a time period equal to Tstrobe, and then sample the ZACwire™ signal. The data present on the signal at this time is the bit being transmitted. Because every bit starts with a falling edge, the sampling window is reset with every bit transmission. This means errors will not accrue for bits downstream from the start bit, as it would with a protocol such as RS232. It is recommended, however, that the sampling rate of the ZACwire™ signal when acquiring the start bit be at least 16x the nominal baud rate. Because the nominal baud rate is 8kHz, a minimum 128kHz sampling rate is recommended when acquiring Tstrobe.

1.4 How to Read a Packet using a µController

It is best to connect the ZACwire™ signal to a pin on the µController that is capable of causing an interrupt on a falling edge. When the falling edge of the start bit occurs, it causes the µController to branch to its ISR. The ISR enters a counting loop incrementing a memory location (Tstrobe) until it sees a rise on the ZACwire™ signal. When Tstrobe has been acquired, the ISR can simply wait for the next 9 falling edges (8 for data, 1 for parity). After each falling edge, it waits for Tstrobe to expire and then samples the next bit.

The ZACwire™ line is driven by a strong CMOS push/pull driver. The parity bit is intended for use when the ZACwire™ is driving long (>2m) interconnects to the µController in a noisy environment. For systems in environments without noise interference, the user can choose to have the µController ignore the parity bit.

Appendix A of this document gives an example of code for reading a TSic™ ZACwire™ transmission using a PIC16F627 µController.

1.4.1 How Often Does the TSic™ Transmit?

If the TSic™ is being read via an ISR, how often is it interrupting the µController with data? The update rate of the TSic™ is programmed to 10Hz (0.1ms response time). Servicing a temperature-read ISR requires about 2.7ms. Therefore the µController spends about 2.7% of its time reading the temperature transmissions.

1.4.2 Solutions if a Real Time System Cannot Tolerate the TSic™ Interrupting the µController

Some real time systems cannot tolerate the TSic™ interrupting the µController. In this case, the µController must initiate the temperature read. This can be accomplished by using another pin of the µController to supply VDD to the TSic™. The TSic™ will transmit its first temperature reading approximately 65ms to 85ms after power up. When it is time for the µController to read the temperature, it first powers the TSic™ using one of its port pins. It will receive a temperature transmission approximately 65ms to 85ms later. If during that time, a higher priority interrupt occurs, the µController can simply power down the TSic™ to ensure it will not cause an interrupt or be in the middle of a transmission when the higher priority ISR finishes. This method of powering the TSic™ has the additional benefit of acting like a power down mode and reducing the quiescent current from a nominal 45µA to zero. The TSicTM is a mixed signal IC and provides best performance with a low-noise VDD supply. Powering through a µController pin does subject it to the digital noise present on the µController's power supply. Therefore it is best to use a simple RC filter when powering the TSic™ with a µController port pin. See the diagram below.



Figure 1.5 – RC Filter for Powering TSic™ through the µController

Appendix A: An Example of PIC1 Assembly Code for Reading the ZACwire™

In the following code example, it is assumed that the ZACwire™ pin is connected to the interrupt pin (PORTB, 0) of the PIC and that the interrupt is configured for falling edge interruption. This code should work for a PIC running between 3-20MHz.

```
TEMP_HIGH     EQU    0X24   ;; MEMORY LOCATION RESERVED FOR TEMP HIGH BYTE
TEMP_LOW      EQU    0X25   ;; MEMORY LOCATION RESERVED FOR TEMP LOW BYTE
                            ;; THIS BYTE MUST BE CONSECUTIVE FROM TEMP_HIGH
LAST_LOC      EQU    0X26   ;; THIS BYTE MUST BE CONSECUTIVE FROM TEMP_LOW
TSTROBE       EQU    0X26   ;; LOCATION TO STORE START BIT STROBE TIME.
ORG           0X004         ;; ISR LOCATION


;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
;; CODE TO SAVE ANY REQUIRED STATE AND TO DETERMINE THE SOURCE OF THE ISR ;;
;; GOES HERE.  WHEN THE SOURCE HAS BEEN DETERMINED, IF THE INTERRUPT WAS ;;
;; A ZAC WIRE TRANSMISSION THEN BRANCH TO ZAC_TX                    ;;
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
ZAC_TX:       MOVLW  TEMP_HIGH     ;; MOVE ADDRESS OF TEMP_HIGH (0X24) TO W REG
              MOVWF  FSR           ;; FSR = INDIRECT POINTER, NOW POINTING TO TEMP_HIGH
GET_TLOW:     MOVLW  0X02          ;; START TSTROBE COUNTER AT 02 TO ACCOUNT FOR
              MOVWF  TSTROBE       ;; OVERHEAD IN GETTING TO THIS POINT OF ISR
              CLRF   INDF          ;; CLEAR THE MEMORY LOCATION POINTED TO BY FSR
STRB:         INCF   TSTROBE,1     ;; INCREMENT TSTROBE
              BTFSC  STATUS,Z      ;; IF TSTROBE OVERFLOWED TO ZERO THEN
              GOTO   RTI           ;; SOMETHING WRONG AND RETURN FROM INTERRUPT
              BTFSS  PORTB,0       ;; LOOK FOR RISE ON ZAC WIRE
              GOTO   STRB          ;; IF RISE HAS NOT YET HAPPENED INCREMENT TSTROBE

              CLRF   BIT_CNT       ;; MEMORY LOCATION USED AS BIT COUNTER
BIT_LOOP:     CLRF   STRB_CNT      ;; MEMORY LOCATION USED AS STROBE COUNTER
              CLRF   TIME_OUT      ;; MEMORY LOCATION USED FOR EDGE TIME OUT
WAIT_FALL:    BTFSS  PORTB,0       ;; WAIT FOR FALL OF ZAC WIRE
              GOTO   PAUSE_STRB    ;; NEXT FALLING EDGE OCCURRED
              INCFSZ TIME_OUT,1    ;; CHECK IF EDGE TIME OUT COUNTER OVERFLOWED
              GOTO   RTI           ;; EDGE TIME OUT OCCURRED.
              GOTO   WAIT_FALL
```



```
PAUSE_STRB:  INCF   STRB_CNT,1    ;; INCREMENT THE STROBE COUNTER
             MOVF   TSTROBE,0     ;; MOVE TSTROBE TO W REG
             SUBWF  STRB_CNT,0    ;; COMPARE STRB_CNT TO TSTROBE
             BTFSS  STATUS,Z      ;; IF EQUAL THEN IT IS TIME TO STROBE
             GOTO   PAUSE_STRB    ;; ZAC WIRE FOR DATA, OTHERWISE KEEP COUNTING
                    ;; LENGTH OF THIS LOOP IS 6-STATES.  THIS MUST
                    ;; MATCH THE LENGTH OF THE LOOP THAT ACQUIRED TSTROBE
             BCF    STATUS,C      ;; CLEAR THE CARRY
             BTFSC  PORTB,0       ;; SAMPLE THE ZAC WIRE INPUT
             BSF    STATUS,C      ;; IF ZAC WIRE WAS HIGH THEN SET THE CARRY
             RLF    INDF,1        ;; ROTATE CARRY=ZAC WIRE INTO LSB OF REGISTER
                                  ;; THAT FSR CURRENTLY POINTS TO
             CLRF   TIME_OUT      ;; CLEAR THE EDGE TIMEOUT COUNTER
WAIT_RISE:   BTFSC  PORTB,0       ;; IF RISE HAS OCCURRED THEN DONE
             GOTO   NEXT_BIT
             INCFSZ TIME_OUT,1    ;; INCREMENT THE EDGE TIME OUT COUNTER
             GOTO   WAIT_RISE
             GOTO   RTI           ;; EDGE TIME OUT OCCURRED.

NEXT_BIT:    INCF   BIT_CNT,1     ;; INCREMENT BIT COUNTER
             MOVLW  0X08          ;; THERE ARE 8 BITS OF DATA
             SUBWF  BIT_CNT,0     ;; TEST IF BIT COUNTER AT LIMIT
             BTFSS  STATUS,Z      ;; IF NOT ZERO THEN GET NEXT BIT
             GOTO   BIT_LOOP

             CLRF   TIME_OUT      ;; CLEAR THE EDGE TIME OUT COUNTER
WAIT_PF:     BTFSS  PORTB,0       ;; WAIT FOR FALL OF PARITY
             GOTO   P_RISE
             INCFSZ TIME_OUT,1    ;; INCREMENT TIME_OUT COUNTER
             GOTO   WAIT_PF
             GOTO   RTI           ;; EDGE TIMEOUT OCCURRED

P_RISE:      CLRF   TIME_OUT      ;; CLEAR THE EDGE TIME OUT COUNTER
```



```
WAIT_PR:      BTFSC  PORTB,0       ;; WAIT FOR RISE OF PARITY
              GOTO   NEXT_BYTE
              INCFSZ TIME_OUT,1    ;; INCREMENT EDGE TIME OUT COUNTER
              GOTO   WAIT_PR
              GOTO   RTI           ;; EDGE TIME OUT OCCURRED



NEXT_BYTE:    INCF   FSR,1         ;; INCREMENT THE INDF POINTER
              MOVLW  LAST_LOC
              SUBWF  FSR,0         ;; COMPARE FSR TO LAST_LOC
              BTFSS  STATUS,Z      ;; IF EQUAL THEN DONE
              GOTO   WAIT_TLOW

              ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
              ;; IF HERE THEN DONE READING THE ZAC WIRE AND HAVE THE DATA ;;
              ;; IN TEMP_HIGH & TEMP_LOW                                   ;;
              ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;

WAIT_TLOW:    CLRF   TIME_OUT
WAIT_TLF:     BTFSS  PORTB,0       ; WAIT FOR FALL OF PORTB,0 INDICATING
              GOTO   GET_TLOW      ; START OF TEMP LOW BYTE
              INCFSZ TIME_OUT
              GOTO   WAIT_TLF
              GOTO   RTI           ; EDGE TIMEOUT OCCURRED

RTI:          ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
              ;; RESTORE ANY STATE SAVED AT BEGINNING OF ISR ;;
              ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
              BCF    INTCON,INTF   ;; CLEAR INTERRUPT FLAG
              BSF    INTCON,INTE   ;; ENSURE INTERRUPT RE-ENABLED
              RETFIE               ;; RETURN FROM INTERRUPT

              ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
```


Appendix B: An Example of 8051 C++ Code for Reading the ZACwire™

In the following code example, it is assumed that the ZACwire™ pin is connected to the PORT 0 pin (0x80hex) of the µController 8051. This code should work for the µController 8051 running between 8 to 24.5MHz. This program example does not use interrupts. Contact ZMD for additional examples using interrupts.

```
#define PWR_PIN                         0x40
#define SIG_PIN                         0x80
#define PORT                            P2

/*******************************************************************************
* FUNCTION MACROS
*******************************************************************************/
#define TSIC_INIT()             {       SFRPAGE = CONFIG_PAGE; PORT_CONFIG |= PWR_PIN; PORT
&= ~PWR_PIN; /* power */\
                PORT_CONFIG &= ~SIG_PIN; PORT |= SIG_PIN; /* signal */ }

#define TSIC_ON()                       SFRPAGE = CONFIG_PAGE; PORT |= PWR_PIN;
#define TSIC_OFF()                      SFRPAGE = CONFIG_PAGE; PORT &= ~PWR_PIN;
#define TSIC_SIGNAL()           (PORT & SIG_PIN)
/*******************************************************************************
* FUNCTION MACROS
*******************************************************************************/
// assuming MCU runs at (24.5 ÷ 8) MHz
// used as blocking wait function
#define WAIT_60_US()
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_(); \
_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();_nop_();
```



```
/******************************************************************************
* Function    : getTSicTemp
* Description : reads from the TSic its output value
* Parameters  : pointer for return value
* Returns     : read value
* Notes       : blocking function, assuming MCU runs at (24.5 ÷ 8) MHz
******************************************************************************/
UINT16 getTSicTemp (UINT16 *temp_value16)
{
        UINT16 temp_value1 = 0;
        UINT16 temp_value2 = 0;
        UINT8 i;
        UINT16 Temperature;
        UINT8 parity;

        TSIC_ON();
        WAIT_60_US();                   // wait for stabilization
        WAIT_60_US();

        SFRPAGE = CONFIG_PAGE;
        while (TSIC_SIGNAL());// wait until start bit starts

        // wait, TStrobe
        while (TSIC_SIGNAL() == 0x00);

        // first data byte
        // read 8 data bits and 1 parity bit
        for (i = 0; i < 9; i++)
        {
                while (TSIC_SIGNAL());                  // wait for falling edge
                WAIT_60_US();
                if (TSIC_SIGNAL())
                        temp_value1 |= 1 << (8-i);      // get the bit
                else
                        while (TSIC_SIGNAL() == 0x00);          // wait until line comes high again
        }

        // second byte
        while (TSIC_SIGNAL());
```



```
    // wait, TStrobe
    while (TSIC_SIGNAL() == 0x00);

    // read 8 data bits and 1 parity bit
    for (i = 0; i < 9; i++)
    {
        while (TSIC_SIGNAL());                  // wait for falling edge
        WAIT_60_US();
        if (TSIC_SIGNAL())
            temp_value2 |= 1 << (8-i);          // get the bit
        else
            while (TSIC_SIGNAL() == 0x00);              // wait until line comes high again
    }

    TSIC_OFF();                         // switch TSic off

    // check parity for byte 1
    parity = 0;
    for (i = 0; i < 9; i++)
        if (temp_value1 & (1 << i))
            parity++;
    if (parity % 2)
        return FALSE;

    // check parity for byte 2
    parity = 0;
    for (i = 0; i < 9; i++)
        if (temp_value2 & (1 << i))
            parity++;
    if (parity % 2)
        return FALSE;

    temp_value1 >>= 1;              // delete parity bit
    temp_value2 >>= 1;              // delete parity bit
    Temperature = (temp_value1 << 8) | temp_value2;
    *temp_value16 = Temperature;
    return TRUE;                    // parity is OK
}
```

```
/********************************************************************************
* Function    : cmdGetTSicValue
* Description : debug function
* Parameters  : none
* Returns     : none
* Notes       : none
********************************************************************************/
void cmdGetTSicValue (void)
{
        UINT16 temp_value;
        float Temp_float;

        printf("cmdGetTSicValue\n");
        TSIC_INIT();            // init the I/O pins used for the TSic
        TSIC_OFF();                     // switch the TSic off until use
        if (getTSicTemp(&temp_value))
        {
                Temp_float = ((float)temp_value / 2047 * 200) - 50;     // conversion equation from TSic's
data sheet
                SFRPAGE_UART();
                printf("temp %u, %2.1f\n", temp_value, Temp_float);
        }
}
```


For further information:

www.zmd.biz

ZMD America, Inc.
201 Old Country Road, Suite 204
Melville, NY 11747, USA
Tel: +01 (631) 549-2666
Fax: +01 (631) 549-2882
sales@zmda.com

ZMD AG
Grenzstrasse 28
01109 Dresden, Germany
Tel: +49 (0) 351.8822.366
Fax: +49 (0) 351.8822.337
sales@zmd.de

ZMD Far East
1F, No. 14, Lane 268
Sec. 1 Guangfu Rd.
Hsinchu City 300, Taiwan
Tel: +886 (0) 3.563.1388
Fax: +886 (0) 3.563.6385
sales@zmd.de

