

Announcing a new era in PCB layout

A PCB Design & layout suite of tools developed to meet the changing needs for PCB layout in the 21st century.

The first completely new, high level combined Schematics Capture & PCB layout product for many years, this exciting software tool has been developed from the ground up by PCB Design industry professionals using the very latest techniques in graphics and data handling.

Pulsonix has been designed based on key criteria:

- Easy to use by way of an intuitive user interface
- Designed for the casual user and the professional
- Imports design and library data from key EDA products

Easy to learn and logical to use

Pulsonix has been developed with an easy to understand user interface using Microsoft standards, look and feel.

The menu structure is logical and intuitive moving from left to right as you progress through your design process. The toolbars and keyboard keys are fully configurable so that at all times you have shortcut keys and tools to hand, making the design process more efficient.

Training needs kept to a minimum

A key principle in the design of Pulsonix was to create a product where the need for structured user training could be minimised. This has been implemented and you will find that you are productive with Pulsonix in a very short time. Pulsonix is delivered with an informative Users Guide and up to date, context sensitive on-line HTML help.

Designed with the future in mind

Pulsonix is built on the latest concepts in software design, hence it has many years of development life and expansion ahead.

With the need for constant growth of a product through customer feedback and market demands, Pulsonix is well positioned to grow with any technology or trends that are being developed, and even some that are years ahead!

The Auto – Interactive Design Environment



Directly Imports Schematics, PCB Designs, Libraries from:

OrCAD Capture/Orcad Layout PADS PowerPCB/Logic/PowerView Accel EDA Cadstar For Windows Protel 98/99SE P-CAD DOS/2000/2001/2002 UltiBoard and UltiCap Eagle EdWin Integra Visula CADIF PCB format

Schematics Electrical Rules Checking (ERC)

On-line and batch checking setup using a table of ERC rules in Technology Includes user definable rules.

User Definable ERC Rules

<undefined></undefined>
<undefined> {Block Port}</undefined>
Bi-Directional
Ground
Input
Input (Block Port)
Open Collector
Open Emitter
Or-Tieable
Output
Output (Block Port)
Passive
Power
Terminator
Tri-State

Name

XB Output

XB Bi-Directional

Or-Tieable

B Tri-State

B Terminator

Ground в

B Passive

Open Emitter

No Connect

XB Input

в

В Power

в

в

Pin types can be user defined then selected in the combonent library definition. Permutations of pin B Open Collector type connections may then be selected in the Electrical Rules Checker to determine Error or Warning situations when adding connections to the design.

Bi-Directional

nput (Block Port)

Jutput (Block Port

pen Collecto

pen Emitter

lutpul

assive

erminator

Tri-State

ower



You can easily zoom straight to an ERC error. In this case 'P' denotes a single pin net error on the output and 'Co' a connection error, as the connection between components is broken.

Auto Dim

This powerful option enables items which are not selected during editing to be 'dimmed' or low lighted so they become unobtrusive while editing the area of concern.

This is especially useful when editing large multi-layer designs, which can be very confusing due to the volume of items being presented in the design window at any one time



32 Bit Windows application supported on:

Windows® 2000 and XP

Easy to learn and use

Designed to be extremely easy to learn and use for both the casual user and PCB layout professional. New customers usually pick-up Pulsonix within a day or so of use.

Flat Sheet and Multi-level **Hierachical Design**

Pulsonix provides 'top down' design: breaking blocks into functional elements allowing you to define the detail of each element, and bottom-up' design: facilitating the re-use of commonly used circuit elements using pre-defined blocks to build a solution

Support For Net Class Rules

Net Class rules can be defined in the Schematic design and automatically passed through to the PCB design editor. This means rule definitions are set further forward in the design process.

Windows Drag & Drop

Easy, pick, drag and drop operation, no additional 'modes' to click or enter before being able to move items.

ERC/DRC Error Viewer

(L Errors X				
DRC errors: 64				
 Board to Text Error (B-X) 				
-Layer: 1-Top				
Between (-4954.0 -3250.0) and (-4954.0 -3215.0)				
🖲 Layer: 2-Ground				
Layer: 3-Power				
Layer: 4-Bottom				
E Component to Component Error (Cm-Cm)				
Pad to Pad Error (P-P)				
Pad to Track Error (P-T)				
Pad to Via Error (P-V)				
Track to Track Error (T-T)				
Track to Via Error (T-V)				

Where design rule errors are produced, a browser displays the errors by layer and type for easy identification. By selecting the marker from the list, the design area moves to the element in error.

Schematic Symbol Wizard

Takes you through creation of the symbol in a step-by-step sequence to easily produce regular symbols. The pin sizes, positions and numbering is selected to make symbol creation so simble and error free.

Workbook Mode

The Workbook tabs allow you to quickly identify open designs and libraries by name. Clicking on the tabs enables quick switching between any open window.

Status Bar

Gives you an instant Property status on any selected item in the design without the need to use a Query or Properties dialog.

Modal Cursors

With the modal cursor option on, you are given an indication of any available modes by a symbol appearing with the cursor. This provides you with instant feedback of the option available during key operations.

Import/Export DXF and IDF Data Formats

Import and Export of both DXF and IDF formats are available, this enables you to communicate intelligently with your mechanical CAD system.

Import Bitmap

Bitmap images may be imported into your designs. These may be your company logo or other bitmaps and symbols required to annotate the design. The design can also be exported to bitmap and WMF formats for documentation purposes.

Fully Customisable Toolbars and Shortcut keys

Using standard Windows technology, you may relocate icons from one toolbar to another. New icons with tools of your choice may be added to the toolbars. All existing shortcut keys may be changed and new ones added at will.

Intuitive Graphical User Interface

Pulsonix has an immediately familiar feel similar to that of your existing Office products. This means you'll be productive in a much shorter space of time.

Windows Style Interface

Similar to Microsoft Office applications, you immediately know where to find common Windows menu items.

Cross-Probing between the Schematic and PCB design editors

Instant selection of parts & connections in Schematics with the highlighting of corresponding tracks and footprints in PCB and vice-versa.



Component Push Mode

An outstanding feature of Pulsonix is the placement 'push' mode. This enables Component placement by 'pushing' other Components out of the way as it is dragged.

Design Variants

Using the Variant Manager, any number of variants may be defined at either the Schematic or the PCB design stage. If using the Schematic as the master, the variant information will be automatically transfered to the PCB design.

Part Creation Wizard

The Part Wizard is used to create all kinds of parts within Pulsonix. This useful tool takes you through the process of part creation step-by-step, thereby avoiding the potential for any errors and automating this process.

Reverse Engineer

Where a PCB design exists but the Schematic doesn't, use the Reverse Engineer feature to rebuild the Schematic. Using partbased symbols, the design can be rebuilt to the Component Bin ready for placement, or it can be fully placed and routed. This feature will save you many hours of work.

Single-Shot Postprocessing

Manufacturing output is simplicity itself with the latest in technology single-shot post design processing. Just set up the plotting parameters once and from then on it's a single click to broduce all your plots. Pulsonix produces professional results using standard manufacturing outputs.

Synchronise Designs

Provides an instant report of differences between the Schematic and PCB designs to check design integrity. Automatic updating to the PCB is run on completion of the operation. Component and Net renames are back annotated to the Schematic.

Integrated Automatic Placement

Initial automatic placement is driven through a single dialog with no previous set up required. Placement rules driven off this dialog make the option easy to use. Placement can be made to/from groups, around the board outline and using areas. Automatic Gate and Pin Swapping is available to assist placement and optimise the overall connection lengths.

Integrated Autorouter

Pulsonix is available with a fully integrated Auto Router using artificial intelligence and rip-up and retry techniques. A powerful product addition to enhance your PCB design system.



easure Results Pad IC16.93 on net PerData6 Width: 1.854 Height: 0.604 Layer: <Top Side Pad IC15.19 Width: 0.604 Height: 1.854 Layer: <Top Side Laver: <Top Side Distance Shortest Gap Dist: 10.262 ×: -9.299 Y: -4.340 Angle: 205.0 Spacing: 0.150 Units: mm Snap | Hide Report.

Measure Tool

An interactive option to measure the gap between any two design items. Select the first item, then a target item, the Measure tool dialog displays the distance between the two items. This is the real distance between the points as would be calculated through the DRC option and is measured against the closest point of each item selected. Other useful information about the selected items is also disblayed.

Footprint Wizard

The easy to use Footprint Wizard breaks down the process of creating a new footprint into a series of logical steps. It enables auto-production of DIP, SOIC, PGA, BGA, Quad and Radial devices using a clear graphical user interface.





In the knowledge that the layout engineer usually devotes a great deal of effort on interactive editing, Pulsonix has been designed to be a pleasure to use. Extensive use of context sensitive, right hand mouse menus gives you instant control on track types, styles, layers and grids.

Curved

Design Browser

Angled



Mitered

The design browser provides design management of all open designs and blocks.

World View

Gives a complete display of the view showing the area of zoom. This window can be used interactively with the mouse for precise zoom selection.

Component Preview

Displays selected components from the Component Bin to ensure selection errors are not made.

Component Bin

Provides a convenient 'off-design' location for Schematic and PCB Components during the design process.

Manufacturing output to ODB++ format

Pulsonix is a registered member of the Valour partner program and exports manufacturing data in ODB++ format. This is fast emerging as the defacto standard for PCB CAD manufacturing output and is accepted by most leading manufacturers.

Extensive Batch DRC

that all aspects of the design can be checked. This rule set includes spacing rules, on/off grid items, keep-in/out items. single pin nets, unconnected pins, plus manufacturability checks of the design.

Spacing	Cin Grid	Manufacturing	V Netz
Tsacks	🗹 Tsacks	Isolated Copper	Single Pin Netz
Vist Vist	Vias	Unpouned Templates	T Net Connectivity
Pads	🔽 Test Points	Unreachable Testpoints	Vininished Track
Vount Holes	Componento	Minimum Probe Points	Track Layer
Test Points	Pads	Split Plane Pad	Track Width
Copper		Plane Themail Pad	Via Size
Test 🖌	Keep In/Dut	Bond Wire Length	Tsack.Length
Board	P Tracks	Wee Close	Connection Length
🖓 Deilt:	Vist Vist	Wee Under Component	Connection Vias
Components	F Test Points	Drill Backolf	Pin Oxfer
Splk Planes	Components	Minimum Pad Land	P Differential Pairo
	Copper	F Pad Undersize	
	Dalla	Component Name	
	Se	slect <u>A</u> I Deselect AI	
Acceptance Rule	Set - Ente Make	a Dutrut	Source
	- Ose	Locked I Garante Bar	@ Design
Load		in Optiona Tid	C Salactor
		- Dated Dr	ules . Yourcool
Save	Clear Al	Enoro Not Diec	ked Churudan

Report Generation

As well as an extensive set of design reports supplied for use during the design process, a powerful user definable Report Maker option is also available. This highly configurable option allows you to output all entities of the design in your own customisable format.



Orthogonal

A graphical warning is given of the nearest point the track may be placed passing an unconnected bad.

If the track is placed closer to the obstacle the colour changes to red. showing a violation.

Free Angle

On-line Design Rule Checking

Real-time spacing rules checking with instant feedback of warnings before the error occurs. 'On-Line DRC' may be set to completely prevent errors occuring during the edit process.

Pulsonix Autorouter Features:



- Adaptive routing strategy
- Gridless routing up to 256 layers .
- Totally integrated into Pulsonix PCB
- Spacing rules by design/net class/net .
- Route using net class pair rules .
- Via rules by design/net class/net . Vias under SMD pads .
- 'No Via' routing control .
- SMD escape fanout control .
- Routes SMDs on both sides of the board
- Automatic breakout pattern usage
- Stub routing length control
- . Memory routing pass
- . Auto-mitre option
- . Support for blind/buried vias
- Full and split Plane/Ground Planes support
- User defined cost factors and routing rules
- Ability to lock critical pre-routing
- Post-route cleanup optimisation .
- Route by Net/Net Class .
- Route Selected Nets

Powerful Cost Options

- Spice based mixed mode A/D simulator .
- High Speed design option
- Chip Packaging Toolkit option
- PCB Thermal Analysis option
- Embedded Component option .
- Library/SAP/MRP integration toolkit option



Extensive design rules checking means

General Features

- 32 bit Windows application
- Ultra-fast bitmap graphics
- Supported under Windows 2000/XP
- Database resolution to 0.1 micron
- Object Oriented Architecture
- Connective data structure (not net-list driven)
- Rotation to 1/100th degree
- Standard interface for Schematic/PCB
- Integrated Schematic, PCB, Simulator, Autorouter
- Workbook Mode
- Component Bin with preview
- World View of design
- Design status bar
- Customisable Toolbars/Shortcuts
- Dockable and Floating Toolbars
- Technology files for fast start-up
- Comprehensive Parts library
- Integrated library editors
- Dynamic Pan, Zoom In/out
- Right mouse shortcut menus
- Drag and Drop methodology
- Intelligent copy, paste & duplicate
- Output to bitmap for documentation
- Update/edit parts on-the-fly
- Multi-level Undo and Redo
- Transient and Persistant Groups
- Full and flexible report generation
- Star or Delta point support for multiple signals
- Comprehensive item property reporting
- Modal cursors
- Powerful Measure tool
- Design assembly variants
- Support for Windows graphics driver library
- Support for Windows printers
- Import Schematic, PCB Design and library data from:

PADS PowerView/PowerPCB OrCAD Capture/Layout P-CAD 2000/2001/2004 Accel Cadstar For Windows Altium/Protel DXP, SE, SE99 UltiCAP/Ultiboard Eagle EdWin Integra

Visula CADIF (PCB only)

Schematic Capture

- Design in Imperial or Metric
- True connectivity during all operations
- Fully customisable interface
- Save and Load Technology files
- Symbol creation wizard
- Graphical symbol and Part editors
- Support for multi-gate logic and irregular devices, such as relays
- Save and Load Drawing profiles
- Uses common Parts libraries with PCB editor for smooth transition from SCM to PCB
- Flat sheet or Multi-level hierarchy

Single or multi-instance of the design block

Placement areas defined in Footprint

degree, Orthogonal and Curved

Integrated Auto Router (optional)

Keep In/Out areas on Autorouting

Testpoint support by side/type

Blind and buried via support

Dynamic Net Optimisation

User definable report writer

Automatic component rename

Radial, Angular dimensions

Single Shot Postprocessing

ODB++ Format exporter

Supports true split Power Planes

IPC 356 test format output

Output to GENCam format

Windows printer outputs

Plotting to HPGL plotters

manufacturing plots

Integrated LPKF Interface

Change Components on-the-fly

Automatic Gate and Pin Swapping

Support for Teardrops on pads and vias

Net Find, Highlight and select browser

Relative and Absolute coordinate system

Integrated Copper Pour with Hatching

Dimensioning with Horizontal, Vertical, Free,

Gerber Photo-plotter to RS-274-D and

Automatic generation of power plane plots

Excellon NC Drill output and drill drawings

Plotting of solder masks, resist and other

DXF Mechanical Design Input/Output

Import Schematic Netlists using: EDIF 2.0.0,

OrCAD, Viewdraw, EWB and other vendors

Chip-on-board (COB) design suite (optional)

Independently floating bond pads on components

Insulated and Cross-over rules for bond wires

Allows 'normal' components to be embedded

Contains additional inner layer build data.

Used for embedded and flexi-rigid designs.

resistors/capacitors, planar transformers and spiral

PSX190906

IDF Mechanical Design Input/Output

Links to external autorouters available

Library generator toolkit (optional)

Min/Max bond wire length rules

Design rules checking for COB rules

Report maker output of COB entities

Embedded Component Suite (optional):

Allows component types for printed

Recommended Hardware and O/S Pentium Processor 1.0 Ghz or faster

High Speed routing (optional)

Die and Bond pad support

Bond Wire support

Wire report output

onto inner layers.

inductors.

256MB Ram

Microsoft XP

Mouse with wheel

I80MB free space on disc

RS-274-X (extended aperture format)

Reverse Engineer, rebuild SCM design from PCB

Many Report outputs including Parts list & BOM

On-line Display Clearances

Design rule error browser

Manual Routing modes:

Single track Auto Router

Auto Corner, Auto Mitre

On-line and Batch Design Rules Checking (DRC)

Manual Routing angle modes Free angled, 45

- Save block to library
- Automatic security copy and backup of designs
- Intelligent Open and Closed Busses
- Reuse of designs using blocks or copy/paste
- Dynamic drag & drop move, rotate and mirror Parts or groups
- Dangle Component in mid-air and autoweld functions
- Item Align function
- Predefined and user defined attribute fields for custom title blocks and auto-updated detail
- Automatic/manual Component & Net rename
 Electrical Design Rules checking including: preset
- and user definable rules design integrity rules
- On-line Electrical Rules Checking (ERC)
- Electrical rules error browser
- Design browser showing all sheet levels including hierarchical blocks
- Net Class rules definition passed through to PCB design editor
- Save Load Colour files
- Truetype fonts support for display and printing
- Cross sheet references
- Power and ground labels
- Insert shapes
- Optimise gates
- Testpoint Part and notation insertion
- Forward annotation of changes to the PCBSynchronise design at any time to check design
- integrity between SCM and PCB designs
- Back annotation changes from PCBWindows and pen plotter outputs
- DXF Import and Export
- Export Netlists to:
 PADS, Viewlogic, Cadstar, Accel EDA,
 BCAD, 2009/2004/2004 Or CAD, BCC
- PCAD 2000/2001/2004, OrCAD PCB
 User definable Parts and Netlist output
- Predefined drawing profiles supplied
- Built-in integrated Spice based A/D mixed mode simulator (optional)

PCB Layout

- Design area up to 2.0 m by 2.0 m (78" by 78")
- Design in Imperial or Metric
- Unlimited number of Layers
- User defined layer types
- Supports SMT, through-hole and mixed technologies
- Supports embedded component technology
- SMDs both sides of the board
- Angles in degrees or radians
- Integrated Schematics & PCB
- Dynamic drag and drop
- Wizards for: Data Transfer Footprint creation Parts creation
- Plotting and printing
- Track/Via breakouts on footprints
- Wire jumpers/jumper parts
- Manual Placement 'push' and 'return' mode
- Integrated Autoplace (with Autorouter package)
- Keep in/out areas use in Autoplacement

Copyright @WestDev Ltd 2006. All rights reserved. E&OE. Pulsonix is a registered Trademark of WestDev Ltd.All other trademarks are acknowledged to their rightful owners

PESCHGES Variometer GmbH

Zieglerstr. 11

52078 Aachen Tel: 0241 56 30 23 E-mail: vertrieb@peschges-eda.de

Web-site: www.peschges-eda.de