


For suggestions
and improvements
please contact
me at
bernd.wiebus@gmx.de



1:1 Print! Check dimension by controlling the gauge!

KiCAD Footprints of some common mode chokes (Manufactured by Würth) from the folder
CommonModeChoke_Wuerth_Type-WE-CMB_RevA_24Oct2010.pretty

Author: Bernd Wiebus/Uedem/Germany/24th Oct 2010
Licence: CC-Zero / Public Domain

NO RESTRICTION ! NO WARRANTY!



<http://creativecommons.org/>

Sheet:		CommonModeChoke_Wuerth_Type-WE-CMB_RevA_24Oct2010.kicad_pcb
File:		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. kicad (2014-06-29 BZR 4957) - product		Id: 1/1